

Hydrograph state file

Required:

Required when no channel network is specified.

Name:

The name is expected to be of the format `Hydrograph.State.<MM.DD.YYYY.hh.mm.ss>`, where `<MM.DD.YYYY.hh.mm.ss>` is the time for which the model state is valid.

The file is located in the `Initial state` directory.

Read by:

```
InitModelState()
```

Format:

ASCII

Purpose:

Contains the amount of water in each hydrograph. This allows a model restart with exactly the same initial conditions.

Details:

For each hydrograph (one associated with each travel time class), there should be an entry for the total number of time steps in the unit hydrograph. Each value is on a new line.