

Demonstration of Entrained Solids and Sr/TRU Removal Processes with Archived AN-107 Waste

Richard T. Hallen
Kriston P. Brooks
Lynette K. Jagoda

July 2000

Prepared for BNFL, Inc.
under contract W375-98-LC-4168

LEGAL NOTICE

This report was prepared by Battelle Memorial Institute (Battelle) as an account of sponsored research activities. Neither Client nor Battelle nor any person acting on behalf of either:

MAKES ANY WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, with respect to the accuracy, completeness, or usefulness of the information contained in this report, or that the use of any information, apparatus, process, or composition disclosed in this report may not infringe privately owned rights; or

Assumes any liabilities with respect to the use of, or for damages resulting from the use of, any information, apparatus, process, or composition disclosed in this report.

References herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by Battelle. The views and opinions of authors expressed herein do not necessarily state or reflect those of Battelle.

Demonstration of Entrained Solids and Sr/TRU Removal Processes with Archived AN-107 Waste

Richard T. Hallen
Kriston P. Brooks
Lynette K. Jagoda

July 2000

Prepared for
BNFL, Inc.
under contract W375-98-LC-4168

Battelle, Pacific Northwest Division
Richland, Washington 99352

SUMMARY

Waste from Hanford underground storage Tank 241-AN-107 is a candidate low-activity waste (LAW) for Envelope C. Envelope C wastes require pretreatment to remove entrained solids, radioactive strontium, transuranics, radioactive cesium, and technetium before immobilization. The initial baseline pretreatment process includes plans for entrained solids removal by crossflow filtration, Sr/TRU precipitation with added strontium and iron, and Sr/TRU precipitate removal by crossflow filtration. However, studies have shown that entrained solids and the Sr/Fe precipitates were very difficult to filter from candidate Envelope C waste. An alternative pretreatment process being developed uses permanganate instead of iron. Permanganate treatment has been shown to be effective for decontaminating waste from Hanford Tank SY-101.

Small-scale experiments with archived AN-107 waste were conducted by Battelle to determine the effectiveness of the permanganate treatment process. These tests were conducted in three rounds of experiments. The early tests showed that permanganate treatment alone would provide adequate TRU removal, however, it would not provide adequate Sr removal. The second set of experiments showed the preferred Sr/TRU removal process involved addition of strontium and permanganate. Because the composition of the archived waste had been altered by past pretreatment tests (diluted and removal of cesium and settled solids), the final set of experiments included tests with actual AN-107 diluted feed. These tests identified conditions that should provide adequate Sr/TRU decontamination.

The work reported here was conducted to evaluate process conditions with two, 1-L batches of archived AN-107, which provided a volume of waste large enough for crossflow filtration studies. One, 1-L sample of archived waste was adjusted to 1M hydroxide and used for entrained solids removal tests. Following this test, Sr/TRU removal was accomplished by addition of a strontium nitrate solution followed by sodium permanganate solution. The resulting precipitate was used for crossflow filtration tests to demonstrate the performance of a 0.1-um filter element.

Even though many of the entrained solids were removed from the archived AN-107 sample by previous pretreatment testing (settle/decant and deep bed filtration from the ion exchange column), crossflow filtration was found to be impractical to remove the remaining solids due to very low filtrate flux rates (0.0079 gpm/ft²). Therefore, AN-107 waste was treated for Sr/TRU removal with the entrained solids present. The entrained solids were then removed along with the Sr/TRU precipitate, in a single filtration step. Crossflow filtration tests were conducted in the Cell Unit Filter (CUF) system with the Sr/TRU precipitated waste. The filterability of archived AN-107, as determined by filter flux rate, increased by an order of magnitude after the pretreatment process (average of 0.11 gpm/ft²). The pretreated waste could be effectively filtered by crossflow filtration.

Results were obtained from experiments with archived AN-107 samples treated at two different target reagent concentrations, 1M hydroxide, 0.075M strontium, and 0.05M permanganate, and 0.8M hydroxide, 0.05M strontium, and 0.03M permanganate. Approximately 1-L of archived AN-107 were treated in each experiment. Decontamination of strontium-90 and TRU (primarily

Am-241) in the supernatant was greater than needed to meet the immobilized low-activity waste (ILAW) requirements (less than 100 nCi/g TRU and less than 20 Ci/m³ Sr-90 in the final ILAW). The target DFs were 10 for Sr-90 and 5 for Am-241. The strontium-90 decontamination factors (DFs) obtained were consistently greater than 20 and the Am-241 DF was 10 and greater. Removal of Eu isotopes 154 and 155 was slightly less than the Am DFs. These DFs include the contribution from the removal of the entrained solids although this was relatively small. The removal of the entrained solids accounted for very little Sr-90 removal and about 10% of the DF for Am-241 because the archived waste samples had most of the solids already removed.

CONTENTS

1.0	INTRODUCTION.....	1.1
2.0	TEST CONDITIONS AND EXPERIMENTAL PROCEDURES	2.1
2.1	Description of Archived AN-107 Sample	2.1
2.2	Crossflow Filtration	2.1
2.3	Sr/TRU Removal Conditions.....	2.2
2.4	Experimental.....	2.3
2.5	Chemical Analyses.....	2.7
3.0	RESULTS AND DISCUSSION	3.1
3.1	Entrained Solids Removal.....	3.1
3.2	Sr/TRU Decontamination.....	3.2
3.3	Change in Chemical Composition	3.4
3.4	Sr/TRU Solids Removal.....	3.6
4.0	CONCLUSIONS AND RECOMMENDATIONS	4.1
5.0	REFERENCES	5.1
APPENDIX A: TEST INSTRUCTION-041, DATA SHEETS, AND LOG BOOK ENTRIES.....		1
APPENDIX B: TEST INSTRUCTION-063 AND LOG BOOK ENTRIES		1
APPENDIX C: ANALYTICAL DATA		1
APPENDIX D: STAFF AND ROLE/RESPONSIBILITY		1

FIGURES

Figure 2.1. Flow Chart of Archive AN-107.....	2.4
Figure 3.1. Comparison of the Filtrate Flux for Entrained Solids and Sr/TRU Precipitate/Entrained Solids Removal from Archived AN-107 Waste at Target Conditions of 55 psi TMP and 12.2 ft/s Crossflow Velocity.....	3.6
Figure 3.2. Volume-Weighted Particle Size Distribution Comparison Between Archive AN-107 Entrained Solids and Sr/TRU Precipitate.....	3.7
Figure 3.3. Average Filtrate Flux for Conditions Tested With the Archived AN-107 Sr/TRU Precipitate	3.8
Figure 3.4. Particle Size Distribution Comparison of Archive AN-107 Sr/TRU Precipitate With and Without Sonication	3.9

TABLES

Table 2.1. Sr/TRU Target Concentrations and Volume for the Two Experiments Conducted with Archived AN-107.....	2.3
Table 2.2. Test Conditions Studied for Entrained Solids Removal from Archived AN-107	2.4
Table 2.3. Test Conditions Studied With Archive AN-107 Sr/TRU Solids Removal	2.5
Table 2.4. Samples and Their Required Analyses	2.6
Table 2.5. Samples and Their Required Analyses	2.6
Table 3.1. Samples and Mass Dilution for Calculating Decontamination Factors	3.2
Table 3.2. Strontium, Am, and Eu Decontamination Factors for Samples MN-22 to MN- 32 and the Composition of Composite CUF Filtrate (MN-32).....	3.3
Table 3.3. Samples and Mass Dilution for Calculating Decontamination Factors	3.3
Table 3.4. Radioactive Element Decontamination Factors and Composition of Filtrate (MR-03).....	3.4
Table 3.5. Concentration of Major ICP Metals in Samples MN-21 to MN-32 and Sample Density (data not corrected for sample dilution from added reagents).....	3.5
Table 3.6. Concentration of Major ICP Metals in Samples MR-01 to MR-03 (data not corrected for sample dilution from added reagents)	3.5

1.0 INTRODUCTION

BNFL Inc. was awarded the Privatization Contract for treatment of Hanford underground storage tank wastes as part of the River Protection Project-Waste Treatment Plant (RPP-WTP). In Part B-1, Battelle is conducting technology development and demonstration of process flowsheet steps for BNFL. Entrained solids removal by crossflow filtration is the first proposed process step in pretreatment. Filtration should remove sufficient solids to prevent plugging of the ion exchange columns downstream and to ensure that insoluble radioactive strontium and transuranic isotopes (TRU) are removed. These solids are then to be concentrated and returned to the U.S. Department of Energy (DOE). The RPP-WTP Privatization Contract (2000) specifies certain isotopic, chemical, and physical limits for the entrained solids returning to the DOE double-shell tanks.

Three candidate low-activity waste types have been identified: Envelope A, Envelope B, and Envelope C. Treatment and disposal of the liquid (supernatant) fraction of Envelope C wastes, such as Tank 241-AN-107, requires additional treatment to remove transuranics and radioactive strontium. Because of the high concentration of organic complexants in this waste (Complexant Concentrate waste), conventional separation processes (e.g., ion exchange) are not effective.

During Part A-1 of privatization, Savannah River Technical Center (SRTC) developed a Sr/TRU removal process involving isotopic dilution and precipitation with added strontium and iron (SRTC 1997a, 1997b, 1997c, and 1997d). While this treatment process provided the necessary supernatant decontamination, the resulting precipitate could not be filtered. The search began for an alternate treatment process. Battelle proposed permanganate be examined as an alternative, because it had been demonstrated to work with waste from Hanford Tank SY-101, which also contained high levels of organic complexants (Orth et al. 1995).

Permanganate has been examined as an oxidant for complexing agents (Orth et al. 1995), solubilizing chromium (Rapko et al. 1995, Rapko 1998), and oxidation of technetium species to pertechnetate (Schroeder et. al 1998) in tank wastes. Permanganate was found to oxidize chromium first, then organic carbon, and lastly nitrite. For wastes such as Tank SY-101, the chromium in the sludge consumes as much as half the permanganate. Orth et al. recommended permanganate doses of 0.1M for decomplexing SY-101 type wastes. At this level of permanganate, decontamination factors (DF) of > 143 were obtained for Sr and 28.5 for Pu. AN-107 does not have the high chromium values in the sludge so permanganate is expected to be effective at lower concentrations.

Permanganate is also used as a precursor to MnO_2 and/or $\text{Mn}(\text{OH})_2$ coprecipitants via the "Method of Appearing Reagents" (Krot et al. 1996). The method of appearing reagents requires the addition of a reductant to the waste to be treated. However, for Hanford wastes this is not necessary because reductants are already present in the waste. The resulting solids are effective coprecipitants for Pu and other TRU elements but generally not as effective as iron precipitates. Decontamination factors of greater 100 have been reported for various simulated waste streams.

The objective of this work was to demonstrate the entrained solids and Sr/TRU removal processes with archived AN-107 waste before proceeding with the integrated processing of AN-107 diluted feed. Similar to entrained solids removal tests for AW-101 (Brooks et. al 1999), tests

were planned to determine the permeability of an Envelope C feed through a single element filter as a function of transmembrane pressure, axial velocity, solids concentration, and time. The archived AN-107 waste was used to demonstrate the treatment scheme for Sr/TRU removal developed from small-scale tests conducted at Battelle with waste simulants and actual waste involving strontium and permanganate addition. Supernatant decontamination data were obtained from two treatment levels; 0.075M Sr and 0.05M permanganate, and 0.05M Sr and 0.03M permanganate. Crossflow filtration tests were conducted with waste treated with 0.075M Sr and 0.05M permanganate to determine the efficiency for Sr/TRU solids removal. In addition, the efficiency of back pulse and chemical cleaning on the filter performance was evaluated. The chemical and radiochemical composition of the supernatant and filtrates were measured to determine efficiency of the Sr/TRU removal process.

This report contains the results of entrained solids removal, Sr/TRU decontamination, and Sr/TRU solids removal testing conducted at Battelle with archived AN-107 waste. Test conditions and experimental procedures are described in Section 2.0. Results from entrained solids removal and treatment with added Sr and permanganate are described in Section 3.0. The major conclusion and recommendations that evolved from this work are given in Section 4.0. The appendices contain the test instruction, data sheets, logbook entries, analytical data, calculation, and staff role/responsibilities for this work.

2.0 TEST CONDITIONS AND EXPERIMENTAL PROCEDURES

The conditions for conducting the entrained solids and Sr/TRU removal tests were detailed in Sr/TRU Precipitation and Ultrafiltration Test Specification (Townson 1998) issued by BNFL. The Test Specification was used to prepare a Test Plan (TP 29953-013) that described the general requirements for the Sr/TRU removal tests to be conducted at Battelle. The actual test was conducted in accordance with Test Instruction-29953-041, which was specific to the Sr/TRU Removal test described in this report for archived AN-107. Deviations from the test instructions were necessary. The additional Sr/TRU precipitation experiment was conducted in accordance with Test Instruction-29953-063.

2.1 Description of Archived AN-107 Sample

The archived AN-107 material used for this test was collected, diluted, settled solids removed, and cesium ion exchanged prior to its use for the BNFL project (Hendrickson 1997). It was collected as 45 grab samples in 125-mL bottles taken during January 1997. Approximately 5.4 liters of tank waste was then transferred to 222-S laboratory and 0.53M sodium hydroxide was added to dilute the waste to 5M sodium and to a free hydroxide concentration of 0.24M. The supernatant was not filtered prior to cesium ion exchange. Instead, the solids were allowed to settle and the supernatant was decanted and sent through the crystalline silicotitanate loaded columns. Analysis of the waste after cesium removal indicated the free hydroxide to be 0.126M. Following cesium removal the sample was transferred to PNNL in five 1-L poly bottles where it has been stored in the Shielded Analytical Laboratory (SAL) hot cells in the Radiochemical Processing Laboratory (RPL).

In June 1999, one liter of this archive AN-107 (1242.62 g) was adjusted with NaOH pellets to achieve a target concentration of 1M free hydroxide. This material was then transferred to the High-Level Radiochemistry Facility (HLRF) hot cells and placed into the CUF system for entrained solids removal testing.

2.2 Crossflow Filtration

The River Protection Project Waste Treatment Plant (RPP-WTP) (1996) flowsheet uses cross-flow filtration as the solid/liquid separation technique. Unlike traditional dead-end filtration, which has a declining filtration rate caused by the growth of a filter cake on the surface of the filter medium, in cross-flow filtration, the filter cake is swept away by the fluid flowing across it. This filtration method is especially beneficial when there are very fine particles and when system simplicity is required.

One of the applications of crossflow filtration is to remove the entrained solids from the waste. The filtration should remove sufficient solids to prevent plugging of the ion exchange column downstream and to ensure that insoluble Sr-90 and transuranic isotopes are removed. Another application of crossflow filtration for Envelope C wastes is to remove the Sr/TRU precipitate from the treated supernatant. The proposed flowsheet for Envelope C waste shows two sequential solids removal steps: First removal of the entrained solids, then Sr/TRU solids removal after Sr and permanganate treatment.

Crossflow filtration tests were conducted in the HLRF hot cells with the Cell Unit Filter (CUF) system. The CUF had the following specifications:

- Mott sintered stainless steel filter, 0.1 micron rating, 24 in. long and 3/8 in. internal diameter (total area 0.196 ft²)
- Re-circulation flow with a maximum linear crossflow velocity of 16.4 ft/s along the axis of the filter
- Maximum transmembrane pressures of 80 psi
- Temperature control of $25 \pm 5^{\circ}\text{C}$ during operation.

The system was fabricated based on modifications of the CUF system designed by SRTC. It is described in detail in Brooks et al. (1999). Unlike that used for the AW-101 testing, the filter used in this work was a Mott 0.1 μm -rated filter designed specifically for liquid service. Conditions for filtration tests were specified in Test Instruction 29953-041, Appendix A.

2.3 Sr/TRU Removal Conditions

Supernatant from Envelope C waste contains Sr-90 and TRU levels that are too high to meet immobilized low-activity waste (ILAW) requirements. The BNFL targets for ILAW are less than 100 nCi/g TRU and less than 20 Ci/m³ Sr-90 in the final ILAW. For AN-107 waste, this translates to target decontamination factors (DF) of approximately 10 for strontium (90% removal) and 5 for TRU (80% removal). Since over 90% of the TRU in AN-107 is due to Am-241, a decontamination factor of 5 was established for Am-241.

Experimental conditions for Sr/TRU removal were determined based on results from small-scale batch experiments with archived AN-107 waste (Hallen et al. 2000). The hydroxide concentration was increased by the addition of sodium hydroxide as solid pellets or 19M (50 wt%) solution. Strontium nitrate and sodium permanganate were added as 1M solutions. The results from the small-scale experiments suggested that adequate Sr/TRU removal could be obtained at a hydroxide concentration as low as 0.5M and reagent concentrations as low as 0.05M strontium and 0.03M permanganate for the archived AN-107 sample. But conservative conditions were chosen for the filtration tests, 1M hydroxide and reagent concentrations of 0.075M for strontium and 0.05M for permanganate, because the AN-107 diluted feed was more concentrated and contained more entrained solids than the archived waste. As part of an effort to prepare feed for sulfate removal tests, a later Sr/TRU removal experiment was conducted with archived AN-107 adjusted to 0.8M hydroxide and reagent concentrations of 0.05M strontium and 0.03M permanganate. This later sample was not tested in the CUF. Target compositions and volumes are shown in Table 2.1 for both experiments

Table 2.1. Sr/TRU Target Concentrations and Volume for the Two Experiments Conducted with Archived AN-107


High Conc.	Target Concentration (M)	Target Volume (L)	Low Conc.	Target Concentration (M)	Target Volume (L)
initial waste	-	0.82	initial waste	-	1.00
NaOH	1	0.88	NaOH	0.8	1.05
Sr(NO ₃) ₂	0.075	0.95	Sr(NO ₃) ₂	0.05	1.11
NaMnO ₄	0.05	1.00	NaMnO ₄	0.03	1.14

2.4 Experimental

All Sr/TRU and solids removal tests were performed in shielded process cells located in the RPL at Hanford. The CUF system, located in the HILRF, was used for entrained solids and Sr/TRU precipitate removal tests. Test Instruction 29953-041, Appendix A, was used to conduct the entrained solids removal test, Sr/TRU removal at high reagent concentration, and Sr/TRU solids removal test. These tests were conducted from July 16 to July 28, 1999. The flowsheet describing these tests is shown in Figure 2.1.

Efforts were made prior to beginning this testing to ensure that clean water fluxes equal to or greater than the original factory specification were achieved. To do this, the pump and filter were changed out and remaining particulates were removed from the CUF by recirculating a side-stream through a 0.05 μm -rated cartridge filter. The clean water flux was then measured over the course of one hour. During this time, the average filtrate flux was 0.98 gpm/ft² at 20-psi pressure differential and an axial velocity of 11.6 ft/s. The clean water flux did not decline during this time. Following the hour long testing at 20 psid, the filter was tested at 10 and 30 psid for 20 minutes each. The filtrate flux remained relatively constant at 0.395 and 1.41 gpm/ft², respectively. These values were above the Mott reported values of 0.37 gpm/ft² for 10 psid and 0.72 gpm/ft² for 20 psid. The deionized water was drained from the system. It is estimated that approximately 100 mL of deionized water remained in the CUF after draining. This residual water diluted the archived AN-107 sample by roughly 10%.

The entrained solids were tested in the CUF under two conditions rather than the original 6 point matrix due to low filtrate fluxes. If the filtrate flow were less than 10 mL/min during the test, BNFL had specified that the test should be discontinued, the filter should be backpulsed, and a new condition should be tested. By stopping the test prematurely, unnecessary data would not be taken and further filter fouling would be prevented. The test conditions studied are shown in Table 2.2. When the flux was found to be very low for the first condition, two backpulses were attempted. Because of the low filtrate flux, only a small quantity of material could be collected in the backpulse chamber and two short backpulses were performed. A higher pressure was then tested to see if an increased flux were possible. Once again, the filtrate flux was excessively low and the test was discontinued. The entrained solids and filtrate were drained from the CUF and placed back into the original container. Samples were taken during the entrained solids removal test but were not analyzed.



* Samples of filtrate or slurry were taken.

Figure 2.1. Flow Chart of Archive AN-107

Table 2.2. Test Conditions Studied for Entrained Solids Removal from Archived AN-107

Condition	Crossflow Velocity (ft/s)	Transmembrane Pressure (psi)
1	12.2	55
3	9.3	70

The CUF was drained, rinsed once with 0.2M NaOH, and then rinsed and the filter backpulsed multiple times with DI water to achieve a neutral pH. Once neutral conditions were reached, a 0.05 μm cartridge filter was attached to the CUF and the remaining particulate matter was removed. Clean water fluxes were measured and found that the original fluxes had been recovered. The system was drained in preparation for filtration of the Sr/TRU precipitate. Once again approximately 100 mL of DI water left in the CUF further diluted the archived AN-107 during the Sr/TRU precipitation filtration test.

The archived AN-107 sample was transferred to an Erlinmeyer flask and placed on a stir plate. The sample was not heated to 50°C before reagent addition as originally specified in the Test Specification. Small-scale test had shown higher DFs when the reagents were added at ambient temperature, then digested after the addition was complete. At ambient cell temperature, approximately 75 mL of a 1M solution of $\text{Sr}(\text{NO}_3)_2$ was added to the archived AN-107 sample over the course of 5 minutes. The original solution was dark brown, but during addition, white precipitate could be seen forming. Approximately 30 minutes later 50 mL of a 1M solution of NaMnO_4 was added to the archived AN-107 sample over the course of 4 minutes. These quantities were added to produce target concentrations of 0.075M Sr and 0.05M permanganate in the final treated sample. The slurry was then heated to 50°C with constant stirring and remained at temperature for 4 hours. The slurry was allowed to cool overnight and then it was added to the CUF for filtration testing.

Six conditions were tested with the Sr/TRU precipitated, archived AN-107 sample in the CUF. The conditions are shown in Table 2.3. It was not possible to maintain the target flows at the required pressures. This may be due to the higher viscosity associated with the Sr/TRU precipitate or pump stator wear.

Table 2.3. Test Conditions Studied With Archive AN-107 Sr/TRU Solids Removal

Condition	Crossflow Velocity (ft/s)	Transmembrane Pressure (psi)
1	11.2	53
2	11.8	38
3	8.1	70
4	9.1	55
5	6.4	54
6	10.0	54

During the course of testing, samples of the slurry and filtrate were taken for chemical and radiochemical analysis. Slurry samples were taken before $\text{Sr}(\text{NO}_3)_2$ and NaMnO_4 addition and after the 4 hour heating and subsequent cooling of the Sr/TRU precipitate. Filtrate samples were taken during each of the 6 conditions. Two slurry samples were also taken after Condition 3 and at the end of the CUF testing. Not all samples taken were analyzed. A filtrate composite sample, MN-32, was made of filtrate samples taken during each test condition and analyzed. The sample identification and analyses performed on each sample are shown in Table 2.4.

Table 2.4. Samples and Their Required Analyses

Sample Description	Sample ID Number	Sample Type	Sample Preparation	Analytes
Waste after entrained solids test (initial waste)	MN-21	Slurry	0.45 um filter, acid digest	Sr-90, Am-241, Na, OH ⁻
Waste after Sr/TRU Removal Treatment	MN-22	Slurry	0.45 um filter, acid digest	Sr-90, Am-241, Na, OH ⁻
1 st CUF Permeate Sr/TRU Solids Removal	MN-23	Filtrate	acid digest	Sr-90, Am-241, Na
Final CUF Slurry	MN-28	Slurry	acid digest	Sr-90, Am-241, Na
Final CUF Permeate	MN-31	Filtrate	acid digest	Sr-90, Am-241, Na
Composite CUF Permeate	MN-32	Filtrate	acid digest	Sr-90, Am-241, Na

Test Instruction 29953-063 (see Appendix B) was used to conduct the Sr/TRU removal experiment at low reagent concentration. This experiment was conducted on October 26, 1999, to prepare Sr/TRU treated waste for sulfate removal scoping tests. Starting with 1-L of archived AN-107 waste, 48 mL of 50 wt% (19M) NaOH was added to give a calculated free hydroxide concentration of 0.8M. A 50-mL sample of caustic adjusted waste was removed for analyses (MR-01 and MR-02) and density determination. Then at ambient cell temperature, 57 mL of 1M Sr(NO₃)₂ was added with stirring over 6 min. The solution was stirred for an additional 9 min before adding 34 mL of 1M NaMnO₄ over 6 min. The waste was stirred for an additional 30 min before heating to 50°C and held there for 4 hours. After cooling to ambient temperature, the treated waste was filtered through a 0.45 um dead-end filter. The density of the filtrate was determined and a sample collected for analyses (MR-03). Table 2.5 listed the samples and analyses required.

Table 2.5. Samples and Their Required Analyses

Process Variable	Sample ID Number	Sample Type	Sample Preparation	Analytes
Archived AN-107	MR-01	Slurry	acid digest	Sr-90, Am-241, Na
Archived AN-107	MR-02	Slurry	0.45 um filter, acid digest	Sr-90, Am-241, Na
Treated AN-107	MR-03	Filtrate	acid digest	Sr-90, Am-241, Na

2.5 Chemical Analyses

All of the chemical analyses were conducted at Battelle. BNFL designated the analytes of interest and minimum reportable quantity in the test specification (see test instructions in appendix). Because the archived AN-107 sample had most of the radioactive cesium removed, Am-241 concentration could be determined directly by gamma energy analysis along with the Eu isotopes 154 and 155. Relatively high levels of Cs-137 raise the gamma background level in the detector due to Compton scattering, thereby making it difficult to detect other, lower-level gamma emitters, especially those having gamma energies below that of Cs-137. The Sr-90 concentration was determined by chemical separation followed by beta counting. Sodium concentration was determined by inductively couple plasma-atomic emission spectrometry, as well as the other metals listed in the test specification

The samples taken during tests in HLRF were transferred to the SAL for analytical sample preparation. All of the analytical results are included in Appendix C.

3.0 RESULTS AND DISCUSSION

The results of the testing and analyses are discussed below for entrained solids removal, Sr/TRU decontamination, and Sr/TRU solids removal from archived AN-107 samples.

The experimental and test conditions were defined by BNFL in Test Specification (Townson 1998, 1999) documents, change request documents, and direct communications with BNFL staff. General test plans were prepared for LAW crossflow filtration and Sr/TRU removal tests (TP-29953-004 and-013). Test instructions were prepared which detailed the specifics for conducting and documented deviations from the test specification for conducting tests with archived AN-107 waste. The test instructions were used to record the specific details of the tests, and are attached in Appendix A and B.

3.1 Entrained Solids Removal

The proposed pretreatment flowsheet shows entrained solids are removed from the double-shell tank wastes as a first step pretreatment. The entrained solids removal test was conducted with a caustic adjusted (1M hydroxide), archived AN-107 waste sample. The test demonstrated that the entrained solids present in this waste could not easily be removed by crossflow filtration. For entrained solids removal, the initial flux dropped in less than a minute to 0.023 gpm/ft² and within 5 minutes had dropped to 0.0074 gpm/ft² at 55 psi transmembrane pressure (TMP) and 12.2 ft/s crossflow velocity. To prevent further plugging of the filter, no further testing was conducted at this condition. An attempt was made to collect sufficient filtrate to backpulse (clean) the filter. Only a small quantity of material could be collected in the backpulse chamber and two short backpulses were performed. A second condition was then tested at 70 psi and 9.3 ft/s (Condition 3 of the test matrix). In this case, after 1 min the filtrate flux was 0.0079 gpm/ft². Testing was stopped at this point and entrained solids removal was determined to be not feasible for AN-107 waste.

The archived AN-107 sample had most of the entrained solids removed by settle/decant and deep bed filtration as part of the ion exchange column testing. No visible solids remained, yet the sample could not be easily filtered. This suggests fine particles or colloidal solids are suspended in the AN-107 sample that plug or foul the filter media. The high axial velocity of liquid across the filter surface did not help filter performance, which suggests that filter cake build up is not an issue. Entrained solids removal is expected to be worse for AN-107 diluted feed because it has approximately 1% settled solids and has not been diluted and used for ion exchange testing.

The archived AN-107 sample was drained from the CUF and Sr/TRU precipitation test was conducted on the sample containing the entrained solids. The samples collected during the attempted filtration of the entrained solids were not analyzed.

3.2 Sr/TRU Decontamination

Sr/TRU removal tests were conducted at two different target concentrations of caustic and reagent addition. To prepare the waste for the filtration tests using the CUF, chemicals were added to give a calculated final concentration of 1M hydroxide, 0.075M Sr, and 0.05M permanganate. Later as part of the sulfate removal scoping tests, Sr/TRU removal was determined for lower concentrations of added chemicals, 0.8M hydroxide, 0.05M Sr, and 0.03M permanganate. The results from these two experiments will determine the potential to minimize the addition of chemicals and the resulting amount of Sr/TRU removal solids for disposal as high activity waste.

Multiple samples were taken during the Sr/TRU removal tests and analyzed to determine the change in waste composition upon treatment. Samples were taken after various stages of treatment and filtration. The radionuclide composition of the treated samples was compared with the initial composition to determine the extent of decontamination. The initial waste composition is the composition after caustic addition and any dilution that may have occurred. The Decontamination Factor (DF) is defined as the concentration of the component in the initial waste divided by the concentration after treatment, corrected by the amount of dilution that occurred:

$$DF = [A]_i / ([A] * MD)$$

where $[A]_i$ is the concentration of component A per mass in the initial sample, $[A]$ is the concentration of component A per mass in the treated sample, and MD is the mass dilution, final mass of treated solution divided by the initial mass of solution. The final mass is determined by summing up the mass of initial waste and all dilution, adjustments, and/or reagent additions.

The archived AN-107 sample from the entrained solids test was used for the higher reagent concentration, Sr/TRU removal test. At ambient hot-cell temperature, approximately 75 mL of $1\text{M Sr}(\text{NO}_3)_2$ and 50 mL of 1M NaMnO_4 were added to 882 mL of the caustic adjusted (1M) waste drained from the CUF. The precipitated waste was digested at 50°C for 4 hours. Table 3.1 lists the samples analyzed, mass dilution to be used for calculating DFs, and description of the sample.

Table 3.1. Samples and Mass Dilution for Calculating Decontamination Factors

Sample ID	Mass Dilution	Sample Description
MN-21	-	initial waste, filtered and acid digested
MN-22	1.1247	treated waste before CUF tests, filtered and acid digested
MN-23	1.1247	CUF filtrate during Condition 1, acid digested
MN-31	1.1247	CUF filtrate during Condition 6, acid digested
MN-32	1.1247	Composite CUF filtrate, Conditions 1-6, acid digested

The strontium, americium, and europium supernatant decontamination factors for samples MN-22 through MN-32 are shown in Table 3.2. All samples had very high decontamination for Sr and TRU components, greatly exceeding the requirements for ILAW. No decontamination of Co-60 or Cs-137 was observed. The concentration of Sr-90 and major TRU components for CUF composite filtrate, MN-32, is given to represent the expected Sr/TRU concentration of treated AN-107 waste.

Table 3.2. Strontium, Am, and Eu Decontamination Factors for Samples MN-22 to MN-32 and the Composition of Composite CUF Filtrate (MN-32)

	MN-22	MN-23	MN-31	MN-32	Target DF	MN-32 (μCi/g)
Sr-90	23	20	21	19	10	1.82
Am-241	32	20	19	17	5	8.9E-3
Eu-154	15	11	9	9	*	2.3E-2
Eu-155	15	11	8	9	*	1.7E-2

* reduces activity of ILAW

A separate sample of archived AN-107 was used for the lower reagent concentration, Sr/TRU removal test. The caustic level was adjusted by adding approximately 48 mL of 19M NaOH to 1-L of archived AN-107. The waste was well mixed and two samples removed. At ambient hot-cell temperature, approximately 57 mL of 1MSr(NO₃)₂ and 34 mL of 1M NaMnO₄ were added to 1 L of the caustic adjusted (0.8M) waste. The precipitated waste was digested at 50°C for 4 hours. After cooling, the waste was filtered through a 0.45 um deadend filter and a sample of the filtrate collected. Table 3.3 lists the samples analyzed, mass dilution to be used for calculating DFs, and description of the sample.

Table 3.3. Samples and Mass Dilution for Calculating Decontamination Factors

Sample ID	Mass Dilution	Sample Description
MR-01	-	initial waste, acid digested (entrained solids present)
MR-02	-	initial waste, filtered and acid digested
MR-03	1.0929	treated waste filtrate, acid digested

Table 3.4 shows the DFs calculated based on the initial total sample (including entrained solids) and based on initial supernatant only for analyzed radioactive elements. Entrained solids removal contributed little to the DF. For Am-241, entrained solids account for approximately 10% of the total. The DFs were very high and consistent with the earlier Sr/TRU removal test at higher concentration. These results suggest that the decontamination requirements for Sr and TRU can be met with reduced reagent concentrations.

Table 3.4. Radioactive Element Decontamination Factors and Composition of Filtrate (MR-03)

	Total Sample DF	Supernatant DF	Target DF	Composition of Filtrate (uCi/g)
Sr-90	31	37	10	1.0
Am-241	18	10	5	1.3E-2
Eu-154	12	7	*	2.2E-2
Eu-155	12	7	*	1.5E-2
Total Beta	38	35	-	2.1

* reduces activity of ILAW

3.3 Change in Chemical Composition

The Sr/TRU precipitation and solids removal steps changed the chemical composition of the waste samples, i.e. solids and supernatant. Table 3.5 shows the compositional change of the major ICP elements and density for the various samples. The most interesting changes are for Fe and Mn. Both are relatively high in the initial waste (MN-21). On treatment, Fe removal was very high, and most likely correlated directly with the high removal of Am and Eu isotopes. Manganese also decreased significantly, which suggests that soluble Mn, likely Mn(II), is oxidized to insoluble Mn(IV) by reaction with Mn(VII). Calcium is precipitated on treatment while the Sr concentration increased because the original solution was below the saturation level for Sr, and a fraction of the added Sr remained soluble. The free hydroxide, determined by titration, decreased very little on precipitation with Sr and permanganate, 0.03M after correction for dilution. This is in contrast to the earlier proposed Fe precipitation for TRU removal, which consumed 3 times the added Fe concentration of hydroxide ($3 \times 0.075 = 0.225$).

Sample MN-28 is the composition of the precipitated slurry, combined supernatant and precipitated solids. The solids were not analyzed, but comparison of the composition of the slurry to the initial composition and filtrates provides an indication of the solids composition. The solids contain primarily Sr and Mn as expected with lower amounts of Fe and Ca. Comparing the Fe concentration in the initial waste and slurry suggests entrained solids contain significant Fe.

Table 3.5. Concentration of Major ICP Metals in Samples MN-21 to MN-32 and Sample Density (data not corrected for sample dilution from added reagents)

	MN-21 (ug/g)	MN-22 (ug/g)	MN-23 (ug/g)	MN-28 (ug/g)	MN-31 (ug/g)	MN-32 (ug/g)
Ca	227	128	130	220	129	129
Fe	445	4.36	8	687	7.56	5.82
Mn	44.1	3.785	1.13	2810	0.48	0.5
Sr	1.14	112	115	4770	171	159
Na	104000	87900	84600	85200	84200	86200
	M	M	M	M	M	M
Na	5.68	4.69	4.49	4.60	4.47	4.58
OH ⁻	0.87	0.74	-	-	-	-
	g/mL	g/mL	g/mL	g/mL	g/mL	g/mL
density	1.26	1.23	1.22	1.24	1.22	1.22

The lower reagent concentration test included ICP data for initial waste with and without entrained solids, and for the filtrate. The concentration of the major ICP elements for these three samples is given in Table 3.6. The most significant difference between the data from the two different concentrations of added reagents is the higher soluble Mn in sample filtrate from the lower treatment level. The reason for this is not understood.

The composition of the entrained solids can be estimated by comparing the composition of MR-01, initial sample with entrained solids, and MR-02, initial sample filtered before analysis. The solids are rich in Fe and Mn. This is consistent with the data from Lumetta and Hoopes (1999) on washing/leaching of AN-107 solids.

Table 3.6. Concentration of Major ICP Metals in Samples MR-01 to MR-03 (data not corrected for sample dilution from added reagents)

	MR-01 (ug/g)	MR-02 (ug/g)	MR-03 (ug/g)
Ca	246	254	144
Cr	71.4	50.4	31.8
Fe	687	219	11.7
Mn	139	24.6	27.4
Sr	1.2	1.2	109
Na	92700	96000	104000
	(g/mL)	(g/mL)	(g/mL)
density	1.26	1.26	1.26

3.4 Sr/TRU Solids Removal

Removal of entrained solids from the archived AN-107 sample with crossflow filtration was not practical so the Sr/TRU precipitation was conducted with entrained solids present. The resulting slurry, containing both entrained solids and Sr/TRU precipitate, was transferred to the CUF and filtration tests conducted. Figure 3.1 shows filtrate flux data for entrained solids removal alone and for Sr/TRU precipitate/entrained solids removal from archived AN-107 at target conditions of 55 psi TMP and 12.2 ft/s crossflow velocity (Condition 1). The Sr/TRU removal process, precipitation with added $\text{Sr}(\text{NO}_3)_2$ and NaMnO_4 , dramatically improved the filtrate flux rate for the archive AN-107 material. The filtrate flux was an order of magnitude higher for the treated waste, 0.11 gpm/ft² averaged over 30-60 min of testing.




Figure 3.1. Comparison of the Filtrate Flux for Entrained Solids and Sr/TRU Precipitate/Entrained Solids Removal from Archived AN-107 Waste at Target Conditions of 55 psi TMP and 12.2 ft/s Crossflow Velocity

Based on these results, it appears that the Sr/TRU precipitate addition acts as a filter aid. This is further illustrated when the particle size distribution measurements are compared. The entrained solids and Sr/TRU precipitate samples were analyzed using the Microtrac UPA. The particles size distribution of the small particles measured with this instrument are shown in Figure 3.2. Results indicate that the bulk of the entrained solids are one micron and less, while the Sr/TRU precipitate particles are generally larger, beyond the range of the UPA instrument.




Figure 3.2. Volume-Weighted Particle Size Distribution Comparison Between Archive AN-107 Entrained Solids and Sr/TRU Precipitate

It is believed that during subsequent conditions (2-6), the shearing of the pump breaks apart the precipitated flocs resulting in smaller particles that reduce the filtrate flux. The results averaged between 20 and 60 minutes of testing for each condition are shown below in Figure 3.3. The results show a steady decline in filtrate flux over time. In fact, over conditions 2 through 5, it is nearly a linear decrease, in spite of the changes in transmembrane pressure and axial velocity. The pressure and velocity at the initial condition was repeated for the final condition. During the 8.5 hours of run time, the filtrate flux dropped by 55%.

The transmembrane pressure and axial velocity effects can also be seen in this data set. The transmembrane pressure appears to have little effect on the filtrate flux over the range from 38 to 70 psi. In fact, there is a decrease in filtrate flux between condition 2 (at 38 psid) and condition 3 (at 70 psid). The axial velocity, on the other hand, does appear to improve filtrate flux as evidenced by the increase in filtrate flux between condition 5 and condition 6. The reduction in filtrate flux for condition 3 compared to condition 2 may be largely due to the decreased axial velocity, not the increase in pressure.




Figure 3.3. Average Filtrate Flux for Conditions Tested With the Archived AN-107 Sr/TRU Precipitate

In the full-scale process, the material will not continuously run through the pump to the extent seen in these liter-scale tests and thus filtrate fluxes may remain high at the other conditions. Thus, the time effect observed here may not significantly impact design. To remove the time dependency, statistical analysis is required. Non-linear regression was used to develop an equation describing flux as a function of time, axial velocity and transmembrane pressure. By minimizing the residual error, the following equation was developed:

$$Flux = 0.158e^{-time} + 0.00462velocity + 0.000645pressure - 0.0283$$

where flux is the filtrate flux in gpm/ft², time is hours from the start testing, velocity is the crossflow velocity in ft/s and pressure is the transmembrane pressure in psi. The time dependence is assumed to be exponential decay while the velocity and pressure dependence are assumed to be linear. Using this equation, it can be seen that both pressure and velocity increases result in improved filtrate flux. Crossflow velocity has a higher impact on filtrate flux over the conditions studied. Total filtration time is the dominant factor in predicting filtrate flux.

The cause of this reduction in filtrate flux over time may be the result of filter fouling. After cleaning the filter with DI water following the run, the filtrate flux was still significantly less than its original value. This is evidence of filter fouling. Furthermore, there is evidence that the particle size may have been reduced during the course of the run. These fines may become

lodged inside the filter and result in the reduction of filtrate flux. Particle size distribution was performed using a Microtrac UPA with the Sr/TRU precipitate taken after CUF filtration. These samples were analyzed with and without sonication. By sonicating the sample, the effects of shear, similar to that seen in the pump can be evaluated. A plot of the sample PSD before and after sonication is shown in Figure 3.4. The plot shows a reduction in particle size on sonication over the range evaluated. Particles below 0.1 μm particle size were found.




Figure 3.4. Particle Size Distribution Comparison of Archive AN-107 Sr/TRU Precipitate With and Without Sonication

4.0 CONCLUSIONS AND RECOMMENDATIONS

Archived AN-107 waste was used to evaluate entrained solids removal, Sr/TRU decontamination of supernatant, and Sr/TRU solids removal. Even though most of the entrained solids had been previously removed from the archived sample, the residual entrained solids rapidly fouled the filter element resulting in very poor filter performance. An attempt to run at higher pressure resulted in more fouling, and reduced filter performance. Filtration efforts to remove entrained solids were abandoned and the waste was treated for Sr/TRU removal with the entrained solids present.

The new processing scheme for Sr/TRU removal involving precipitation by added strontium and permanganate worked well. The decontamination factors for Sr and TRU components were significantly greater than the ILAW DF requirements for higher reagent concentrations of 1M hydroxide, 0.075M Sr, and 0.05M permanganate and lower reagent concentrations of 0.8M hydroxide, 0.05M Sr, and 0.03M permanganate. These results support the use of lower concentration of reagent additions in future tests. Optimization studies should be conducted to examine the reduction in added hydroxide from 1M to 0.5 M, reduction of Sr from 0.075M to 0.05M, and reduction in permanganate from 0.05M to 0.03M and the impact this reduction has on filtration performance with new samples from Tank AN-107.

The combined entrained solids and Sr/TRU precipitate were successfully filtered in the single element, crossflow filtration unit. The filtrate flux was high, >0.1 gpm/ft², at the initial test conditions of 53 psi and 11.2 ft/s for the treated archived AN-107 sample. The filter flux rate dropped significantly with time as testing progressed and appears to be a result of shearing the agglomerated solids and fouling of the filter element by the resulting fine particles. The relatively low clean water flux rates obtained at the end of the test also indicate filter fouling. Chemical cleaning was required to restore clean water flux rates to pre-test levels. The filter performance as a function of wt% solids could not be determined in this study because the treated waste volume was close to the minimum CUF volume and no dewatering could occur. Additional filtration tests need to be conducted to determine the filtrate flux as a function of wt% solids. Solids washing in the CUF also needs to be conducted to determine filtrate flux rate as a function of solids loading during washing.

5.0 REFERENCES

- Brooks, K. P., P. R. Bredt, G. R. Golcar, S. A. Hartley, M. W. Urie, J. M. Tingey, K. G. Rappe, and L.K. Jagoda. 1999. *Ultrafiltration and Characterization of AW-101 Supernatant and Entrained Solids*, PNWD-3000, Battelle, Richland, Washington.
- Hallen, R. T., K. P. Brooks, and L. K. Jagoda. 2000. *Development of an Alternative Treatment Scheme for Sr/TRU Removal: Permanganate Treatment of AN-107 Waste*, PNWD-3047, Battelle, Richland, Washington.
- Hendrickson, D.W. 1997. *Hanford Complexant Concentrate Cesium Removal Using Crystalline Silicotitanate*, SESC-EN-RPT-005, Rev. 0, SGN Eurisys Services Corporation Richland, Washington.
- Krot, N. N., V. Shilov, A. Bressonov, N. Budantseva, I. Charushnikova, V. Perminov, and L. N. Astafurova. 1996. *Investigation on the Coprecipitation of Elements from Alkaline Solutions by the Method of Appearing Reagents*, WHC-EP-0898, Westinghouse Hanford Company, Richland, Washington.
- Lumetta, G.J. and F.V. Hoopes. 1999. *Washing of the AN-107 Entrained Solids*, PNWD-2469, Battelle Pacific Northwest Division, Richland, Washington.
- Orth, R. J., A. H. Zacher, A. J. Schmidt, M. R. Elmore, K. R. Elliott, G. G. Neuenschwander, and S. R. Gano. 1995. *Removal of Strontium and Transuranics from Hanford Tank Waste via Addition of Metal Cations and Chemical Oxidant - FY 1995 Test Results*, PNL-10766, Pacific Northwest Laboratory, Richland Washington.
- Rapko, B.M., G.J. Lumetta, and M.J. Wagner. 1996. *Oxidative Dissolution of Chromium from Hanford Tank Sludges Under Alkaline Conditions*, PNNL-11233, Pacific Northwest National Laboratory, Richland, Washington
- Rapko, B.M. 1998. *Oxidative Alkaline Dissolution of Chromium from Hanford Tank Sludges Results of FY 98 Studies*, PNNL-11908, Pacific Northwest National Laboratory, Richland, Washington.
- River Protection Project Waste Treatment Plant (RPP-WTP) (formerly TWRS) Privatization Contract (mod. 14). 2000. DE-AC27-RL13308. U.S. Department of Energy, Richland, Washington.
- Schroeder, N. C., J. G. Bernard, D. L. Clark, J. R. Ball, K. R. Ashley, A. P. Truong, and D. L. Blanchard. 1998. *Fundamental Chemistry, Characterization, and Separation of Technetium Complexes in Hanford Wastes*, Environmental Management Science Program Workshop, July 27-30, Chicago, Illinois.
- SRTC 1997a, *Hanford Envelope Archive C Tank Waste Precipitation Study*, March 20, 1997, SRTC-BNFL-004, revision 0, Savannah River Technology Center, Aiken, South Carolina.
- SRTC 1997b, *Hanford Simulant Tank Waste Precipitation Study*, July 8, 1997, SRTC-BNFL-006, revision 1, Savannah River Technology Center, Aiken, South Carolina.

SRTC 1997c, *Hanford Envelope C Tank Waste Precipitation Study*, August 13, 1997, SRTC-BNFL-005, revision 2, Savannah River Technology Center, Aiken, South Carolina.

SRTC 1997d, *Hanford Envelope C Tank Waste Sr/TRU Precipitation Demonstration*, November 18, 1997, SRTC-BNFL-024, revision 0, Savannah River Technology Center, Aiken, South Carolina.

Townson, Paul S., 1998, *Sr/TRU Precipitation and Ultrafiltration Test Specification TSP-W375-99-00004 Rev. 0*, December 15, 1998, BNFL Inc., Richland, Washington.

Appendix A: Test Instruction-041, Data Sheets, and Log Book Entries

Scoping Studies: Entrained Solids Removal, Permanganate Treatment for Sr/TRU Removal, and Precipitate Removal from Archived AN-107

Data Sheets

Log Book Entries

Appendix B: Test Instruction-063 and Log Book Entries

Sr/TRU Removal from Archived AN-107 with Minimal Reagent Addition

Log Book Entries

Appendix C: Analytical Data

Appendix D: Staff and Role/Responsibility

Staff Member	Role/Responsibility
Richard Hallen	Scientist/Technical Leader - Sr/TRU Precipitation
Kriston Brooks	Engineer/CUF System, Entrained Solids Removal, Sr/TRU Precipitation, and Precipitate Removal
Lynette Jagoda	Engineer Associate/CUF System, Entrained Solids Removal, Sr/TRU Precipitation, and Precipitate Removal
Gita Golcar	Scientist/Particle Size Analyses
Don Rinehart	Technician/Hot Cell Tests-Sr/TRU PPT/CUF Operation
Ralph Lettau	Technician/Hot Cell Tests-Sr/TRU PPT/CUF Operation
Dave Ortiz	Technician/Hot Cell CUF Operation and Cleaning
Vaughn Hoopes	Technician/Hot Cell sample prep.
Mac Zumhoff	Technician/Hot Cell Operations

DISTRIBUTION

No. of
Copies

No. of
Copies

OFFSITE

ONSITE

2 DOE/Office of Scientific and Technical
Information

5 British Nuclear Fuels, Limited
M. E. Johnson (4) BN-FL
A. Thompson BN-FL

14 Pacific Northwest National Laboratory
K. P. Brooks K6-24
R. T. Hallen (5) K2-12
L. K. Jagoda K6-24
D. E. Kurath P7-28
E. V. Morrey P7-28
Technical Report Files (5)

Appendix A: Test Instruction-041, Data Sheets, and Log Book Entries

**Scoping Studies: Entrained Solids Removal, Permanganate Treatment for
Sr/TRU Removal, and Precipitate Removal from Archived AN-107**

Data Sheets

Log Book Entries



RT HALLEN

Date 6/10/99

Route

File T1-041Copy → from 0203 Brooks

Task 2.3 & 2.5

29953

PNNL Test Instruction		Document No.: BNFL-TP-29953-041 Rev. No.: 0
Title: Scoping Studies: Entrained Solids Removal, Permanganate Treatment for Sr/TRU Removal, and Precipitate Removal from Archived AN-107 (previously treated by Cs IX)		
Work Location: RPL SFO HLRF	Page 1 of 15	
Author: Richard T. Hallen	Effective Date: Upon Final Approval Supersedes Date: New	
Use Category Identification: Information		
Identified Hazards: <input type="checkbox"/> Radiological <input type="checkbox"/> Hazardous Materials <input type="checkbox"/> Physical Hazards <input type="checkbox"/> Hazardous Environment <input type="checkbox"/> Other:	Required Reviewers: <input checked="" type="checkbox"/> Technical Reviewer <input type="checkbox"/> SFO Manager	
Are One-Time Modifications Allowed to this Test Instruction? <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No NOTE: If Yes, then modifications are not anticipated to impact safety. For documentation requirements of a modification see SBMS or the controlling Project QA Plan as appropriate.		
On-The Job Training Required? <input type="checkbox"/> Yes or <input checked="" type="checkbox"/> No FOR REVISIONS: Is retraining to this procedure required? <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No Does the OJT package associated with this procedure require revision to reflect procedure changes? <input type="checkbox"/> Yes <input type="checkbox"/> No <input checked="" type="checkbox"/> N/A		
Approval	Signature	Date
Author	<u>Richard T. Hallen</u>	<u>6/9/99</u>
Technical Reviewer	<u>H. Brooks</u>	<u>6/9/99</u>

Uncontrolled Copy

- see 0203 Brooks

1.0 Applicability

This test instruction is to be used to perform studies on entrained solids removal, permanganate treatment for Sr/TRU removal and precipitate solids removal from archived AN-107 waste that has been previously treated by cesium ion exchange resin. The entrained solids and precipitate will be removed using the Cell Unit Filter (CUF) in the HLRF A-cell from approximately 1-L of AN-107 waste (C3E5, C3E4 and/or C3E6). The permanganate treatment is to be conducted after the entrained solids removal and before precipitate removal.

2.0 Supporting Documents

This test instruction is not a stand-alone document. It will be used in conjunction with PNNL Operating Procedure BNFL-TP-29953-020 which contains the necessary procedural information for the safe operation of the CUF. It is also linked to PNNL Test Plan #s BNFL-TP-29953-004 and -013 which contains an overall description of the project, ES&H compliance, emergency response, and the hazards assessment and mitigation. Scoping tests on the permanganate treatment of AN-107(cesium removed) is described in detail in test instruction, TP-29953-037.

3.0 Responsible Staff

The staff responsible for executing this test plan are as follows.

- Task Managers – Kriston Brooks and Rich Hallen
- SFO Manager – Randy Thornhill
- Test Scientists/Engineers – Kriston Brooks, Ken Rappe, Lynette Jagoda, Sam Bryan, and Rich Hallen
- Hot Cell Technician – Mac Zumhoff, Don Rinehart, and Ralph Lettau
- Radiological Control Technician

4.0 Materials, Equipment, Supplies and Reagents Needed

4.1 Materials Required

- ✓ 1. Twenty two 20 mL glass scintillation vials for filtrate and slurry samples, pre-labeled on top and side as follows: MN-21 through MN-30 and CUF-AAN107-01 through CUF-AAN107-10, and Tc IX -01 and Tc IX-02.
- ✓ 2. Three 1 liter polyethylene bottles. They should be labeled as follows: "MNO4 CUF Slurry," "CUF Archive AN-107 First Rinse" and "MNO4 CUF First Rinse." The bottle labeled "MNO4 CUF Slurry" should be marked with graduation lines at 100 mL intervals up to 1000 mL.
- 3. Two 10 liter containers, one labeled for the alkaline rinses and the other labeled for the acidic rinses.
- 4. Containers for draining from the bottom of the pump and from the sample valve.
- ✓ 5. 12 liters of 0.2 micron filtered DI water for determining clean water flux and for rinsing the CUF

4.2 Equipment

- ✓ 1. 4000 gram balance
- ✓ 2. pH paper

- ✓3. Hand held camera. To be used to read filtrate flowmeter.
- ✓4. Stopwatch
- ✓5. Calculator
- 6. CUF Ultrafiltration system with 100 mL plug in place using 0.1 micron Mott-L filter and new pump rotor
- 7. 1000 W Chiller
- 8. 2-L flask
- 9. hot-stir plate (E-cell)
- 10. big stir bar
- 11. 2 mL pipet

4.3 Reagents Needed

- 1. 2 liters of 1M HNO₃ + 0.1-0.2M Citric Acid
- 2. 1 liter of 5 ppm hypochlorite solution (pH > 7)
- ✓3. 50 mL of 1.0M NaMnO₄
- ✓4. 75 mL of 1.0M Sr(NO₃)₂
- ✓5. 1 liter of Archive AN-107 that has been adjusted to 1M OH

4.4 Other Supplies

- ✓1. Workplace Copy of Operating Procedure BNFL-TP-29953-020
- ✓2. Extra Copies of Data Sheets 1, 2, and 3
- ✓3. Laboratory Record Book
- ✓4. DAS disk for recording data

BNW-13745

5.0 Test Instructions for CUF Operation and Permanganate Treatment

The laboratory record book (LRB) shall be used to record other testing information as required by this procedure and all test conditions not stated by this procedure.

Cross-contamination between samples and contamination of samples from outside sources must be minimized at each step. Use new tools and bottles for each sample as much as possible. Those tools that are reused should be washed and rinsed prior to reuse.

Keep all test materials in sealed containers as much as possible to prevent them from drying.

5.1 Pre-start for Scoping Studies

5.1.1 Inventory materials, equipment, supplies, and reagents to ensure all required items are available. Assure that all materials have been modified for remote handling.

5.1.2 Do the following and initial and date when each item is completed.

_____ Review PNNL Operating Procedure BNFL-TP-29953-020.

_____ Review the work instructions in BNFL-TP-29953-041.

5.1.3 Conduct the "0.0 Pre-Start" operations in BNFL-TP-29953-020. Drain the system overflow container.

5.1.4 Perform "1.0 Start-Up" operations in BNFL-TP-29953-020 with 1 liter of filtered DI water with one variation: V4 the filtrate control valve should be closed. Run CUF for 5 minutes at between 4-6 gpm. In-line pressure should be varied from using V1 from 10 to 70 psig. Ensure that there are no leaks in the system. If leaks are detected, shut down system immediately.

5.1.5 Conduct the "10.0 Draining the system" operation in BNFL-TP-29953-020.

5.1.6 Perform "1.0 Start-Up" operations in BNFL-TP-29953-020 with 1.0 liter of filtered, distilled water with one variation: V4 the filtrate control valve should be closed. Run CUF for 5 minutes at between 4-6 gpm. In-line pressure should be varied from using V1 from 10 to 70 psig.

5.1.7 Conduct the "10.0 Draining the system" operation in BNFL-TP-29953-020.

5.1.8 Perform "1.0 Start-Up" operations in BNFL-TP-29953-020 with 1.0 liter of filtered, distilled water

5.1.9 Perform "6.0 Back pulsing" operations in BNFL-TP-29953-020.

5.1.10 Shut off the system and conduct the "10.0 Draining the system" operation in BNFL-TP-29953-020.

5.1.11 Perform "1.0 Start-Up" operations in BNFL-TP-29953-020 with 1.0 liter of filtered, distilled water.

5.1.12 Conduct the "3.0 Operation during Ultrafilter Recycle Mode" operations in BNFL-TP-29953-020 using the conditions below. Filtrate flow rate should be monitored and data collected in the operating procedure. Each test should be performed for only 20 minutes and the system should be back pulsed. After each condition, the test engineer should initial and date the table below.

Condition	Flowrate (gpm)	Transmembrane Pressure (psig)	Initial and date when complete
1	4.20	10	<i>[Signature]</i> 7/16/99
2	4.20	20	<i>[Signature]</i> 7/16/99
3	4.20	30	<i>[Signature]</i> 7/16/99

5.1.13 Shut off the system and conduct the "10.0 Draining the system" operation in BNFL-TP-29953-020.

5.2 Start-Up for CUF Operation

5.2.1 Obtain the following information:

M&TE List:

PM4000 Balance 1:

Calib ID 362-06-01-054
Location A-cell North

Calib Exp Date 8/99

PM4000 Balance 2:

Calib ID 362-06-01-061
Location A-cell South

Calib Exp Date 8/99

Thermocouple:

Calib ID _____
Location _____

Calib Exp Date _____
Thermocouple type _____

Digital Thermometer:

Calib ID _____
Location _____

Calib Exp Date _____

5.2.2 Record the tare and sample weight of AN-107 with storage bottles (verify/identify sample is AN-107 id#). (This bottle should have had 40 grams of NaOH pellets in it to raise the hydroxide concentration to 1M.) Record the weight(s) below.

Bottle Label Archive AN-107 w/ 1M NaOH

Tare bottle 127.82 g NaOH wt 39.98 g

Bottle and sample 1415.77 g AKG 6/9/99
1410.42 g AKG 7/15/99

5.2.3 Conduct the "1.0 Start-Up" operations in BNFL-TP-29953-020 using AN-107. Shake the waste thoroughly before adding it to the slurry reservoir. There may be some solids left the jars that cannot be transferred by shaking. If so, consult with the cognizant engineer on recovering these solids. DI water addition or scraping the sides with a spatula could be attempted. Record the method of recovery in the LRB.

5.2.4 Record the weight(s) of empty reaction vessel or sample bottles in the spaces provided below.

Empty bottle _____ g

1242.62 g
of Archived
AN-107
- check
density
of
AN-107
1.279
= 978.0

ADDED _____ g
TOTAL _____ g

5.2.5 Record the level in the slurry reservoir sight glass.

Height 6 inches

5.3 CUF Operation: Entrained Solids Removal Test with AN-107

5.3.1 Conduct the "3.0 Operation during Ultrafilter Recycle Mode" operations in BNFL-TP-29953-020 using the conditions below. Filtrate flow rate should be monitored and data collected as specified in the operating procedure. After each condition, the test engineer should initial and date the table below. If no filtrate flow occurs or the filtrate flow is less than 10 mL/min, discontinue testing and move to the next condition. After each condition, the test engineer should initial and date the table below.

NOTE: Samples of filtrate should be taken within the first 10 minutes of operation during Condition 1 and 30 minutes into each of the other 5 conditions. A slurry sample should be taken during Condition 3. Instructions for sampling are provided below.

NOTE: Test conditions below are suggested and all conditions do not need to be run, make sure condition 1 is run for 1 hour, other conditions should be run at least 20 minutes, run as many of the conditions as time allows.

Condition	Flowrate (gpm)	Transmembrane Pressure (psig)	Initial and date when complete
1	4.20	55	
2	4.20	40	
3	4.20	70	
4	3.13	55	
5	5.23	55	
6	4.20	55	

5.3.2 Obtain 1 filtrate sample of at least 10 grams within the first 10 minutes of operation (during Condition 1). Record the weight and sample number in Data Sheet 3. These will be used for chemical and radiochemical analyses.

5.3.3 Obtain filtrate samples of at least 5 grams each following "8.0 Filtrate Sampling" in BNFL-TP-29953-020 and using the pre-labeled sample vials after approximately 30 minutes of operation for each condition. Record the weight and sample number in Data Sheet 3. These will be used for chemical and radiochemical analyses.

Tare Wts
CUF AAN 107-01
CUF AAN 107-02

Tare
17.0259
17.0349

with Sample
25.580

Not run -
filter
plugs

5.3.4 Obtain 2 slurry samples of at least 10 grams following "7.0 Slurry Sampling" in BNFL-TP-29953-020. The samples should be taken after condition 3. The first slurry sample should not be saved, but dumped back into the tank. Record the weight and sample number in Data Sheet 3.

5.3.5 Tare weigh a prelabeled 20 mL sample vial.

5.3.6 Using a pipet, transfer 2 mL from each of the 6 filtrate sample vials taken previously in step 5.3.3 into the sample vial. Record the weight and sample number in Data Sheet 3. This composite will be used for chemical and radiochemical analyses.

5.3.7 Conduct the "11.0 Shutting down" operation in BNFL-TP-29953-020.

5.4 Entrained Solids Removal Test: Rinsing and Draining the System

5.4.1 Tare the 1 liter bottle labeled, "~~MNO₄ CUF Slurry~~"

Weight of bottle and lid 1290.86 g

5.4.2 Conduct the "10.0 Draining the system" operation in BNFL-TP-29953-020. Collect liquid in 1 liter bottle. Make sure as much materials as possible has been collected. This materials will be used for the permanganate treatment. Weigh bottle after all liquid has been removed.

Weight of slurry, bottle and lid _____ g

Weight of material collected _____ g

NOTE: Sections 5.5, 5.6 and 5.7 can be completed after Step 5.4.2

5.4.3 Conduct the "9.0 Rinsing the system" operation in BNFL-TP-29953-020. The first rinse should be done with 1 liter of distilled water. This liquid should be collected and saved in the container labeled "CUF Archive AN-107 First Rinse." The second rinse should be done with 2 liters of filtered, distilled water, and the final rinse with 1 liter filtered, distilled water. The second and third rinses should be collected separately from the first in the alkaline rinse storage container. Conduct the acid wash of the CUF unit with 1M HNO₃/0.1-0.2M Citric Acid as described in the CUF operating procedure. The acidic solutions should be allowed to sit in the CUF overnight. When drained, the acidic solutions should be placed in a separate container.

5.4.4 The CUF should be drained according to "10.0 Draining the system" operation in BNFL-TP-29953-020 and rinsed at least 3 times with filtered, distilled water to bring the pH back up to neutral. The acidic solutions should be placed in a separate container from the alkaline ones.

5.4.4 Perform "1.0 Start-Up" operations in BNFL-TP-29953-020 with 1.0 liter of filtered, distilled water.

5.4.5 Perform "6.0 Back pulsing" operations in BNFL-TP-29953-020.

5.4.6 Shut off the system and conduct the "10.0 Draining the system" operation in BNFL-TP-29953-020.

5.4.7 Perform "1.0 Start-Up" operations in BNFL-TP-29953-020 with 1.0 liter of filtered, distilled water.

5.4.8 Conduct the "3.0 Operation during Ultrafilter Recycle Mode" operations in BNFL-TP-29953-020 using the conditions below. Filtrate flow rate should be monitored and data collected in the operating procedure. Each test should be performed for only 20 minutes and the system should be back pulsed. After each condition, the test engineer should initial and date the table below.

Condition	Flowrate (gpm)	Transmembrane Pressure (psig)	Initial and date when complete
1	4.20	10	
2	4.20	20	
3	4.20	30	

5.4.9 Shut off the system and conduct the "10.0 Draining the system" operation in BNFL-TP-29953-020.

5.5 Sr/TRU Removal by Permanganate Treatment

NOTE: Sections 5.5, 5.6 and 5.7 can be completed after Step 5.4.2

5.5.1 Setup the ppt reaction equipment as specified. The precipitation is to be conducted in a 2L flask. Secondary containment should be used to allow recovery from a possible breach of the 2 L flask. Place stir bar in flask.

Shake the bottle of waste thoroughly and collect two 20 mL one in the vial labeled Tc IX-01 and one in MN-21. Shake and transfer the remaining waste to the reaction vessel. There should be some solids. If solids are observed, record observation or notify the cognizant scientist/engineer (record observations in the LRB).

5.5.2 Record the weight(s) of the empty bottle with lid in the spaces provided below. Calculate the amount of material transferred to the reaction vessel. The cognizant scientist/engineer will calculate the amount of strontium and permanganate solution to add.

AN-107

Full 1239.16 g Full g
Empty 31.45 g Empty g

900 mL mark on 2 liter flask

Added 1107.71 g Added g Total g

Density = g/mL total volume added mL

5.5.3 Calculate the amount of strontium and permanganate solution to add. The cognizant scientist/engineer calculations are to be reviewed prior to the additions, and retained in the project files.

75 mL Sr(NO₃)₂ (1M)
Record here and below 50 mL Density g/mL Weight g

5.6 Permanganate Treatment of AN-107

5.6.1 Turn on stirrer. ~~Turn heat on and heat to 50 ± 5°C.~~ Do not heat! *RTH 7/26/99*

5.6.2 While continuously stirring the waste sample, personnel are to slowly add 75 mL of 1.0 M Sr(NO₃)₂ solution per each liter of AN-107 sample. (based upon BNF-003-98-0023, add 1M Sr at a rate of 2 to 20 mL/min/L of waste, target 10 mL/min/L of waste) - add over 5-10 minute period - then stir for additional 5-10 minutes until well mixed. *RTH 7/26/99*
Tare bottle of 1M Sr 184.3352 g
Tare Empty bottle 100.522
Weight Added 83.813

~~5.6.4 Heat the waste mixture at 50 ± 5°C with stirring for 2 hours after completing the addition of the Sr.~~ *RTH 7/26/99*

5.6.5 Slowly add 50 mL of 1 M NaMnO₄ solution per each liter of AN-107 sample. (based upon BNF-003-98-0023, add 1 M NaMnO₄ at a rate of 2 to 20 mL/min/L of waste, target 10mL/min/L of waste) add over a 5-10 minute period - then stir for an additional 5-10 minutes until well mixed. *RTH 7/26/99*
Tare bottle of 1M NaMnO₄ 112.1823 g
Tare Empty bottle 57.857 g
Weight Added 54.325 g *4 RTH 7/26/99*

5.6.6 Heat the waste mixture at 50 ± 5°C with stirring for 4 hours after completing the addition of the NaMnO₄.

5.6.6 Turn off the stirrer and allow the waste to cool to 25 ± 5°C. If possible, use a video recorder to document the settling behavior of the waste mixture. Record the volume of settled solids. Not performed *RTH 8/3/99*

5.6.7 ~~Stir waste and~~ Collect two 20 mL samples, one in Tc IX-02 and one in MN-22. - of supernat after cooling/settling.

5.7 Completion of Permanganate Treatment/Precipitation and Startup of CUF Testing

(The solids removal from the reaction vessel is to occur as soon after precipitation as possible. If for some reason, a delay is required between precipitation and solids removal, transfer the slurry from the reaction vessel to 1 or 2 - 1 liter poly bottles as needed.)

5.7.1 Conduct the "1.0 Start-Up" operations in BNFL-TP-29953-020 using permanganate treated AN-107. Record the weight of the reaction vessel and ppt. Shake/mix the waste slurry thoroughly before transferring to the slurry reservoir. There may be some solids left in the flask that is difficult to transfer. If so, consult with the cognizant scientist/engineer on recovering these solids. DI water addition/washing could be attempted if the amount of solids looks significant. Record the method of recovery in the LRB.

5.7.3 Record the weight(s) of empty reaction vessel or sample bottles.

Vessel and ppted AN-107 2204.704 g
 Empty vessel 1024.37 g
 ADDED 1180.40 g

5.7.3 Record the level in the slurry reservoir sight glass.

Height Not seen inches

5.8 CUF Operation: Sr/TRU Precipitate Removal Test with Archived AN-107

5.8.1 Conduct the "3.0 Operation during Ultrafilter Recycle Mode" operations in BNFL-TP-29953-020 using the conditions below. Filtrate flow rate should be monitored and data collected as specified in the operating procedure. After each condition, the test engineer should initial and date the table below. If no filtrate flow occurs or the filtrate flow is less than 10 mL/min, discontinue testing and move to the next condition. After each condition, the test engineer should initial and date the table below.

NOTE: Samples of filtrate should be taken within the first 10 minutes of operation during Condition 1 and 30 minutes into each of the other 5 conditions. A slurry sample should be taken during Condition 3. Instructions for sampling are provided below.

NOTE: Test conditions below are suggested and all conditions do not need to be run, make sure condition 1 is run for 1 hour, other conditions should be run at least 20 minutes, run as many of the conditions as time allows.

Condition	Flowrate (gpm)	Transmembrane Pressure (psig)	Initial and date when complete
1	4.20	55	<u>[Signature]</u> 7/27/99
2	4.20	40	<u>[Signature]</u> 7/27/99
3	4.20	70	<u>[Signature]</u> 7/27/99
4	3.13	55	<u>[Signature]</u> 7/27/99
5	5.23	55	<u>[Signature]</u> 7/27/99

6	4.20	55	
---	------	----	--

5.8.2 Obtain 1 filtrate sample of at least 10 grams within the first 10 minutes of operation (during Condition 1). Record the weight and sample number in Data Sheet 3. These will be used for chemical and radiochemical analyses.

5.8.3 Obtain filtrate samples of at least 5 grams each following "8.0 Filtrate Sampling" in BNFL-TP-29953-020 and using the pre-labeled sample vials after approximately 30 minutes of operation for each condition. Record the weight and sample number in Data Sheet 3. These will be used for chemical and radiochemical analyses.

5.8.4 Obtain 2 slurry samples of at least 10 grams following "7.0 Slurry Sampling" in BNFL-TP-29953-020. The samples should be taken after condition 3. The first slurry sample should not be saved, but dumped back into the tank. Record the weight and sample number in Data Sheet 3.

5.8.5 Tare weigh a prelabeled 20 mL sample vial.

5.8.6 Using a pipet, transfer 2 mL from each of the 6 filtrate sample vials taken previously in step 5.8.3 into the sample vial. Record the weight and sample number in Data Sheet 3. This composite will be used for chemical and radiochemical analyses.

5.8.7 Conduct the "11.0 Shutting down" operation in BNFL-TP-29953-020.

5.9 Sr/TRU Precipitate Removal Test: Rinsing and Draining the System

5.9.1 Tare the 1 liter bottle labeled, "MNO₄ CUF Slurry."

Weight of bottle and lid ~~_____~~ g

5.9.2 Conduct the "10.0 Draining the system" operation in BNFL-TP-29953-020. Collect liquid in 1 liter bottle. Make sure as much materials as possible has been collected. This materials will be used for the permanganate treatment. Weigh bottle after all liquid has been removed.

Weight of slurry, bottle and lid ~~_____~~ g

Weight of material collected ~~_____~~ g

~850 ml removed

5.9.3 Conduct the "9.0 Rinsing the system" operation in BNFL-TP-29953-020. The first rinse should be done with 1 liter of distilled water. This liquid should be collected and saved in the container labeled "MNO₄ CUF First Rinse." The second rinse should be done with 2 liters of filtered, distilled water, and the final rinse with 1 liter filtered, distilled water. The second and third rinses should be collected separately from the first in the alkaline rinse storage container. Conduct the acid wash of the CUF unit with 1M HNO₃/0.1-0.2M Citric Acid as described in the

CUF operating procedure. The acidic solutions should be allowed to sit in the CUF overnight. When drained, the acidic solutions should be placed in a separate container.

5.9.4 The CUF should be drained according to "10.0 Draining the system" operation in BNFL-TP-29953-020 and rinsed at least 3 times with filtered, distilled water to bring the pH back up to neutral. The acidic solutions should be placed in a separate container from the alkaline ones.

5.9.4 Perform "1.0 Start-Up" operations in BNFL-TP-29953-020 with 1.0 liter of filtered, distilled water.

5.9.5 Perform "6.0 Back pulsing" operations in BNFL-TP-29953-020.

5.9.6 Shut off the system and conduct the "10.0 Draining the system" operation in BNFL-TP-29953-020.

5.9.7 Perform "1.0 Start-Up" operations in BNFL-TP-29953-020 with 1.0 liter of filtered, distilled water.

5.9.8 Conduct the "3.0 Operation during Ultrafilter Recycle Mode" operations in BNFL-TP-29953-020 using the conditions below. Filtrate flow rate should be monitored and data collected in the operating procedure. Each test should be performed for only 20 minutes and the system should be back pulsed. After each condition, the test engineer should initial and date the table below.

Condition	Flowrate (gpm)	Transmembrane Pressure (psig)	Initial and date when complete
1	4.20	10	
2	4.20	20	
3	4.20	30	

5.9.9 Shut off the system and conduct the "10.0 Draining the system" operation in BNFL-TP-29953-020.

5.10 Experimental Clean Up and Sample Disposition.

Clean up all of the equipment used.

Do not discard any samples without written instructions from the task manager. Duplicate samples were collected at all sampling points, but only primary samples submitted for analyses. The duplicates are to be retained until review of the analytical data is completed and notification is writing is received to dispose of these samples. The alkaline and acid CUF wash solutions should be disposed of properly.

6.0 Sample Analysis

The point of contact for physical property sample analysis of the slurry samples is Paul Bredt. The point of contact for the sample analysis of the filtrate, wash, and filtered solids samples is Mike Urie and Rick Steele.

6.1 Chemical and Radiochemical Analysis

The points of contact for the sample analysis of the slurry and filtrate samples are Mike Urie and Rick Steele.

The following samples should be transferred to the SAL hot cells for prep work and analysis for the entrained solids test if the average filtrate flow at any condition is >40 mL/min:

- One sample of slurry from CUF described in Step 5.3.4
- Initial sample of filtrate taken during Condition 1 described in Step 5.3.2
- Final sample of filtrate taken during Condition 6 described in Step 5.3.3
- Composite filtrate prepared in Step 5.3.6

The following will be performed on the above samples if they are analyzed: TOC/TIC on the original sample, then acid digest followed by GEA, Sr-90 analysis and ICP-AES.

The two samples labeled Tc IX-01 and Tc IX-02 should be transfer to the SAL and Dean Kurath notified of their arrival. These samples will be used for batch contacts with Tc ion exchange resins.

The two 20g samples, MN-21 and MN-22 should be transferred to the SAL hot cells for prep work and analysis for the Sr/TRU precipitation test. Once in SAL the samples should be filtered with 0.45 micron disposable syringe filter as soon as possible (or filter in A-cell when taken).

The following samples should be transferred to the SAL hot cells for prep work and analysis from the Sr/TRU Precipitate Removal test:

- Initial sample of filtrate taken during Condition 1 described in Step 5.8.2 (ICP, Sr and GEA)
- Final sample of filtrate taken during Condition 6 described in Step 5.8.3 (ICP, Sr and GEA)
- Composite filtrate prepared in Step 5.8.6 (ICP, Sr and GEA)
- One sample of slurry from CUF described in Step 5.8.4 (acid digest-ICP, Sr and GEA)

Table 3 below shows the sample analysis list for the Sr/TRU precipitation and SR/TRU solids removal test. The table lists the analyses to be performed on samples generated from this test instruction.

Table 3. Samples and Their Required Analyses (if vial numbers differ, cross out and show actual 3)

Process Variable	Vial ID	Sample Type	Sample Preparation	Analysis Description ^(a)
AN-107 after entrained solids	MN-21	as received	0.45 um filter, acid digest	Sr/Am, [OH]
AN-107 after Sr/TRU PPT	MN-22	ppted waste	0.45 um filter, acid digest	TOC/TIC, Sr/Am, ICP, [OH]
1 st CUF Permeate Sr/TRU PPT	MN-23	CUF filtrate	acid digest	Sr/Am, ICP
Final CUF Permeate	MN-24	CUF filtrate	acid digest	Sr/Am, ICP
Composite CUF Permeate	MN-25	Filtrate	acid digest	Sr/Am, ICP
Final CUF Slurry	MN-26	Slurry	acid digest	Sr/Am, ICP

(a) Descriptions of analyses are contained in Table 4.

Table 4. Description of Analyses

Constituent	Analysis Method	PNNL Procedure No.
Americium-241, Eu isotopes	GEA	PNL-ALO-450
Strontium-90 (Yttrium-90)	Separations and Beta Counting	PNL-ALO-476/431
Hydroxide	EPA SW-846 Modified Method, 310(3)	PNL-ALO-228
TOC/TIC		
Metal Ions (see Table 5 list)	ICP-AES	PNL-ALO-211/280

Table 5. Analytical Requirements for Supernate/Filtrate and Centrifuged Solids

Analyte	Centrifuged Solids Minimum Reportable Quantity microCi/gm	Supernate/Filtrate Minimum Reportable Quantity microCi/ml	Analysis Method
Strontium-90	7.01E+01	1.5E-01	Chemical Separation & Beta Count
Americium-241	1.2E-03	7.2E-04	GEA
	microgm/gm	microgm/ml	
Al	3.3E+02	7.5E+01	Acid Digestion followed by ICP-AES
Ba	6.0E+02	7.8E+01	
Ca	1.8E+02	1.5E+02	
Cd	1.1E+01	7.5E+00	
Co	3.0E+00	3.0E+01	
Cr	1.2E+02	1.5E+01	
Cu	1.8E+01	1.7E+01	
Eu	NA	NA	
Fe	1.4E+02	1.5E+02	
K	1.5E+03	2.0E+02	
La	6.0E+01	3.5E+01	
Mg	5.4E+02	1.5E+02	
Mn	3.0E+02	1.5E+02	
Mo	6.0E+00	9.0E+01	
Na	1.5E+02	7.5E+01	
Ni	1.6E+02	3.0E+01	
Pb	6.0E+02	3.0E+02	
Si	3.0E+03	1.7E+02	
Sr	3.0E+02	8.7E+01	
Ti	1.5E+02	1.7E+01	
U	6.0E+02	6.0E+02	
Zn	6.0E+00	1.65E+01	
OH-		0.05M	

Data Sheet 1: Operating Data

Date:

July 16, 1999

Tank Number:

Water Test

Filter:

Second Mattuck 0.1um

Test Conditions:

F = 4.2 gpm test 1 = 10 psig test 2 = 20 psig test 3 = 30 psig

Operator:

D. Reinhart

Test Engineer:

LK Jagoda BKP Bvulis

Test No.	Time	Chiller Temp.	Slurry Temp.	Slurry loop Flowrate	Filter Outlet Pressure	Permeate Pressure	Filter Inlet Pressure	Filtrate Flowrate		Tank Level	Comments
								Volume	Time		
2	13:03		23.5	3 gpm	Not given	2	20				Rotameter = 30
2	13:08						20				Rotameter = 26
2	13:16						18				Rotameter = 24
2	13:23						18				Rotameter = 25
2	13:32			4 gpm		2	20				Rotameter = 27
2	13:49	25.5	26.7			3	20				Rotameter = 27
2	13:57	25.5	24.6	4 gpm		3	20				R = 25
2	14:02	23.8	22.5	4 gpm		3	20				R = 24
2	14:03	23.5	22.1	4 gpm			20				R = 24
1	14:12	23.5	22.7	~4 gpm			10				R = 10
1	14:15	24.0	23.4	~4 gpm			10				R = 10
1	14:19	24.7	24.2	~4 gpm			~9				R = 9
1	14:22	25.4	24.9	~4 gpm			10				R = 10
1	14:26	25.9	25.4	~4 gpm			9.5				R = 10
1	14:30	25.5	24.6	~4 gpm			9.5				R = 9
1	14:32	25.0	23.7	~4 gpm			9.5				R = 9
3	14:40	23.2	22.2	~4 gpm		4	30.0				R = 45
3	14:42	23.9	23.2	~4 gpm		4	30.0				R = 40
3	14:47	25.0	24.5	~4 gpm		3	30.0				R = 39
3	14:53	26.1	25.5	~4 gpm		3	30.0				R = 38
3	15:00	24.3	23.0	~4 gpm		3	30.0				R = 37

118 8/3/99

Task 2.3 & 2.5

29953

p.1 of 5

See

TP-29953-041

Data Sheet 1: Operating Data

Date:

July 23rd 1999

Tank Number:

Water test

Filter:

After AN-107 Clean up

Test Conditions:

Test 2 = 20 pps ~ 4.2 gpm

Operator:

Don Rinehart

Test Engineer:

LK Jagoda

Test 1 = 10 pps ~ 4.2 gpm
All for 20 min minimum

p. 2 of 5

VB 8/3/99

Task 2.3 & 2.5
29953

Test No.	Time	Chiller Temp.	Slurry Temp.	Slurry loop Flowrate	Filter Outlet Pressure	Permeate Pressure	Filter Inlet Pressure	Filtrate Flowrate		Tank Level	Comments
								Volume	Time		
2	3:23	22.2	21.3	4.17	18.0	~2	19.0				R ₁₀ = 32
2	3:33	24.7	24.2	4.21	17.5	~2.5	19.0				R = 32
2	3:40	26.0	25.6	4.21	17.5	~2	19.0				R = ~33
2	3:48	24.7	23.2	4.19	17.0	~2	19.0				R = 32
2	4:00	22.1	21.0	4.17	17.0	~2	19.0				R = 30
2	4:14	25.4	24.9	4.20	18.0	~2	19.0				R = 32
1	5:04	24.1	23.6	4.00	8.0	~2	10.0				R = 14
1	5:08	22.0	20.3	3.98	8.0	~2	10.0				R = 12.5
1	5:11	20.9	19.4	3.99	8.0	~2	10.0				R = 12.0
1	5:16	20.9	19.7	3.98	8.0	~2	10.0				R = 12.0
1	5:20	21.4	20.3	3.98	8.0	~2	10.0				R = 12.5
1	5:24	22.1	21.2	3.99	8.0	~2	10.0				R = 12.5
3	5:31	24.4	24.1	4.02	27.0	5	30.0				R = 50
3	5:43	24.9	23.8	4.2	25.0	4	28.0				R = 45
3	5:46	23.8	22.4	4.1	29.0	4	30.0				R = 49
3	5:56	23.2	22.3	4.07	29.0	4	30.5				R = 50

Data Sheet 1: Operating Data

Date: July 27, 1999
 Tank Number: AV-102 Archive Sr/TRA ppt
 Filter: O-Line Mott-L (2nd)
 Test Conditions: KP Bracks
 Operator: R Lettau
 Test Engineer:

Test No.	Time	Chiller Temp.	Slurry Temp.	Slurry loop Flowrate	Filter Outlet Pressure	Permeate Pressure	Filter Inlet Pressure	Volume	Filtrate Flowrate Time	Flowrate	Tank Level	Comments
1	10:01	29.4	28.4	3.9	51	2	54	40	7.47			Rotameter = 10
1	10:07	25.3	23.8	3.8	52	2	56	40	14.36			Rotameter = 6
1	10:11	23.6	21.9	3.85	52	2	56	30	12.83			Rotameter = 5
1	10:22	25.5	25.1	3.9	51	2	54	30	18.13			Rotameter = 4
1	10:31	25.9	24.7	3.8	51	1	54	30	12.09			Rotameter = 3-4
1	10:49	29.2	27.9	3.8	58	2	51	30	23.32			Rotameter = 2
1	11:02	29	23.9	3.9	53		57	30	28.12			Rotameter = 2
	11:09	Backpulsed twice at 20 psi										
2	11:11	31.4	32.1	4.1	37	1	39.5	30	14.72			Rotameter = 4
2	11:27	21.5	19.6	4.0	37	1	40	30	31.38			Rotameter = 2
2	11:31	21.1	22.1	4.0	37	1	40	30	33.34			Rotameter = 1
2	11:41	26.0	25.3	4.0	36	1	39	30	30.93			
2	11:54	22.3	20.4	4.0	37	1	40.5	20	25.44			
2	12:05	23.0	23.7	4.0	37	1	40	20	25.97			
	12:08	Backpulsed twice at 70 psi										
3	12:14	26.6	24.5	2.9	68	1	70	30	14.56			Rotameter = 4
	12:28	Backpulsed 5 times at 70 psi										
3	12:29	22.6	17.9	2.7	72	1	74	30	16.28			Rotameter = 4
3	12:39	26.9	23.4	3.7	71	1	72	50	34.60			
3	12:52	25.4	22.1	2.9	68	1	70	30	10.25			

Data Sheet 1: Operating Data

Date: July 27, 1999
 Tank Number: AN-1000 Archive Sr. Trm ppt
 Filter: 0.1 um Mott-L (2nd)
 Test Conditions:
 Operator: R Lettman
 Test Engineer: LX Sagnoli

Test No.	Time	Chiller Temp.	Slurry Temp.	Slurry loop Flowrate	Filter Outlet Pressure	Permeate Pressure	Filter Inlet Pressure	Filtrate Flowrate		Tank Level	Comments
								Volume	Time		
3	12:58	23.0	19.6	2.8	67	1	69	30	38.57		
3	1:07	23.2	19.5	2.8	68	1	70	30	42.50		
3	1:17	27.1	23.9	2.8	71	1	73	30	42.54		
3	1:28	28.7	19.0	2.9	103	1	67	30	54.97		21.5 gpm 11.5 gpm 14.5 gpm
4	2:04	27.6	25.9	3.13-316	50	1	58	30	22.03		R=4
4	2:08	27.2	24.5	3.1	51-52	1	55	30	34.63		R=0
4	2:22	21.9	18.2	3.1	67	1	60	30	46.62		re adjusting pressure
4	2:35	25.9	23.5	3.2	53	1	56	30	49.72		
4	2:47	23.7	19.9	3.13	53	1	56	30	58.38		
4	2:59	24.5	21.8	3.11	53	1	55	30	52.71		
4	3:09	26.2	22.9	3.23	52	#1	55	30	56.60		
5	3:30	24.2	21.9	3.3	52	1	55	30	25.13		R=1
5	3:32	"	"	"	"	"	"	30	33.19		R=0
5	3:42	25.8	22.7	3.4	49	1	52	30	44.50		adj back to 55 gpm
5	4:02	21.7	19.5	2.22	55	1	55				R=4.5
5	4:05	"	"	"	"	#1	"	30	39.79		
5	4:15	25.5	23.9	2.24	51	1	53	30	55.22		adj to 55 gpm
5	4:30	22.1	19.5	2.38	53	1	55	30	67.38		adj flow back to 2.25
5	4:42	24.9	23.1	2.25	54	1	56	30	64.62		
5	4:55	24.1	21.0	2.22	53	1	55	30	69.84		

Can't reach target flow!!

Re start - New target - 2.25 gpm @ 55 gpm

Date: July 27, 1999
 Tank Number: AN-1037
 Filter: O. Linn Mott - L (2nd)
 Test Conditions:
 Operator: R. L. Lettau
 Test Engineer: LK Jagade

July 27, 1999

AN-1067 Archive

Q. / um $n_{vit} - L$ (2nd

1-1308	1-1308
--------	--------

B. L. L. L. L.

5.5.5

Test No.	Time	Chiller Temp.	Slurry Temp.	Slurry loop Flowrate	Filter Outlet Pressure	Permeate Pressure	Filter Inlet Pressure	Filtrate Flowrate		Tank Level	Comments
								Volume	Time		
5	5:05	22.1	19.0	2.24	52	1	55	30	75.10		
6	5:23	22.4	25.5	~3.4	53	1	55				R=4
6	5:24	22.4	25.5	~3.4	53	1	55	30	28.47		R=1
6	5:33	26.2	22.4	~3.46	52	1	55	30	45.87		
6	5:43	23.2	18.6	~3.45	53	1	55	30	52.16		
6	5:52	24.4	20.9	~3.5	52	1	55	30	50.25		
6	6:05	25.1	20.9	~3.5	52	1	55	30	54.22		
6	6:19	22.9	18.7	~3.5	52	1	55	30	58.72		
6	6:25	24.5	21.6	~3.5	52	1	55	30	56.31		

7/15/99

Hot Cuff

9:00pm - Blank filter is in
running ~20psig

9:30 0.05 μ filter open (V10 & V2)
~15psig

9:40 Bagged up old
Mott filter to keep cleaner. V22 & V23 valve labels
on old filter -

9:55pm - Shut down

7/16/99

~~8:45~~ 8:45 am Turned on the pump at ~5gpm at 15psig
Running pump thru filter cartridge with blank filter
attached.

Pulled off water sample sent thru filter. (0.2 μ m)
(dead-end filter). w/ 10" Hg on outside vacuum
gauge, filtered very slowly. Drained water - no particulate
seen. Filled up a second time. Again filtered slowly at
first & then stopped. No obvious solids on filter.

Vacuum system was down. Filters quickly and
no obvious solids after 3 times.

9:50 Turned off system. Filtered material from V9
2 times in 150 mL filter. No obvious solids on
filter.

Replaced 0.1 μ m Mott w/ new mott filter

Project No. 99053 Date of Work 7/15 & 7/16/99
Entered By [Signature] Date 7/15/99
Disclosed To and Understood By _____
Signed 1. _____ Date _____
2. _____ Date _____

13:03 $P_{in} = 20$ $T = 23.5$ $P_{out} = 2$ psi

Rotameter = 30

13:08 Rotameter = 26

13:16 Rotameter = 24

13:23 Rotameter = 25 ~ 4 gpm $P_{in} = 18$

13:32 Rotameter = ~~25~~ 27 $P_{out} = 2$ $P_{in} = 18$

$T = 26.7^{\circ}\text{C}$

2:06 pm - Finish test 2 (20 psig ~ 4.28 gpm)
for 20 min.

Over all Ran 1 hr with very little
drop in flux!!

Back pulsed 5 times.

2:10 Starting test #1 (10 psig ~ 4.28 gpm)

2:33 finished test #1

Back pulsing 5 times ~

2:37 Starting test #3 (30 psig ~ 4.28 gpm)

3:00 pm finished test #3 - in 20 min dropped from 45 = R

37 = R

3:20 Hard to tighten - valve - done -

Project No.

29983

Date of Work

7/16/99

Entered By

Date

7/16/99

Disclosed To and Understood By

Signed 1.

Date

2.

Date

~ 4:30 pm AN-107 Shaken and poured into CUF

~4:45 Started system

Can't get pressure above 12 psig even with V1 mostly closed.
Identified 2 problems

* Problem with V1 opening & closing - to refight it.

* Building Air is low 60 psig max

5:20 - Played with V1 until bar can reach 70 psig on system.

5:26 Turn system to setup condition one
F = 4.2 gpm
P = 55 psig

5:28 open V4

T = 0 R = 10

T = 0:49 R = 0
(49 sec)

Switch to glass flowmeter
Close V6

10 ml = 35 sec

20 ml = 1:20

30 ml = 3:09

closed V4 = collected sample CUF AAN/107-0 (filtrate)
* Attempted to backpulse / mostly with Air - couldn't fill backpulse chamber

Project No. 29953

Date of Work

7/14/91

Entered By

Date

7/16/91

Disclosed To and Understood By

Signed 1.

Date

2.

Date

7/16/99

Set conditions to 4.2 gpm @ 70 psi
#1/4 open 5 ml / 51 seconds
V4 closed

Drained system - recovered almost all
volume, lost 119.56 g.

[Probably left much of that lost weight
in the filter as clogging solids]

8:05 H₂O: 2M NaOH has been pumping around
about 1 hr. - Tried to back pulse -
little success - going to add H₂O from
top & try again.

2 back pulses from the top -
flux is much better!!!

Refilling and back pulsing normally -
2 more back pulses -
opened V4 - R=10 - Washed out Rotameter
& glass flow meter for ~30 sec

closed V4 - Back pulsing 6 more times

8:30 Draining

9:00 Back pushed in through top 5 times -
added another ~.5 L

9:12 running -

9:30 Draining

9:35 refilling - (3 from top - back pulse)

9:40 running - 9:50 draining

9:55 Refilling to leave for week

Project No. 79983 Date of Work 7/16/99
Entered By [Signature] Date 7/16/99
Disclosed To and Understood By [Signature]
Signed 1. [Signature] Date 7/16/99

12/17

12:40

AM. System up & running -

Visual inspection pre-start up showed water
visually clear, after running ~ 15 min
still clear.

Plan - take pH - hook up .05 μ filter to
remove any remaining solids

1:20

pH ~ 8.0

1:40

Drained - ^{partially} and put ~ 1.5 liter of fresh H_2O
into tank

1:55

Running through 0.05 μ filter
 ~ 25 psig ~ 5.7 gpm

2:05

Backed off flowrate to ~ 5.2 gpm -

2:05

Chiller on $T \sim 38^\circ C$ when turned on

2:08

$\longrightarrow T$ dropped quickly to $< 30^\circ C$

2:15

pulsed flowrate 4 times (trying to make sure that
solids are knocked out of
fittings)

2:48

pulsed flowrate 5 times

3:04

valve closed (aous m off)

3:06

Conditions set to 20 psig ~ 4.8 gpm

3:12

$T = 0$
 $T = 5$
 $T = 13$
 $T = 20$

$R = 30$
 $R = 30$
 $R = 30$
 $R = 32$

$T = 30$
 $T = 40$
 $T = 50$
 $T = 61$

$R = 33$
 $R = 31$
 $R = 30$
 $R = 32$

Project No. 29983

Date of Work

7/23/99

Entered By

Date

7/23/99

Disclosed To and Understood By

Signed 1.

Date

2.

Date

AN-107 Hot CUFF Clean-up & Water testing

7/23/99

4:20 Back pulsed 4 times -

4:20 New Conditions - Test #1 -
~4.0 gpm & 10 psig.

$T=0$ $R=12$

4:25 Rubber hose from glass flowmeter came off -
Stopped System

4:45 Fixed glass flowmeter connector -
added ~1.0 L DI H₂O

5:00 am Set conditions to 10 psig ~4.0 gpm

$T=0$ $R=14$

$T=5$ $R=12.5$

$T=14$ $R=12.0$

$T=20$ $R=12.5$

5:25 Finished - Back pulsing 3 times

New Conditions 4.2 gpm ; 30 psig

$T=0$ $R=45$

dropped p to 27 psig -
adjusted to 30

$T=1$ $R=50$

* Water level too low for flow rate - turning 1.9
to foam - R dropped to <30
Added 1 max Liter (top of site glass on tank)

~~$T=12$~~ Clean it up - R went back to 45
 $T=14$ $R=45$ 47 P=27-28

add pressure back to 30 $R=49$

$T=20$ $R=49$

$T=25$ $R=50$

Project No. 29953

Date of Work

7/23/99

Entered By

Date

7/23/99

Disclosed To and Understood By

Data from H₂O test
Record on tape CUFF-2
(Kip full @ ~5945 am)

clean

7/26/99

HB

Compared 18" TC to Thermometer temp at ~ 40-50°C as a check of the calibration. All measurements were within 0.3°C of each other in a stirred beaker of water.

18" TC = 54.0°C

18" TC = 54°C

Thermometer = 53.5°C

Thermometer = 53.7°C

6" TC = 53.8°C

Tare wts using Mettler AT400

384-06-Q-004

7/26/99

Sr/TRU ppt 75 mL (full) 184.3352 g

1M NaMnO₄ 50 mL (full) 112.1823 g

TCIX-01 16.8953 g

TCIX-02 17.0301 g

Mn-21 17.0031 g

Mn-22 16.9183 g

Mn-23 16.8969 g

Mn-24 16.9147 g

1 liter
tainer

From AN-107 Archive - 2 samples removed ~ 20 mL

TCIX-01 43.654 g - full weight } (using cell PM 400-cal
 MN-21 41.325 g - full weight } 43.650 g (recheck on 7/27/99)
 41.319 g (recheck 7/27/99)

13:39 Began adding Sr(NO₃)₂ Solution to AN-107.

T = 34.1°C

Some of the Sr solution is lost due to difficulty pouring
 out of the container (a few drops)

13:45 Finished the addition of the Sr solution.

Stirred for 10 minutes after Sr Addition complete
 Turned stirrer off to video-

13:57 Turned off video time stamp

14:04 Turned stirrer back on

Project No. 29953 Date of Work 7/26/99
 Entered By HB Date 7/26/99
 Disclosed To and Understood By _____
 Signed 1. _____ Date _____
 2. _____ Date _____

Sr/TRU ppt
14:13 Add NaMnO_4 Solution

$T = 33.6^\circ\text{C}$

Bottles are spilling significantly - they are hard to pour. Possibly ~2 mL lost to side of container.

14:17 Addition is complete

14:19 Turned off stirrer. The stir plate has quite a lot of purple MnO_4^- .

14:29 Turned on heat $T = 38^\circ\text{C}$

14:52 Reached 50°C

15:37 $T = 53.2$

16:50 - took video of container

18:55 - heater off.

* Note over last 3 hrs $T = 50.4 \rightarrow 51.8^\circ\text{C}$

@ lowest setting on hot plate temperature ~~not~~ climbs very slowly. About every 30 min ~~that~~ (as temp approached 52°C) the hot plate was turned off (stirrer left on) for ~10 min until the temp dropped back to almost 50°C

19:21 $T = 48.2$

19:29 $T = 47.4$ Scanner T.C. DAS off -
Still mixing well. -

- Removing T.C. so lid sits tighter to reduce evaporation.

1/27/99

$T = 35.4^\circ\text{C}$ Put T.C. back in

8:18 Took short video

8:20 Turned off stirrer to allow settling. Took external filter off.

8:55 Took 2 samples from top of reaction vessel
 Te IX-02 & Mn-22 .

9:02 Weighed containers

Project No.

29953

Date of Work

7/27/99

Entered By

Date

7/26/99

Disclosed To and Understood By

1 - 10:00 am started system

7B

10:06 am took sample Mn-23 Filtrate

10:30 am took sample Mn-24 Filtrate - #1

Weights of full samples

Tc IX-7	41.345 g
Mn-22	40.943 g
Mn-23	31.553 g
Mn-24	30.440 g

2 - 11:10 am started new condition

11:40 am took sample Mn-25 Filtrate # 2

Mn-25 32.508 g (Full sample wt)

12:55 Mn-26 Filtrate # 3 31.399 g (Full sample wt.)

1:28

For the last 30-40 min the pump has been making a throbbing sound, the pressure has fluctuated with the pump pulses. It has also been drifting up to 75 & down to 67. Ralph has adjusted it several times.

* Tare wts taken in cell for Bottle Mn-27-30

Mn-27	= 16.903
Mn-28	= 17.098
Mn-29	= 16.950
Mn-30	= 16.961

Test condition 3 ended @ 1:29 - Backpulsing 5 times (from V10)

1:50 pm - Taking 2 slurry samples

Sample Mn-27 = 28.845 (sample + slurry) (Bottle)

* After dumping first pull back into tank there was some residue in the vial which became part of sample.

Slurry #1

Project No.	29953	Date of Work	7/27/99
Entered By	J. Brooks	Date	7/27/99
Disclosed To and Understood By			
Signed 1.		Date	
2.		Date	

AN-107 Archive testing

Sample Mn-28 = 28.708 g (Sample + Slurry)
↳ Slurry #2

14:01
(2:01 pm)

Starting test 4 - 55 psig 3.15 - 3.16 gpm

~14:30 Flushed sampling system

14:50 Took filtrate sample = Mn-29 = 27.037 g (Sample + Slurry)
↳ Filtrate #4

15:11 Finished Condition 4

Back pulsing 4 times

15:30 Starting Condition 5 testing - Max flow 3.3 - 3.4 gpm
target 5.23 gpm / 55 psig 55 psig.

Air pressure is too low to achieve high flow rates @
Having building Air chiller.

16:01 - Re starting Condition 5 with a new target of
2.25 gpm @ 55 psig.

Back pulsed 3 times before start

Putting in two more sample bottles

Mn 31 - tar = 16.8608

Mn 32 - tar = 16.9707

4:44

Sample Mn-30 = 33.347 g (Sample bottle & slurry)
↳ Filtrate #5

4:50:08

Finish Condition 5 - Back pulsing 3 times

5:23

Start Condition 6 - ~ 3.5 gpm / 55 psig

Sample Mn-31 - ~~tar~~ 27.244 g (sample bottle & slurry)
↳ Filtrate #6

6:25

Finished Condition 6

Project No. 2995-3

Date of Work

Entered By

Date

Disclosed To and Understood By

7/27/99

7/27/99

~~7:05pm~~ Drained - 850 ml of AN-107 Archive Recovered

7:30 Added 1 L .2 M NaOH Pumped around ~15 min.
While pumping allowed to go through filtrate
System ~ 5 min - open and closed V6 3 times
to rinse glass flow meter (filled to top & overflow)
Then Back pulsed 3 times.

7:53 Draining - Collecting into bottle labeled 1st Rinse ^{AN-107}

8:14 Refilled with 1.5 L H₂O, Running @ 50 psi
~ 4.5 gpm - trying to rinse tank walls
with the ^{same} spatter that dirtied them,
_{filter}

8:25 Drained -

Refilled with 2 L DI H₂O - Ran 15 min.
9:05pm Shut down

8/99 8:00am Turned on CWF at 30 psi & 4.5 gpm

8:30 am Backpulsed & drained

8:49 am Added liquid w/ tube to backpulse chamber
Performed 5 times

9:50 am Added 1.5 L DI water into system
and ran around for a while at 30 psi & 5 gpm
Rinsed filtrate sample line & upper loop

10:30 Drained -

Project No. 29953

Date of Work 7/27/99

Entered By [Signature]

Date 7/27/99

Discussed To and Understood By

Signed 1. [Signature]

Date

2. _____

Date

AN-107 Archive - Composite prep.

7/28/99

Preparation of Composite Mn-32 (tare 16.9g)

total wt sample only

of indiv.
Δ wt. =

11:31am	tared	—	0.00 g		
	After ~2 ml	Mn-24	2.377 g	total	2.377 g
	After ~2 ml	Mn-25	4.789 g	total	2.412 g
	After ~2 ml	Mn-26	6.518 7.192 g	total	2.403 g
	After ~2 ml	Mn-29	9.543 g	total	2.351 g
	After ~2 ml	Mn-30	12.076 g	total	2.533 g
	After ~2 ml	Mn-31	14.418 g	total	2.342 g
				check ✓	14.418 g

Total wt. Bottle plus composite sample = 31.386g

~2:30 Transferred samples out to go to SAL for analysis

Samples transferred -	TCTx - 01	Mn-32	Mn 23
	TCTx - 02	Mn 21	Mn 28
	Mn - 31	Mn 22	Mn 27

2:45 Refilled with ~1.5 L H₂O -
Ran ~30 min

3:20 Brushed down sides - water now foamy & brown again

3:40 Took pH - ≈ 7.5 or less - i.e. Can attach filter now.

4:00 Shut down until tomorrow

Project No.

29953

Date of Work

7/28/99

Entered By

Date

7/28/99

Disclosed To and Understood By

Signed 1.

Date

199

1:50 am - up and running to remix, any re suspend, solids in system.

10:19 Hooked up & running 0.05m filter system, 25 psig; ~4.8 gpm - Very Foamy & Cloudy

10:55 back pulsing with Clean H₂O from the top. (Twice)

12:00 Cleaned until 12:00 still a little cloudy

1:45 Continued to clean until 1:45 - Crystal clear visually - V2 & V10 closed.

1:55 - Testing ~ 20 psig / 4.2 gpm
T=0 R=20-21
T=8.5 R=17

2:05 V4 off - Back pulsing 10 times

2:29 Cleaning again - V2 & V10 open to 0.05m filter

2:50 Pulsed flow 6-7 times to create turbulence/different flow patterns.

3:15 - Partially drained (put filter die hose into waste container) Refilled with 2 L all added from the top as Clean H₂O back pulsed.

3:45 - Running again - H₂O brownish & cloudy.

4:23 - building air down - pump shut off

20953

7/29/99

Project No. _____ Date of Work _____

Entered By [Signature] Date 7/29/99

Disclosed To and Understood By _____ Date _____

Signed 1. _____ Date _____

AN-107 cleanup

7/31/99

7:50

System up & running - U2 & V10 open i.e. filtering through 0.05 μ filter,

8:55

looks clear visually - U2 & V10 closed -

Set conditions to 20 psig ~ 4.2 gpm
Open V4 - rc adjust to 20 / 4.2 gpm

T = 0	R = 22.5
T = 6	R = 20
T = 10	R = 20
T = 14	R = 20
T = 17	R = 18
T = 20	R = 17.5

9:23 - Testing shows system is still not clean -
Going to add acid.

9:24 - Back pulsing ~~5~~^(five) times then draining

9:41 - Back pulsed 3 times Fresh H₂O from top

10:17 looks clean - doing a complete drain

10:39 Pouring Acid in - through top. (1 L 12M HNO₃ 0.2 M extra

11:25 running acid - 25 psig - 4.1 gpm (pulsed a few times)

12:46 - Run of acid finished - very foamy -

12:48 Draining - Acid greenish now ~~AD~~

1:25 Refilled Clean H₂O - running (30 psig ~ 4.5 gpm)
Open V4 3 times - R page @ 60+ / gpm fills fast.
Back pulse 5 times

Project No.

Date of Work

Entered By

Date

Discussed To and Understood By

7/30/99

7/30/99

~~12:13~~ 1:34 Draining.

1:40 * Note - Leak detected in the
Back pulse chamber near @ bottom of
Site glass.

2:00 Refilled and running @ 30 psi ~4.

2:13 Stopped/Draining

2:20 Refilled - Ran -

2:45 Drained
pH = ~3-3.5

2:55 Refilled Running pH = 3.5 - 4.0

3:20 Dumped -

3:30 Refilled

3:46 pH = 4.5 !!

Shutting down -

Project No.

Date of Work

Entered By

Date

Disclosed To and Understood By

Signed 1.

Date

2.

Date

29953



7/30/99

7/30/99

Appendix B: Test Instruction-063 and Log Book Entries

Sr/TRU Removal from Archived AN-107 with Minimal Reagent Addition

Log Book Entries

PNNL Test Instruction		Document No.: BNFL-TI-29953-063 Rev. No.: 0
Title: Sr/TRU Removal from Archived AN-107 (previously treated by Cs IX) with Minimal Reagent Addition		
Work Location: RPL SFO HLRF	Page 1 of 8	
Author: Richard T. Hallen	Effective Date: Upon Final Approval Supercedes Date: New	
Use Category Identification: Information		
Identified Hazards: <input type="checkbox"/> Radiological <input type="checkbox"/> Hazardous Materials <input type="checkbox"/> Physical Hazards <input type="checkbox"/> Hazardous Environment <input type="checkbox"/> Other:	Required Reviewers: <input checked="" type="checkbox"/> Technical Reviewer <input type="checkbox"/> SFO Manager	
Are One-Time Modifications Allowed to this Test Instruction? <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No NOTE: If Yes, then modifications are not anticipated to impact safety. For documentation requirements of a modification see SBMS or the controlling Project QA Plan as appropriate.		
On-The Job Training Required? <input type="checkbox"/> Yes or <input checked="" type="checkbox"/> No FOR REVISIONS: Is retraining to this procedure required? <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No Does the OJT package associated with this procedure require revision to reflect procedure changes? <input type="checkbox"/> Yes <input type="checkbox"/> No <input checked="" type="checkbox"/> N/A		
Approval	Signature	Date
Author		10/25/89
Technical Reviewer		10/25/89

Controlled Document

1.0 Applicability

This test instruction is to be used to perform studies on permanganate treatment for Sr/TRU removal from archived AN-107 waste that has been previously treated by cesium ion exchange resin and prepare addition treated waste for sulfate removal studies. The precipitation will be conducted in SAL and solids removed by deadend filtration. Approximately 1-L of AN-107 waste (use C3E4 first then C3E5, and/or C3E6) will be used.

2.0 Supporting Documents

This test instruction is a stand-alone document. Background information on permanganate treatment can be found in PNNL Test Plan BNFL-TP-29953-013, which contains an overall description of the project, ES&H compliance, emergency response, and the hazards assessment and mitigation. Past scoping tests on the permanganate treatment of AN-107(cesium removed) are described in detail in test instructions, TI-29953-037, -040, -041, and -043.

3.0 Responsible Staff

The staff responsible for executing this test plan are as follows.

- Task Manager – Dean Kurath
- SFO Manager – Rick Steele
- Test Scientists/Engineers – Kriston Brooks and Rich Hallen
- Hot Cell Technician – Vaughn Hoopes
- Radiological Control Technician

4.0 Materials, Equipment, Supplies and Reagents Needed

4.1 Materials Required

- ✓1. Four 20 mL glass scintillation vials for samples, pre-labeled on top and side as follows: MR-01 - MR-04.
- ✓2. One 250 mL filtrate Storage Bottle.
- ✓3. 1-L size disposable filtration unit, 0.45 um filter.
- ✓4. 150-mL disposable filtration unit, 0.45 um filter.
- ✓5. One 150 mL breaker or bottle for transferring and weighing the Archived AN-107
✓250 mL Plastic Bottle T= 14.7621

4.2 Equipment

- ✓1. 160 gram balance (largest available in SAL)
- ✓2. Calculator
- ✓3. 2-L erlenmeyer flask
- ✓4. hot-stir plate
- 5. Thermometer or thermocouple/reader
- ✓6. big stir bar
- ✓7. watch
- ✓8. Catch pan to use as secondary containment.

4.3 Reagents Needed

- ✓1. 48 mL of 19M (50 wt %) NaOH
- ✓2. 57 mL of 1.0M Sr(NO₃)₂
- ✓3. 34.2 mL of 1.0M NaMnO₄
- ✓4. 1 liter of Archive AN-107 - #4

AN107-C3E-4
AN107-C3E-5

4.4 Other Supplies

- ✓1. Control Copy of this Test Instruction
- ✓2. Laboratory Record Book (record LRB# 13733)

5.0 Test Instructions for Permanganate Treatment

The laboratory record book (LRB) shall be used to record other testing information as required by this procedure and all test conditions not stated by this procedure.

Cross-contamination between samples and contamination of samples from outside sources must be minimized at each step. Use new supplies and bottles for each sample as much as possible.

Keep all test materials in sealed containers as much as possible to prevent them from drying.

5.1 Pre-start

5.1.1 Inventory materials, equipment, supplies, and reagents to ensure all required items are available. Assure that all materials have been modified for remote handling. (The large Erlenmeyer flask will need to be banded so the waste can be poured out. The 1-liter filter flask is large and hard to handle in the cell, band the flask.)

5.1.2 Do the following and initial and date when completed.

ALG 10/26/89 Review the work instructions in this TI.

5.1.3 Record the weights of all the materials/supplies before they are transferred into the hot cell.

	ID#	Empty	Full
Sample vials	MR-01	<u>16.8154</u> g	<u>42.9240</u> g
	MR-02	<u>16.8161</u> g	<u>41.7626</u> g
	MR-03	<u>17.0376</u> g	<u>43.9384</u> g
	MR-04	<u>16.8920</u> g	<u> </u> g
Stir Bar		<u>38.4447</u> g	
Erlenmeyer Flask			<u>736</u> g
Large			
Filter unit receiver		<u>571</u> g	<u>15.2208</u> g
Filter unit		<u>85.4563</u> g	<u>18.8515</u> g

41.9686g

Small
Tare
Filter unit receiver 39.4161 g cap 11.1947 g
Filter unit 30.8118 g lid 8.3338 g

Filtrate storage bottle 587 g w/id

5.2 Start-Up

5.2.1 Obtain the following information:

M&TE List:

Balance 1:

Calib ID 360-06-01-016 Calib Exp Date 2/00
Location SAL Cell #2

Thermocouple or Thermometer:

Calib ID TC-325-415 Calib Exp Date 8-00 1-2001
Location Cell 3 Type K

5.2.2 Record the identification number on the bottle of archived AN-107 (verify/identify sample is AN-107 id#).

Bottle Label(s) AN-107-C3E-4
AN-107-C3E-5

5.3 Sr/TRU Removal by Permanganate Treatment

5.3.1 Setup the ppt reaction equipment as specified. The precipitation is to be conducted in a 2L flask. Secondary containment should be used to allow recovery from a possible breach of the 2 L flask. Place stir bar in flask.

Add 1000 mL of archived AN-107 to the Erlenmeyer Flask. Because the balance will only measure 160 grams, 10 transfers should be completed, each with approximately 100 mL of waste.

	Add ~100mL	After Waste Pour in Flask	
Tare weight bottle			
<u>14.7621</u> g	<u>138.8350</u> g	<u>14.9370</u> g	transfer 1 = <u>123.8980</u> g
now add another 100 mL	<u>132.3573</u> g	<u>14.9057</u> g	transfer 2 = <u>117.4516</u> g
now add another 100 mL	<u>125.9800</u> g	<u>15.0023</u> g	transfer 3 = <u>110.9777</u> g
now add another 100 mL	<u>129.9138</u> g	<u>14.9302</u> g	transfer 4 = <u>114.9336</u> g
now add another 100 mL	<u>131.0341</u> g	<u>15.0090</u> g	transfer 5 = <u>116.0251</u> g
now add another 100 mL	<u>123.1172</u> g	<u>14.9664</u> g	transfer 6 = <u>108.1508</u> g
now add another 100 mL	<u>131.3619</u> g	<u>15.0333</u> g	transfer 7 = <u>116.3289</u> g
now add another 100 mL	<u>129.4123</u> g	<u>14.9678</u> g	transfer 8 = <u>114.8445</u> g
now add another 100 mL	<u>137.0690</u> g	<u>14.9162</u> g	transfer 9 = <u>122.1528</u> g
now add another 100 mL	<u>131.0906</u> g	<u>15.0100</u> g	transfer 10 = <u>116.0806</u> g
			Total = <u>1,160.8936</u> g

*on the 8th addition more sample was added to the cup before weighing so an avg. of the other nine wts was used.

Density = _____ g/mL Total volume = Total mass/density = _____ mL

Turn on stirrer. Turn on the temperature recording device. Record temperatures of cell and waste. Cell Temperature 25°C Waste Temperature 31.5°C (@ 8:30am

Remove 50 mL of waste for sampling/filter below - record weight removed
5.3.2 While continuously stirring the waste, personnel are to slowly (over a 2 minute period) add 48 mL of 19M (50 wt %) NaOH. This is the entire content of the bottle labeled 19M NaOH.

Full
Tare bottle of 19M NaOH 98.0334 (wt outside of cell) 6:53 Added
Tare Empty bottle 25.7361 Over 3 minutes
Weight Added 72.2973 g

5.3.3 While continuously stirring the waste, personnel are to slowly (over a 5 minute period) add 57 mL of 1.0 M $\text{Sr}(\text{NO}_3)_2$. This is the entire content of the bottle labeled 1M Sr.

Full
Tare bottle of 1M Sr 91.3135 (wt outside of cell) 7:12 - 7:18 am
Tare Empty bottle 22.2641 Added Sr
Weight Added 69.0494 g

5.3.4 While stirring, slowly (over a 5 minute period) add 34.2 mL of 1 M NaMnO_4 . This is the entire content of the bottle labeled 1M NaMnO_4

Tare bottle of 1M NaMnO_4 97.2778 (wt outside of cell) 7:27 start
Tare Empty bottle 57.9487 7:33 complete
Weight Added 39.3291 g

5.3.5 Allow the waste to thoroughly mix after addition of all of the reagents, i.e. stir for 30 minutes.

Began heating 8:22 am

5.3.6 Heat the waste mixture at $50 \pm 5^\circ\text{C}$ with stirring for 4 hours. Record temperature.

Started 4 hrs 8:33 am - 45°C collect above-50mL
While the waste is digesting for 4 hours, transfer 20-mL of waste from the original bottle to vial MR-01 and record the weight of sample. This sample will be the unfiltered control, and is to be digested with acid as is for analytical. Duplicate samples need to be digested and submitted for analyses. Then filter approximately 30 mL of the original waste with 0.45 μm filter. Use the filtrate to determine the density of the Archived AN-107 in duplicate using volumetric flasks (use 10 mL ball flask)

Tare flask 14.2162 ①
Flask plus 10 mL of waste 26.8939
Weight of 10 mL of waste 12.6777

density of waste 1.268 g/mL

Tare flask 9.3917 ②
Flask plus 10 mL of waste 22.0781

16.8154 g

Weight of 10 mL of waste 12.6784 density of waste 1.268 g/mL

Transfer 20 mL of the filtrate to vial MR-02 and record the weight. This sample is the filtered control. Sample in duplicate, acid digest, and submit for analyses.

12:41 pm - stirrer and heater off
5.3.7 After 4 hours of digesting, turn off the stirrer and allow the waste to cool to $25 \pm 5^\circ\text{C}$. If possible, use a video recorder to document the settling behavior of the waste mixture. Record the volume of settled solids if possible. mL See video - maybe 100 mL clear super.

5.4 Solids Removal with the Deadend Filter Unit

5.4.1 Tare the 1-L receiver bottle/lid and filter assembly/lid of the filtration unit (preferably before it is sent into the cell). Make sure receiver bottle is banded for remote handling.

Tare of receiver bottle and lid 586 g See section 5.1 this instruction.
Tare of the filter assembly 104.2324 and lid
with lid

5.4.2 Assemble 1-L filtration unit and filter all of treated waste in the erlenmeyer flask. Some solids should have settled on cooling/setting. Decant most of the supernate from the flask to the filter. The supernate should filter faster without all of the solids/cake on the filter unit. When approximately half the material has been filtered, swirl the bottle to suspend the solids. Continue filtering the slurry. If excessive solids remain in the bottom of the bottle, small amounts of filtrate can be used to rinse the solids from the bottle. Record weight of empty flask if possible. Filter the solids until compacted on filter and no free liquid remains. Disassemble filter unit and weigh. If necessary to get filtrate to Sandy Fiskum by COB Wednesday, stop filtration and transfer 250 mL of waste to a tared, 250 mL storage bottle.

Done last
Tare of receiver bottle/lid and filtrate 1438.4 g ~700 mL
Tare of the filter assembly/lid and wet solids 199.5 g Weight of filtrate 587 g tare = 851.4
Tare = 104.2324 g Weight of wet solids 95.2176 g + 587 g = 56.7729 g Stir bar

5.4.3 Transfer 20-mL of filtrate from the filter flask to vial MR-03. Determine the density of the filtrate in duplicate using volumetric flasks (use at least 10 mL ball flask, prefer 25 mL.)

Tare flask 19.90815 (3)
Flask plus 25 mL of filtrate 51.3483
Weight of 25 mL filtrate 31.4403 density of filtrate 1.2576 g/mL

Tare flask 20.3640 (4)
Flask plus 25 mL of filtrate 51.0622
Weight of 25 mL filtrate 31.4982 density of filtrate 1.2599 g/mL

Transfer the remaining treated, archived AN-107 filtrate to the sample storage bottle. Collect the solids on the filter and save for future work.

Tare of 250 mL bottle - w/lid = 229.54
w/lid = 214.95

5.5 Experimental Clean Up and Sample Disposition.

Clean up all of the equipment used.

Do not discard any samples without written instructions from the task manager. Duplicate samples were collected at all sampling points. The duplicates are to be retained until review of the analytical data is completed and notification in writing is received to dispose of these samples.

6.0 Sample Analysis

The point of contact for the sample analysis is Mike Urie and Rick Steele.

Prepare and submit all samples in duplicate. Analyze all samples for the following: Am/Eu by GEA, Sr-90 analysis, Tc-99 beta scintillation without oxidation, and Na by ICP-AES (report all detected analytes).

Table 1. Samples and Their Required Analyses

Process Variable	Vial ID	Sample Type	Sample Preparation	Analysis Description ^(a)
Archived AN-107	MR-01	as received	acid digest	Am/Eu/Sr/Tc, Na
Archived AN-107	MN-02	as received	0.45 um filter, acid digest	Am/Eu/Sr/Tc, Na
Treated AN-107	MN-03	filtrate	acid digest	Am/Eu/Sr/Tc, Na

(a) Descriptions of analyses are contained in Table 2.

Table 2. Description of Analyses

Constituent	Analysis Method	PNNL Procedure No.
Americium-241, Eu isotopes	GEA	PNL-ALO-450
Strontium-90 (Yttrium-90)	Separations and Beta Counting	PNL-ALO-476/431
Tc-99	Beta Counting without chemical oxidation	
Metal Ions (see Table 5 list)	ICP-AES	PNL-ALO-211/280

Table 3. Analytical Requirements for Supernate/Filtrate

Analyte	Supernate/Filtrate Minimum Reportable Quantity microCi/gm	Analysis Method
Americium-241	1E-03	GEA
Europium-154	1E-03	GEA
Europium-155	1E-03	GEA
Strontium-90	1E-01	Chemical Separation & Beta Count
Technetium-99	1E-02	Beta Scintillation without sample oxidation
	microgm/gm	
Al	NR	Acid Digestion followed by ICP-AES
Ba	NR	
Ca	NR	
Cd	NR	
Co	NR	
Cr	NR	
Cu	NR	
Eu	NR	
Fe	NR	
K	NR	
La	NR	
Mg	NR	
Mn	NR	
Mo	NR	
Na	2.3E+05	
Ni	NR	
Pb	NR	
Si	NR	
Sr	NR	
Ti	NR	
U	NR	
Zn	NR	

NR no minimum reportable quantity but report data for all analytes detected

Treatment of Archived AN-107 with minimal reagent additi double per Mike Johnson

to 500 ml of waste 19M NaOH 0.024 Liter or 0.912 moles

1M Sr 0.0285 Liter or 0.057 moles

1M MnO₄ 0.0171 Liter or 0.0342 moles

Balance number: 380-06-01-013

Calibration date: 2/90

Makeup 50 % NaOH solution ~19 M

use NaOH pellets

40 grams/mole (FW) (lot # 01012EG) ALS reagent - 97+010

Tare 50 mL bottle 24.8879 grams

add 36.48 grams NaOH bottle + NaOH 61.4279 grams

add 36.48 g water 97.9663 grams

actual weight of NaOH added _____ grams

actual weight of water added _____ grams

Label bottle with ID, 50% NaOH total weight 98.0319 gram

48 mL

Makeup Sr(NO₃)₂ solution

use Sr(NO₃)₂

211.63 grams/mole (FW) (lot #

Tare 100 mL bottle 21.9174 grams

add 12.0629 grams Sr(NO₃)₂ bottle + Sr(NO₃)₂ 33.9904 grams

add 57 g of water 91.3185 grams

actual weight of Sr(NO₃)₂ added _____ grams

actual weight of water added _____ grams

Label bottle with ID, 1M Sr(NO₃)₂ 57 mL 91.3191 gram

Makeup NaMnO₄ solution

use NaMnO₄.H₂O

159.94 grams/mole (FW) (lot #

Tare 100 mL bottle 57.6883 grams

add 5.46995 grams NaMnO₄ bottle + NaMnO₄ 63.1533 grams

add 34.217.1 g of wat 97.2223 grams

actual weight of KMnO₄ added _____ grams

actual weight of water added _____ grams

Date prepared: 10/25/99

Prepared by: Richard A. Hall

Work Package Number: W53400

1M NaMnO₄ 97.2792 g

34.2 mL

COPY



RECEIVED

OCT 25 1999

EUGENE V. MORREY

River Protection Project
Waste Treatment Plant

3000 George Washington Way
Richland, WA 99352
Tel: (509) 371-3500
Fax: (509) 371-3504

Mr. Eugene Morrey
Pacific Northwest National Laboratory
P.O. Box 999, MSIN P7-28
Richland, Washington 99352

Direct tel: 509-376-1982
Direct fax: 509-376-7127

CCN #: 007525

CC: *Kristen Brooks*

Rich Hallen

Don Kurath

Dave Blanchard

Sandra Fiskum

OCT 21 1999

Dear Eugene:

Contract No. DE-AC06-96RL13308 - W375 - PREPARATION OF ADDITIONAL
ARCHIVED AN-107 SOLUTION FOR SULFATE SEPARATION TESTS

References:

1. Document, BNFL-TI-29953-061, revision 0, "Sulfate Removal Studies from AN107 Archived Waste," Battelle Pacific Northwest Division, Richland, Washington, dated October 18, 1999.
2. CCN# 004960, M. E. Johnson, BNFL Inc. to E. V. Morrey, Battelle, "Conditions for Precipitation of Sr/TRU in Archived 241-AN-107 Sample," Battelle, dated July 28, 1999.

This letter specifies conditions for conducting Sr/TRU precipitation with ~500-ml of archived AN-107 solution that has previously been treated to separate cesium using crystalline silico-titanate. BNFL Inc. is requesting Battelle prepare the pretreated archived AN-107 solution for use in additional sulfate removal tests.

Battelle is conducting tests with the archived AN-107 solution to evaluate methods for separating sulfate from Envelope C waste solutions (ref. 1). The archived AN-107 solution had previously been processed through a column that contained crystalline silico-titanate to separate cesium. Battelle used a small portion of the archived AN-107 solution to demonstrate Sr/TRU separation using sodium permanganate and strontium nitrate. Battelle then used all available pretreated, archived AN-107 solution for sulfate separation tests. Battelle needs to conduct the Sr/TRU precipitate process with additional archived AN-107 solution.

Battelle personnel conducted Sr/TRU precipitation and filtration tests with the archived AN-107 solution using the following test conditions.

➤ Starting Conditions for the archived AN-107 solution

• Na:	5.68M	Density:	1.256 gm/ml
• Volume:	881.9 ml		
• Am-241:	0.174 μ Ci/gm	Co-60:	0.0616 μ Ci/gm
• Eu-154:	0.232 μ Ci/gm	Eu-155:	0.166 μ Ci/gm


- Sr-90: 38.5 $\mu\text{Ci/gm}$
- Reagents Concentrations and Conditions
 - Free hydroxide (calculated) was 0.8M,
 - Final NaMnO_4 molarity was 0.05M,
 - Final $\text{Sr}(\text{NO}_3)_2$ molarity was 0.075M
 - Heat mixture to 50°C for 4-hours, then cool and filter
- Final Conditions for the archived AN-107 solution before filtration
 - Na: 4.83M Density: 1.226 gm/ml
 - Volume: 1014.53 ml Dilution factor: 1.1247 (mass basis)
 - Am-241: 0.00485 $\mu\text{Ci/gm}$ Co-60: 0.0545 $\mu\text{Ci/gm}$
 - Eu-154: 0.0135 $\mu\text{Ci/gm}$ Eu-155: 0.0097 $\mu\text{Ci/gm}$
 - Sr-90: 1.52 $\mu\text{Ci/gm}$

BNFL Inc. has selected Sr/TRU precipitation conditions different than those originally specified for the archived AN-107 sample in order to reduce the amounts of manganese hydroxide and strontium carbonate added to the high-level waste.

BNFL Inc. requests Battelle personnel to react ~500-ml of archived AN-107 solution with sodium hydroxide, 1M sodium permanganate, and 1M strontium nitrate solutions to achieve final added concentrations of ~0.8M OH (calculated), 0.03M ($\pm 5\%$) MnO_4 , and 0.05M ($\pm 5\%$) Sr. Battelle personnel are to constantly mix the slurry, heat the slurry to 50°C for 4-hours, then cool and dead-end filter using a 0.45- μm filter. Battelle personnel are to sample and analyze the archived AN-107 supernate before and after reagent additions to determine the supernate density, concentrations of Na, Sr-90, Am-241, Eu-154, Eu-155, and Tc-99 by beta scintillation without sample oxidation. The minimum reportable quantities for Na, Sr-90, Am-241, Eu-154, Eu-155, and Tc-99 are 2.3E+05 $\mu\text{gm/gm}$, 0.1 $\mu\text{Ci/gm}$, 1E-03 $\mu\text{Ci/gm}$, 1E-03 $\mu\text{Ci/gm}$, 1E-03 $\mu\text{Ci/gm}$, and 0.01 $\mu\text{Ci/gm}$, respectively.

Battelle should accumulate costs for this activity as part of the sulfate removal task authorized by Mr. Bill Roberson to Ms. Whelan on October 14, 1999. A final charge control package should be submitted to BNFL Inc. for all sulfate removal tasks in November 1999.

Yours sincerely,



Michael E. Johnson
Pretreatment Technical Manager

MEJ/ctf

cc:

Fittro, C.T. w/o	BNFL Inc.	A212
Slaathaug, E. w/o	BNFL Inc.	E213
Johnson, M.E. w/o	BNFL Inc.	B268
PDC w/o	BNFL Inc.	K110

T1-063

BNU-13733
Page 65

65

reagent prep for T1-063

Preparation of Archived AN-107 with minimal reagent addition double per Mike Johnson

1000 ml of waste 19M NaOH	0.024 Liter	or	0.912 moles
1M Sr	0.0285 Liter	or	0.057 moles
1M MnO ₄	0.0171 Liter	or	0.0342 moles

Balance number: 380-06-01-013
Calibration date: 2/90

Takeup 50 % NaOH solution ~19 M
use NaOH pellets

40 grams/mole (FW) (lot # 01012EG) ALS reagent - 97+010
are 50 mL bottle 24.8879 grams
add 36.48 grams NaOH bottle + NaOH 61.4279 grams
add 36.48 g water 97.9663 grams
actual weight of NaOH added _____ grams
actual weight of water added _____ grams
label bottle with ID, 50% NaOH total weight 98.0319 gram
48 mL

Takeup Sr(NO₃)₂ solution
use Sr(NO₃)₂

211.63 grams/mole (FW) (lot # 21.9174) grams
are 100 mL bottle 33.9904 grams
add 12.0629 grams Sr(NO₃)₂ bottle + Sr(NO₃)₂ 91.3185 grams
add 57 g of water _____ grams
actual weight of Sr(NO₃)₂ added _____ grams
actual weight of water added _____ grams
label bottle with ID, 1M Sr(NO₃)₂ 57 mL 91.3191 gram

Takeup NaMnO₄ solution
use NaMnO₄.H₂O

159.94 grams/mole (FW) (lot # 57.6883) grams
are 100 mL bottle 63.1533 grams
add 5.46995 grams NaMnO₄ bottle + NaMnO₄ 97.2792 g
add 34.217.1 g of water 34.2 mL
actual weight of KMnO₄ added _____ grams
actual weight of water added _____ grams
Date prepared: 10/25/99
Prepared by: Richard A. Hall
Work Package Number: W53400

Project No. _____ Date of Work _____
Entered By Richard A. Hall Date 10/25/99
Disclosed To and Understood By _____
Signed 1 _____

for use
11-063

10/27/99

Added 1 l of solution Archive AN-107 to 1000 ml flask.
Capped & stored overnight (last night)
Calibrated balance w/ weights in cell

Weight of Cal Wt	Weight Measured
100g	100.0g
1000g	999.9g
5000g	4999.7g

waste added 1160.8936 grams
- 66.9736
1093.9200 grams

Weight of flask 2062.5g (w/ rubber stopper)
Beaker (empty) 14.8559g (before use)

Weight Beaker (empty) 14.8518g (after use)
Weight 50ml bottle 15.0987g (empty)
Weight 50ml bottle 81.9825g (full) } 66.9736 gram removed

Weight of flask 1995.4g (w/ rubber stopper) (67.1 grams)

Adding $\text{Sr}(\text{NO}_3)_2$ we see white flecks in black solution increased w/ more Sr addition.

Quite a few flecks after completed. As it stirs, the flecks are getting smaller & the solution is lighter br color.

Added NaMnO_4 . Solution turned dark brown again. White flecks not seen anymore. Solution is milk-chocolate brown.

Weight of flask 2175.1g (w/ rubber stopper)

Began 4 hr heat at 8:33

Sampled initial from the 50ml pulled before any chemical addi:

MR-01 42.9740g

Initial wt = 16.8154g

MR-02

Initial wt = 16.8161g

Project No. _____ Date of Work _____
Entered By HTB Date 10/27/99
Disclosed To and Understood By _____
Signed 1. Richard J. Hahn Date 12/14/99
2. _____ Date _____

2.1
145.4
179.7 required added

12:33 Time for ~~4~~ hr digestion finished.
Temp ranged from 47.5 - 53.4 C over 4 hrs.
12:41 T = 52.0 C Stirrer and Heat off
Finished with 4 hr. digestion.
Camera recording.

1:08 46.4 C = T waste
1:26 T = 44.1
2:00 T = 40.4
2:36 T = 37.3
2:51 T = 36.3
3:22 T = 34.5
4:06 T = 32.7
4:18 T = 32.3

4:30 Filtering - The solution is filtering very well
There is already 700+ ml of filtrate in the
collection bottle. Suspect to add last 1/2 to the
* Stir bar slid into the filter. Will retrieve later.
5:00 Filter cake is mud like.

~ 6:05pm Mostly completed filtration of treated archive AN-107

10/28/99

Filled 250 mL container w/ treated, filtered archive
Measured density of treated, filtered archive AN-107

Filled MR-03 43.9364 g - vial w/ lid

Weighed receiver bottle & filter unit. ~~40~~

Weight of big flask + stopper = 869.3 g

Original tare w/o stopper = 736 g

Stopper = 85.2 g

Project No. _____ Date of Work _____
Entered By D. Brooks Date 10/28/99
Disclosed To and Understood By _____
Signed 1. Richard T. Hall Date 12/14/99
2. _____ Date _____

Appendix C: Analytical Data

Battelle PNNL/325 Bldg/RPG/Inorganic Analysis ...
ICPAES Data Report

Project: # 29953
Client: K. Brooks

John O. Hall
RT HALLEN

Date 9/3/99

Route

File 71-047

Copy

ACL Number(s): 99-2255 through 99-2260

Client ID: "Mn-23" through "Mn-28"

ASR Number: 5457

Total Samples: 6

original

final data report

Procedure: PNL-ALO-211, "Determination of Elements by Inductively Coupled Argon Plasma Atomic Emission Spectrometry" (ICP-AES).

Analyst: DR Sanders

Analysis Date (Filename): 08-04-99 (A0538)

See Chemical Measurement Center 98620: ICP-325-405-1 File for Calibration and Maintenance Records.

M&TE Number: ICPAES instrument -- WB73520
Mettler AT400 Balance -- Ser.No. 360-06-01-029

John Wagner 8-13-99
Reviewed by

MW 8-17-99
Concur

8/13/99

Battelle PNNL/325 Bldg/RPG/Inorganic Analysis ... ICPAES Data Report

Six radioactive aqueous samples, Mn-23 through Mn-28 (ACL# 99-2255 through 99-2260), were analyzed by ICPAES after preparation by the Sample Receiving and Preparation Laboratory (SRPL). Samples were prepared by SRPL using PNL-ALO-128 acid digestion procedure. All samples were prepared using plastic labware. Approximately 5ml aliquots of sample solution were weighed, processed and diluted to a final volume of 20ml. All liquid samples were caustic, salt solutions prior to processing. Sample Mn-28 (ACL# 99-2260) was filtered after being diluted to 20 ml using 0.45 um membrane filter.

All results reported are in $\mu\text{g/g}$ including liquid samples as requested by client. All results have been corrected for preparation and analytical dilution. Volumes and weights are recorded on bench sheets (included with raw data, etc.). Analytes of interest include Al, Ba, Ca, Cd, Co, Cr, Cu, Fe, K, La, Mg, Mn, Mo, Na, Ni, Pb, Si, Ti, U, and Zn. No changes have been made relative to the preliminary report provided earlier to the client.

All quality control checks met tolerance requirements for analytes of interest except as noted below. Following is a list of quality control check measurement results relative to ICPAES analysis tolerance requirements under MCS-033.

Five fold serial dilution:

(Aqueous samples) All results were within tolerance limit of $\leq 10\%$ after correcting for dilution.

Duplicate RPD (Relative Percent Difference):

(Aqueous samples) All analytes of interest were recovered within tolerance limit of $\leq 20\%$ relative percent difference (RPD).

Post-Spiked Samples (Group A):

(Aqueous samples) All analytes of interest were recovered within tolerance of 75% to 125%.

Post-Spiked Samples (Group B):

(Aqueous samples) All analytes of interest were recovered within tolerance of 75% to 125%.

Blank Spike:

(Aqueous samples) All analytes of interest in the blank spike were recovered within tolerance limit of 80% to 120%.

8/13/99

Battelle PNNL/325 Bldg/RPG/Inorganic Analysis ...
ICPAES Data Report

Matrix Spiked Sample:

(Aqueous samples)

All analytes of interest in the matrix-spike were recovered within tolerance limit of 75% to 125% except for Ba and Pb. Matrix-spike recovery for barium in sample Mn-22 (ACL# 99-2259) was only about 5%. Lead recovery in the same sample was about 41%. Low recovery for the two analytes may be caused by moderate to high concentration of sulfate in the sample. Post-spike and blank-spike recovery for all analytes of interest was recovered within tolerance limit of 75% to 125%.

Quality Control Check Standards:

Concentration of all analytes of interest was within tolerance limit of $\pm 10\%$ accuracy in the standards: QC_MCVA and QC_MCVB. Calibration Blank (ICP98.0) concentration was less than two times IDL.

High Calibration Standard Check:

Verification of the high-end calibration accuracy for all analytes of interest except lanthanum and uranium was within $\pm 5\%$ tolerance. The high-end calibration accuracy for lanthanum was somewhat low, about -6.9% and uranium was also low by about -5.7% . This will cause results for lanthanum and uranium concentration to appear lower than what is actually present in the samples. Lanthanum and uranium concentration measurements were all below EQL (and below MRQ).

Process Blank:

(Aqueous samples)

All analytes of interest were within tolerance limit of \leq EQL or $< 5\%$ of sample concentration.

Laboratory Control Standard (LCS):

(Aqueous samples)

No LCS was prepared for PNL-ALO-128 acid digested samples.

Analytes other than those requested by the client are for information only. Please note bracketed values listed in the data report are within ten times instrument detection limit and have a potential uncertainty much greater than 15%. See attached ICPAES data results.

8/13/99

**Battelle PNNL/325 Bldg/RPG/Inorganic Analysis ...
ICPAES Data Report**

Comments:

- 1) "Final Results" have been corrected for all laboratory dilution performed on the sample during processing and analysis unless specifically noted.
- 2) Detection limits (DL) shown are for acidified water. Detection limits for other matrices may be determined if requested.
- 3) Routine precision and bias is typically $\pm 15\%$ or better for samples in dilute, acidified water (e.g. 2% v/v HNO₃ or less) at analyte concentrations greater than ten times detection limit up to the upper calibration level. This also presumes that the total dissolved solids concentration in the sample is less than 5000 $\mu\text{g/mL}$ (0.5 per cent by weight).
- 4) Absolute precision, bias and detection limits may be determined on each sample if required by the client.
- 5) The maximum number of significant figures for all ICP measurements is 2.

8/13/99

Multiplier=	3.2	16.3	16.4	16.3	15.9
ALO#	99-2255-PB @1	99-2255 @5	99-2256 @5	99-2257 @5	99-2258 @5
Client ID=	Process Blank	Mn-23	Mn-31	Mn-32	Mn-21
Run Date=	8/4/99	8/4/99	8/4/99	8/4/99	8/4/99
Det. Limit (ug/mL)	(Analyte)	ug/g	ug/g	ug/g	ug/g
0.015	Ag	—	—	—	—
0.060	Al	—	119	105	133
0.080	As	—	—	—	—
0.050	B	—	13.8	16.4	18.5
0.010	Ba	—	[0.33]	—	[1.3]
0.010	Be	—	—	—	—
0.100	Bi	—	—	—	—
0.100	Ca	—	130	129	227
0.015	Cd	—	23.2	22.6	27.0
0.100	Ce	—	—	—	[9.7]
0.025	Co	—	[1.8]	[1.8]	[2.0]
0.020	Cr	—	35.7	36.9	58.6
0.015	Cu	[0.13]	11.5	14.1	12.8
0.050	Dy	—	—	—	—
0.100	Eu	—	—	—	—
0.025	Fe	[0.13]	8.00	7.56	445
2.000	K	—	604	584	665
0.025	La	—	[0.77]	[0.71]	9.46
0.005	Li	—	[0.34]	[0.26]	[0.25]
0.100	Mg	—	—	—	—
0.005	Mn	—	1.13	[0.48]	[0.50]
0.030	Mo	—	13.2	12.9	15.0
0.100	Na	[0.75]	84,600	84,200	86,200
0.100	Nd	—	[2.6]	[2.9]	29.0
0.030	Ni	—	189	184	217
0.100	P	—	166	162	184
0.060	Pb	—	69.5	66.9	67.4
0.300	Pd	—	—	—	[4.9]
0.300	Rh	—	—	—	[4.8]
0.075	Ru	—	13.0	12.5	12.7
0.050	Sb	—	—	—	—
0.050	Se	—	[1.0]	[0.94]	[1.0]
0.100	Si	—	38.2	43.8	34.4
1.000	Sn	—	—	—	—
0.005	Sr	—	115	171	159
0.500	Te	—	—	—	—
0.800	Th	—	—	—	—
0.005	Ti	—	—	—	0.943
0.250	Tl	—	—	—	—
2.000	U	—	[40]	[38]	[41]
0.015	V	—	—	—	—
0.500	W	—	[60]	[59]	[59]
0.010	Y	—	[0.44]	[0.59]	[0.56]
0.020	Zn	[0.18]	5.19	5.48	5.39
0.025	Zr	—	[1.1]	[1.2]	[0.94]

Note: 1) Overall error greater than 10-times detection limit is estimated to be within +/- 15%.
2) Values in brackets [] are within 10-times detection limit with errors likely to exceed 15%.
3) "--" indicate measurement is below detection. Sample detection limit may be found by multiplying "det. limit" (far left column) by "multiplier" (top of each column).

Det. Limit (ug/mL)	Multiplier= ALO#= Client ID= Run Date= (Analyte)	16.3 99-2259 @5 Mn-22 8/4/99 ug/g	16.3 99-2259-DUP @5 Mn-22 8/4/99 ug/g	80.5 99-2260 @25 Mn-28 8/4/99 ug/g			
0.015	Ag	—	—	—	—	—	—
0.060	Al	105	107	121	—	—	—
0.080	As	—	—	—	—	—	—
0.050	B	13.1	13.4	[15]	—	—	—
0.010	Ba	—	—	[1.9]	—	—	—
0.010	Be	—	—	—	—	—	—
0.100	Bi	—	—	—	—	—	—
0.100	Ca	126	130	220	—	—	—
0.015	Cd	22.8	23.4	22.6	—	—	—
0.100	Ce	—	—	[15]	—	—	—
0.025	Co	[1.7]	[1.8]	—	—	—	—
0.020	Cr	34.4	35.2	64.2	—	—	—
0.015	Cu	11.1	11.3	12.1	—	—	—
0.050	Dy	—	—	—	—	—	—
0.100	Eu	—	—	—	—	—	—
0.025	Fe	4.32	4.40	687	—	—	—
2.000	K	597	614	[600]	—	—	—
0.025	La	[0.63]	[0.67]	[11]	—	—	—
0.005	Li	[0.21]	[0.23]	[0.60]	—	—	—
0.100	Mg	—	—	—	—	—	—
0.005	Mn	3.73	3.84	2,810	—	—	—
0.030	Mo	12.8	13.3	[12]	—	—	—
0.100	Na	90,700	85,100	85,200	—	—	—
0.100	Nd	[1.9]	[2.0]	[38]	—	—	—
0.030	Ni	185	191	188	—	—	—
0.100	P	162	165	138	—	—	—
0.060	Pb	67.2	69.1	140	—	—	—
0.300	Pd	—	—	—	—	—	—
0.300	Rh	—	—	—	—	—	—
0.075	Ru	12.6	13.0	[13]	—	—	—
0.050	Sb	—	—	—	—	—	—
0.050	Se	[0.86]	[1.00]	[4.6]	—	—	—
0.100	Si	29.5	30.4	[44]	—	—	—
1.000	Sn	—	—	—	—	—	—
0.005	Sr	110	114	4,770	—	—	—
0.500	Te	—	—	—	—	—	—
0.800	Th	—	—	—	—	—	—
0.005	Ti	—	—	[1.3]	—	—	—
0.250	Tl	—	—	—	—	—	—
2.000	U	[38]	[39]	—	—	—	—
0.015	V	—	—	—	—	—	—
0.500	W	[59]	[60]	[47]	—	—	—
0.010	Y	[0.32]	[0.31]	[3.6]	—	—	—
0.020	Zn	5.29	5.74	[8.4]	—	—	—
0.025	Zr	[0.83]	[0.72]	—	—	—	—

Note: 1) Overall error greater than 10-times detection limit is estimated to be within +/- 15%.
 2) Values in brackets [] are within 10-times detection limit with errors likely to exceed 15%.
 3) "—" indicate measurement is below detection. Sample detection limit may be found by multiplying "det. limit" (far left column) by "multiplier" (top of each column).

ASR #

5457

File: L:\radchem\hydroxide\asr5457

WP#

W51304

Analysis Date: 8/3/99
Print Date: 8/4/99

Hydroxide and Alkalinity Determination

Governing Procedures: PNL-ALO-228: Determination of Hydroxyl (OH-) and
Alkalinity of Aqueous Solutions, Leachates and Supernates
and Operation of Brinkman 636 Auto-Titrator

Equip # WB76843

Lab Loc. 525

Analyst: *RT HALL* 8/4/99

Reviewer: *RT HALL* 8/4/99

Titrant	Molarity
HCl	0.2034

Std. & Spike	Molarity
NaOH	0.1018

RPG #	Sample ID	Sample Vol. (mL)	Sample Wt. (g)	Density g/mL	Titrator Routine #	Initial pH reading	OH			Found millimoles base	Molarity base	millimole RPD
							1st Equivalence Point	Titrant Vol. (mL)	pH			
99-2258	Mn-21	0.100	0.1271	1.271	1	11.558	0.423	0.086	10.624	0.086	0.86	
99-2258	Mn-21	Replicate	0.2547	1.274	2	11.759	0.855	0.174	10.750	0.174	0.87	1.06%
99-2259	Mn-22	0.200	0.2485	1.243	3	11.702	0.723	0.147	10.67	0.147	0.74	
99-2259	Mn-22	Replicate	0.2494	1.247	4	11.707	0.724	0.147	10.699	0.147	0.74	0.14%
QC Data:												
Reag. Blk.		5.00			1	6.143						
Standard 1	0.1018 N NaOH	5.000	5.0036	1.001	2	12.026	2.492	0.5069	7.918	0.5069	99.6%	Std 1
Standard 2	0.1018 N NaOH	5.000	5.0196	1.004	3	11.89	2.486	0.5057	7.578	0.5057	99.3%	Std 2
99-2258MS	Mn-21 + 2mL 0.1N NaOH	0.100	0.1256	1.256	5	11.846	1.338	0.272	10.611	0.272	91.2%	MS
99-2259MS	Mn-22 + 2mL 0.1N NaOH	0.100	0.1229	1.229	6	11.702	1.292	0.263	10.640	0.263	92.9%	MS

OH % Recovery, Acc

Performance checks

Buffer	VWR Lot #	CMS#	Expire Date
10	981659-24	144109	Jul-00
4	981583-24	144107	Jun-00
7	981894-24	144108	Aug-00

Balance #	360--01-06-037	Vol.	Wt.
Pipet #	H30762	5.00	4.944
Pipet #	2734494	0.500	0.496
Pipet #	120737	0.100	0.1013
Pipet #	120737	0.200	0.1997

RT HALL
Date 8/12/99
Route
File T1-041
Copy Original

Chem Rec_51a

Prep date: 4/18/99

Preparation of Standardized 0.2 M HClWP# K51300

Standardized 0.1021 M NaOH will be re-checked and then used to standardized the ~ 0.1 M HCl solution. The 0.1021 M NaOH was prepared in Chem Rec_37 (see Chem Rec_37 --prep.date 2-25-98 for original data) and re-verified against NIST SRM84j Potassium Acid Phthalate KHC₈H₄O₄ (KAP) = 204.23 g/mole -- Barcode # 52232 --- (see below verification check).

The re-standardized value of 0.1018 M NaOH was reassigned to this NaOH solution with a revised Expiration Date of Feb. 2000.

Prepared 1- liters of ~0.2 M HCl by diluting 100 mL of 1.029M HCl (Chemrec_10) to 0.5 L with DI. H₂O.


20 mL aliquots of 0.2 M HCl were were neutralized to the phenophthalien endpoint using the re-standardized 0.1018 M NaOH. The volume of NaOH is accurate to +/- 0.02mL and the pipitting error is estimated to be < 1% @ 1s. Thus total error is < 3 % for the measurements

NaOH Molarity veification

Verification Test #	Wt. of KAP	Vol. of 0.1021M NaOH to neutralize	NaOH Molarity =a * 1000 / b * 204.23	Molarity Error +/- @ 1 s
1	0.80894	38.95	0.1017	
2	0.80582	38.84	0.1016	
3	0.96233	46.12	0.1022	
Ave=			0.1018	0.0003
			re-certified value	

Titration Id.	aliquot of sample	Vol. of 0.1018M NaOH to neutralize	Molarity of Acid in Sample	Molarity Error +/- @ 1 s
1	20.00	39.88	0.2030	
2	20.00	39.92	0.2032	
3	20.00	40.04	0.2038	
Ave Molarity HCl =			0.2034	0.00042

Analyst/Date

 8/4/99

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Radioanalytical Applications Team

99-2255
8/6/99

Client : Brooks

Cognizant Scientist:

Concur :

Date :

Date :

Sr-90 (PNL-ALO-476, 431)

Gamma (PNL-ALO-450)

Measured Activities (uCi/ml)

ALO ID Client ID	Co-60 Error %	Eu-152 Error %	Cs-137 Error %	Eu-154 Error %	Sb-125 Error %	SnSb-126 Error %	Eu-155 Error %	Am-241 Error %
99-2255PB Process Blank	<2.E-5	<4.E-5	<2.E-5	<4.E-5	<3.E-5	<1.E-5	<5.E-5	<9.E-5
99-2255 Mn-23	6.21E-2 2%	<2.E-3	6.52E-2 2%	2.20E-2 2%	<9.E-4	4.31E-4 22%	1.65E-2 3%	9.48E-3 8%
99-2256 Mn-31	6.02E-2 2%	<2.E-3	4.03E-2 2%	2.95E-2 2%	1.12E-3 25%	3.89E-4 16%	2.15E-2 3%	9.77E-3 8%
99-2257 Mn-32	6.22E-2 2%	<2.E-3	4.45E-2 2%	2.86E-2 2%	<9.E-4	2.69E-4 17%	2.11E-2 3%	1.09E-2 7%
99-2258 Mn-21	7.74E-2 2%	5.02E-3 8%	2.83E-2 2%	2.91E-1 2%	<2.E-3	<6.E-4	2.08E-1 3%	2.19E-1 5%
99-2259 Mn-22	6.68E-2 2%	<2.E-3	2.31E-2 2%	1.65E-2 2%	<8.E-4	3.89E-4 16%	1.19E-2 4%	5.56E-3 15%
99-2259 Dup 1 Mn-22	6.68E-2 2%	<2.E-3	2.34E-2 2%	1.73E-2 2%	<8.E-4	3.86E-4 18%	1.19E-2 4%	7.27E-3 15%
RPD	0%		1%	5%		1%	0%	27%
99-2259 Dup 2 Mn-22	6.55E-2 2%	<2.E-3	2.20E-2 2%	1.64E-2 2%	<8.E-4	2.87E-4 21%	1.21E-2 5%	5.04E-3 17%
99-2260 Mn-28	6.38E-2 2%	6.14E-3 9%	3.05E-2 3%	3.59E-1 1%	<2.E-3	<6.E-4	2.59E-1 3%	2.63E-1 11%

RT HALL

Date 8/12/99

Route

File T1-041

Copy original

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Radioanalytical Applications Team

99-2255
8/6/99

Client : Brooks

Cognizant Scientist:

Concur :

L. Heenan

C. Sciergiew

Date :

8-6-99

Date :

8-6-99

Sr-90 (PNL-ALO-476, 431)
Gamma (PNL-ALO-450)

Measured Activities (uCi/g)

ALO ID Client ID	Co-60 Error %	Eu-152 Error %	Cs-137 Error %	Eu-154 Error %	Sb-125 Error %	SnSb-126 Error %	Eu-155 Error %	Am-241 Error %
99-2255PB Process Blank	<2.E-5	<4.E-5	<2.E-5	<4.E-5	<3.E-5	<1.E-5	<5.E-5	<9.E-5
99-2255 Mn-23	5.09E-2 2%	1.64E-3	5.34E-2 2%	1.80E-2 2%	7.37E-4	3.53E-4 22%	1.35E-2 3%	7.77E-3 8%
99-2256 Mn-31	4.94E-2 2%	1.64E-3	3.30E-2 2%	2.42E-2 2%	9.18E-4 25%	3.19E-4 16%	1.76E-2 3%	8.01E-3 8%
99-2257 Mn-32	5.09E-2 2%	1.64E-3	3.64E-2 2%	2.34E-2 2%	7.37E-4	2.20E-4 17%	1.73E-2 3%	8.92E-3 7%
99-2258 Mn-21	6.16E-2 2%	4.00E-3 8%	2.25E-2 2%	2.32E-1 2%	1.59E-3	4.78E-4	1.66E-1 3%	1.74E-1 5%
99-2259 Mn-22	5.45E-2 2%	1.63E-3	1.88E-2 2%	1.35E-2 2%	6.52E-4	3.17E-4 16%	9.70E-3 4%	4.53E-3 15%
99-2259 Dup 1 Mn-22	5.44E-2 2%	1.63E-3	1.91E-2 2%	1.41E-2 2%	6.52E-4	3.15E-4 18%	9.70E-3 4%	5.92E-3 15%
RPD	0%		1%	5%		1%	0%	27%
99-2259 Dup 2 Mn-22	5.33E-2 2%	1.63E-3	1.79E-2 2%	1.34E-2 2%	6.51E-4	2.34E-4 21%	9.85E-3 5%	4.10E-3 17%
99-2260 Mn-28	5.15E-2 2%	4.95E-3 9%	2.46E-2 3%	2.90E-1 1%	1.61E-3	4.84E-4	2.09E-1 3%	2.12E-1 11%

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Radioanalytical Applications Team

99-2255
8/6/99

Client : Brooks

Cognizant Scientist:

C. Soderquist

Date :

8-6-99

Concur :

L. R. Greenwood

Date :

8-6-99

Sr-90 (PNL-ALO-476, 431)

Gamma (PNL-ALO-450)

ALO ID Client ID	Sr-90 $\mu\text{Ci/mL}$ $\pm 1s$	Sample Density, g per mL	Sr-90 $\mu\text{Ci/g}$ $\pm 1s$
99-2255PB Process Blank	<5.E-3	1	<5.E-3
99-2255 Mn-23	1.96E+0 $\pm 4\%$	1.221	1.61E+0 $\pm 4\%$
99-2255DUP Mn-23	2.22E+0 $\pm 4\%$	1.221	1.82E+0 $\pm 4\%$
RPD	12%		
99-2256 Mn-31	1.99E+0 $\pm 4\%$	1.220	1.63E+0 $\pm 4\%$
99-2257 Mn-32	2.22E+0 $\pm 4\%$	1.221	1.82E+0 $\pm 4\%$
99-2258 Mn-21	4.84E+1 $\pm 4\%$	1.256	3.85E+1 $\pm 4\%$
99-2259 Mn-22	1.87E+0 $\pm 3\%$	1.228	1.52E+0 $\pm 3\%$
99-2260 Mn-28	3.31E+1 $\pm 3\%$	1.240	2.67E+1 $\pm 3\%$
Matrix Spike	88%		
Reagent Spike	102%		
Blank	<5.E-3		

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Radioanalytical Applications Team

99-2255
8/6/99

Client : Brooks

Cognizant Scientist:

C. Sedeghi

Date :

8-6-99

Concur :

J. Greenwood

Date :

8/6/99

Sr-90 (PNL-ALO-476, 431)

Gamma (PNL-ALO-450)

ALO ID Client ID	Densities of Samples				
	Gross	Tare	Net	Volume	Density
99-2255 Mn-23	14.1799 g	8.0603 g	6.1196 g	5.01 mL	1.221 g/mL
99-2256 Mn-31	14.3510 g	8.2358 g	6.1152 g	5.01 mL	1.220 g/mL
99-2257 Mn-32	14.1705 g	8.0474 g	6.1231 g	5.01 mL	1.221 g/mL
99-2258 Mn-21	14.4554 g	8.1599 g	6.2955 g	5.01 mL	1.256 g/mL
99-2259 Mn-22	14.2015 g	8.0536 g	6.1479 g	5.01 mL	1.226 g/mL
99-2259 Dup 1 Mn-22	14.3323 g	8.1806 g	6.1517 g	5.01 mL	1.227 g/mL
99-2259 Dup 2 Mn-22	14.2551 g	8.0797 g	6.1754 g	5.01 mL	1.232 g/mL
			Average, n = 3		1.228 g/mL
			±		0.2%
99-2260 Mn-28	14.3292 g	8.1147 g	6.2145 g	5.01 mL	1.240 g/mL

Volume is known to ± 0.2%, 1s.

Analytical Chemistry Laboratory (ACL) Analytical Services Request (ASR)
(Cover Page ... information applicable to all samples in series)

Requested By: Kristen Brooks Signature 9/5/99 6-2233 K6-24
Print Name Signature/Date Phone MSIN

Requester - Please Complete All Fields In This Section. Unless Specified "Optional" or ASR is a Revision

Request ID (optional): _____ Matrix: Samples vary (specify on Request Page). or
PNL Project Number (if known): 2-9953 Liquid: ☒ Aqueous ☐ Organic ☐ Multi-phasic
Work Order/Pkg.: W53400 Solid: ☐ Soil ☐ Sludge ☐ Sediment ☐ Glass
Cost Estimate (\$): _____ ☐ Filter ☐ Smear ☐ Metal ☐ Organic ☐ Other Solids
Protocol Requirement: ☒ None ☐ RCRA ☐ CERCLA, or
Other (specify): _____ Solid/Liquid Mixture: ☐ Gas: ☐
Hold Time Requirement: ☒ None ☐ RCRA ☐ CERCLA, or
Other (specify): _____ Biological: ☐ Tissue ☐ Urine ☐ Feces
TPA Support: X No, or
Milestone No.: _____ Process Knowledge: ☐ Sample Information Check List,
or Reference Doc.: _____
PCBs Present: ☒ No ☐ Yes
Sample Disposition ...
Untreated Sample(s): ☐ Return ☒ Dispose ☐ Store, or
Reference Doc.: _____
Prep'd Sample(s): ☒ Dispose ☐ Return ☐ Store, or
Reference Doc.: _____
Additional Instructions: ☐ No, or
Reference Doc.: _____
ACL COC Req'd (PNL-ALO-010): ☒ No ☐ Yes
Date Report Req'd: 12-1-99
Sample Storage Requirements: ☒ No ☐ Refrigerate, or
Send Report to: Rich Hallen
Other (specify): _____
Date Sampled (optional): _____ MSIN: K2-12 Phone: 375-6919
Time Sampled (optional): _____ Fax (optional): 372-4732

For ACL Use Only ... Do Not Complete This Section

Date Delivered: 11/1/99 ACL Numbers: _____
Time Delivered (optional): _____
Deliv. By (if known): Mike Mann
Received By: FU Hoopes
Resp. ACL Mgr.: _____
Signature/Date: _____
Job Group (optional): _____
Sample Group (optional): _____
PNL Impact Level: ☐ 1 ☐ 2 ☐ 3
DQ Review Req'd: ☒ No ☐ Yes ACL Waste: ☒ No ☐ Yes
ASR Number: _____ Revision: ☐ Yes

[illegible]

**Battelle PNNL/325 Bldg/RPG/Inorganic Analysis ...
ICPAES Data Report**

Project: 29953
Client: K.P. Brooks

ACL Number(s): 00-0292 through 00-0294

Client ID: "MR-01" through "MR-03"

ASR Number: 5570

Total Samples: 3

Procedure: PNL-ALO-211, "Determination of Elements by Inductively Coupled Argon Plasma Atomic Emission Spectrometry" (ICP-AES).

Analyst: D.R. Sanders

Analysis Date (Filename): 11-12-99 (A0552)

See Chemical Measurement Center 98620: ICP-325-405-1 File for Calibration and Maintenance Records.

M&TE Number: ICPAES instrument -- WB73520
Mettler AT400 Balance -- Ser.No. 360-06-01-029

Jerry Wagner 1-17-00
Reviewed by

MW Hie 1-18-00
Concur

1/17/00

Battelle PNNL/325 Bldg/RPG/Inorganic Analysis ...
ICPAES Data Report

Three radioactive aqueous samples, MR-01 through MR-03 (ACL# 00-0292 through 00-0294) were analyzed by ICPAES after samples were processed by the Shielded Analytical Laboratory (SAL). ALO-128 acid digestion procedure was used to process the three samples and a process blank. Approximately 5 to 6 ml sample aliquots were processed and diluted to a corrected final volume of approximately 23 to 24 ml. Sodium was the only analyte requested. Analytical dilutions of 5-fold to 50-fold were necessary due to the high concentration of sodium present in the sample.

Measurement results have been corrected for preparation and analytical dilution. Sample results are reported as $\mu\text{g/g}$ as requested. Weights and volumes used have been recorded on bench sheets and are included with this report. Analytes reported other than sodium are for information only.

Quality control check-standard results for sodium met tolerance requirements except as noted below. Following is a list of quality control measurement results relative to ICPAES analysis tolerance requirements under MCS-033.

Five fold serial dilution:

(Aqueous sample) All results for sodium in the diluted sample is within tolerance limit of $\leq 10\%$ after correcting for dilution.

Duplicate RPD (Relative Percent Difference):

(Aqueous sample) Sodium is recovered within tolerance limit of $\leq 20\%$ relative percent difference (RPD).

Post-Spiked Samples (Group A):

(Aqueous sample) Sodium was recovered within tolerance of 75% to 125%.

Blank Spike:

(Aqueous sample) None.

Matrix Spiked Sample:

(Aqueous sample) None.

Quality Control Check Standards (aqueous sample):

Concentration for Sodium is within tolerance limit of $\pm 10\%$ accuracy for QC_MCVA, ICP98.0 and QC_SSTMCV check standards.

1/17/00

**Battelle PNNL/325 Bldg/RPG/Inorganic Analysis ...
ICPAES Data Report**

High Calibration Standard Check (aqueous sample):

Verification of the high-end calibration concentration for sodium is within tolerance of $\pm 5\%$ accuracy.

Process Blank:

(Aqueous sample)

Sodium was detected in the process blank but at a concentration less than 5% of the concentration measured in any of the samples and is within tolerance limits.

Laboratory Control Standard (LCS):

(Aqueous sample)

None prepared for ALO-128 acid digestion procedure.

Please note bracketed values listed in the data report are within ten times instrument detection limit and have a potential uncertainty much greater than 15%.

Comments:

- 1) "Final Results" have been corrected for all laboratory dilution performed on the sample during processing and analysis unless specifically noted.
- 2) Detection limits (DL) shown are for acidified water. Detection limits for other matrices may be determined if requested.
- 3) Routine precision and bias is typically $\pm 15\%$ or better for samples in dilute, acidified water (e.g. 2% v/v HNO_3 or less) at analyte concentrations greater than ten times detection limit up to the upper calibration level. This also presumes that the total dissolved solids concentration in the sample is less than 5000 $\mu\text{g/mL}$ (0.5 per cent by weight).
- 4) Absolute precision, bias and detection limits may be determined on each sample if required by the client.
- 5) The maximum number of significant figures for all ICP measurements is 2.

1/17/00

Multiplier=		4.8	19.1	19.0	19.1	18.4
ALO#=		00-0292-PB	00-0292 @5	00-0292-DUP @5	00-0293 @5	00-0294 @5
Client ID=		Process Blank	MR-01	MR-01	MR-02	MR-03
Run Date=		11/12/99	11/12/99	11/12/99	11/12/99	11/12/99
Det. Limit	(Analyte)	ug/g	ug/g	ug/g	ug/g	ug/g
(ug/mL)						
0.025	Ag	--	--	--	--	--
0.060	Al	5.54	156	154	141	117
0.250	As	--	--	--	--	--
0.050	B	14.0	18.9	17.4	19.3	18.4
0.010	Ba	--	2.08	2.07	[0.64]	--
0.010	Be	--	--	--	--	--
0.100	Bi	--	--	--	--	--
0.250	Ca	--	248	244	254	144
0.015	Cd	--	29.1	28.9	30.0	25.0
0.200	Ce	--	[15]	[14]	[6.1]	--
0.050	Co	--	[2.1]	[2.1]	[2.2]	[1.9]
0.020	Cr	--	71.8	71.0	50.4	31.8
0.025	Cu	--	13.1	13.0	13.8	11.5
0.050	Dy	--	--	--	--	--
0.100	Eu	--	--	--	--	--
0.025	Fe	[0.27]	690	684	219	11.7
2.000	K	--	724	723	767	659
0.050	La	--	14.1	14.1	12.5	--
0.030	Li	--	--	--	--	--
0.100	Mg	--	--	--	--	--
0.050	Mn	--	139	138	24.6	27.4
0.050	Mo	--	15.7	15.5	16.3	13.7
0.150	Na	26.5	91,500	93,900	96,000	104,000
0.100	Nd	--	42.4	42.1	31.8	[2.9]
0.030	Ni	[0.27]	235	233	241	203
0.100	P	--	201	197	214	182
0.100	Pb	--	165	162	144	81.2
0.750	Pd	--	[22]	[21]	[15]	--
0.300	Rh	--	--	--	--	--
1.100	Ru	--	--	--	--	--
0.500	Sb	--	--	--	--	--
0.250	Se	--	--	--	--	--
0.500	Si	28.0	[23]	[23]	[19]	[35]
1.500	Sn	--	--	--	--	--
0.015	Sr	--	[1.2]	[1.2]	[1.2]	109
1.500	Te	--	--	--	--	--
1.000	Th	--	--	--	--	--
0.025	Ti	--	[2.2]	[2.1]	[0.57]	--
0.500	Tl	--	--	--	--	--
2.000	U	--	[53]	[45]	[53]	[47]
0.050	V	--	--	--	--	--
2.000	W	--	[78]	[78]	[79]	[66]
0.050	Y	--	[3.7]	[3.7]	[3.0]	--
0.050	Zn	--	[8.8]	[8.7]	[6.5]	[4.7]
0.050	Zr	--	20.2	16.6	15.4	[2.9]

Note: 1) Overall error greater than 10-times detection limit is estimated to be within +/- 15%.

2) Values in brackets [] are within 10-times detection limit with errors likely to exceed 15%.

3) "--" indicate measurement is below detection. Sample detection limit may be found by multiplying "det. limit" (far left column) by "multiplier" (top of each column).

Corrected copy
11/5/99

SAMPLE PREP SHEET
(325 SHIELDED ANALYTICAL LABORATORY)

TI/ARF NO.: ASR5570 PROJECT NO.: 29553 WBS NO.: SAMPLE TYPE: AQUEOUS
ISSUED BY: RT STEELE DATE: 11/01/99 PREP TYPE: ACID DIGEST (ALO-128)
ANALYST: *[Signature]* DATE: 11-3-99 CHAIN OF CUSTODY RQD: NONE
REVIEW: *[Signature]* DATE: 11-4-99 QA PLAN: SBMS IMPACT LEVEL:
CLIENT: RT HALLEN (K-330000) CORE ID: N/A TANK ID: AN107

WORK PACKAGE NUMBER	ALO NUMBER	SAMPLE IDENTIFICATION	ANALYTE OR ANALYSIS	SAMPLE WT	Sp.G. (g/mL)	WATER WT (g)	TOTAL VOL (mL)	SPIKE ID	SPIKE VOL (mL)	DILUTION FACTOR	DILUTION MATRIX	PIPET CALIB (mL)	MISC
W45525	00-00292-PB	PROCESS BLANK	1,2	4.9827			25.56	23.79					
	00-00292	MR-01	1,2	6.2722			28.63	23.94	145				
	00-00292-DUP	MR-01	1,2	6.1909			28.29	23.48	115/99				
	00-00293	MR-02	1,2	6.2789			28.73	23.98					
	00-00298	MR-03	1,2	6.3154			27.24	23.24					

11-15-99

(1) REQUIRED ANALYSES:
ICP-AES (Na)

(2) REQUIRED ANALYSES:
GEA, Sr-90, Te-99-BY-BETA-COUNTING-WITHOUT-OXIDATION

Corrected Copy

PNL-ALO-128

Nitric and Hydrochloric Acid Extraction of Liquids Using a Dry-Block Heater

Client name: KP Brooks

Work Auth. Doc (WAD): ASR 5570

Tank/Core/Project: Tank AN107

Special instructions

Work package number: W53400

Project number: 29553

PNL QA plan: SBMS

PNL impact level:

Prep. lab (SAL/SRPL/other): SAL

Preparation batch number:

ACL Sample ID	Client sample ID	Gross Weight (g)	Tare Weight (g)	Net Sample Weight (g)	Sample Volume (ml)	Final Soln Gross Wgt (g)	Final Soln 1mL Wgt (g)	Final Volume (ml)
1 00-00292-PB	PROCESS BLANK	33.7110	28.7283	4.9827	4.9938	53.3873	1.0268	25-5623.7
2 00-00292	MR-01	35.1221	28.8499	6.2722		55.6288	1.0832	28-6323.9
3 00-00292-DUP	MR-01	34.7895	28.5986	6.1909		54.3750	1.0873	28-2923.4
4 00-00293	MR-02	35.2657	28.9868	6.2789		55.2368	1.0844	28-7323.9
5 00-00294	MR-03	35.1118	28.7964	6.3154		54.2790	1.0851	27-9423.2
6								
7				Density				1.15/99
8			MR-01	1.256				
9			MR-01000	1.2397				
10			MR-02	1.2573				
11			MR-03	1.2646				
12								
13								
14								

Analyst's sample preparation comments:

Spike source:

1 ml P.P.T. 23°C

PNL spike ID number:

Anal. balance M&TE: 360-06-01-016

4.9714 \bar{x} = 4.9815

4.9862 s = .0077

4.9767 RSO = .15%

4.9822 RSO = 4.9938 ml

4.9908

Sample filtered (yes/no): NO

Other sample preparation worksheets may be substituted at the discretion of the Cognizant Scientist. Use one worksheet per client.

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Radioanalytical Applications Team

00-0292
2/8/00

Client : Brooks

Cognizant Scientist: _____

Date : _____

Concur : _____

Date : _____

Measured Activities (uCi/g)

<u>ALO ID</u> <u>Client ID</u>	<u>Sr-90</u> <u>Error %</u>
00-0292	3.82E+1
MR-01	3%
00-0292DUP	2.87E+1
MR-01	3%
RPD	28%
00-0293	4.01E+1
MR-02	3%
00-0294	9.97E-1
MR-03	3%
Reagent Spike	106%
Blank Spike	99%
Blank	7.69E-3
	3%

RT Hallen
RT HALLEN

Date 2/8/2000

Route _____

File T1-063

Copy record

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Radioanalytical Applications Team

00-0292GEA
2/8/00

Client : Brooks

Cognizant Scientist: _____

Date : _____

Concur : _____

Date : _____

Measured Activities (uCi/g)

ALO ID Client ID	Co-60 Error %	Cs-137 Error %	Eu-154 Error %	Eu-155 Error %	Am-241 Error %
00-0292PB Process Blank	<3.E-5	3.52E-4 6%	<7.E-5	<7.E-5	<9.E-5
00-0292 MR-01	6.04E-2 4%	2.06E-2 13%	2.88E-1 2%	1.93E-1 6%	2.47E-1 11%
00-0292DUP MR-01	6.33E-2 4%	2.53E-2 11%	2.77E-1 2%	1.94E-1 5%	2.72E-1 11%
RPD	5%	20%	4%	1%	10%
00-0293 MR-02	6.27E-2 3%	2.06E-2 8%	1.73E-1 2%	1.21E-1 5%	1.49E-1 11%
00-0294 MR-03	5.16E-2 4%	2.08E-2 10%	2.15E-2 9%	1.51E-2 17%	1.31E-2 25%

RT Hallen
RT HALLEN
Date 2/8/2000
Route _____
File TF-063
Copy Revised

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Radioanalytical Applications Team

00-0292
2/8/00

Client : Brooks

Cognizant Scientist: _____

Date : _____

Concur : _____

Date : _____

Measured Activities (uCi/g)

<u>ALO ID</u> <u>Client ID</u>	<u>Total Beta</u> <u>Error %</u>
00-0292PB Process Blank	1.86E-2 3%
00-0292 MR-01	8.86E+1 3%
00-0292DUP MR-01	8.84E+1 3%
RPD	0%
00-0293 MR-02	8.10E+1 3%
00-0294 MR-03	2.12E+0 3%
Reagent Spike	124%

RT HALLEN

Date

Route

File

Copy

27 Hall
2/8/2000
71-063
Record

Appendix D: Staff and Role/Responsibility

Staff Member	Role/Responsibility
Richard Hallen	Scientist/Technical Leader - Sr/TRU Precipitation
Kriston Brooks	Engineer/CUF System, Entrained Solids Removal, Sr/TRU Precipitation, and Precipitate Removal
Lynette Jagoda	Engineer Associate/CUF System, Entrained Solids Removal, Sr/TRU Precipitation, and Precipitate Removal
Gita Golcar	Scientist/Particle Size Analyses
Don Rinehart	Technician/Hot Cell Tests-Sr/TRU PPT/CUF Operation
Ralph Lettau	Technician/Hot Cell Tests-Sr/TRU PPT/CUF Operation
Dave Ortiz	Technician/Hot Cell CUF Operation and Cleaning
Vaughn Hoopes	Technician/Hot Cell sample prep.
Mac Zumhoff	Technician/Hot Cell Operations

DISTRIBUTION

No. of
Copies

No. of
Copies

OFFSITE

ONSITE

2 DOE/Office of Scientific and Technical
Information

5 British Nuclear Fuels, Limited
M. E. Johnson (4) BN-FL
A. Thompson BN-FL

14 Pacific Northwest National Laboratory
K. P. Brooks K6-24
R. T. Hallen (5) K2-12
L. K. Jagoda K6-24
D. E. Kurath P7-28
E. V. Morrey P7-28
Technical Report Files (5)

