

Inorganic and Radiochemical Analysis of 241-C-104 Tank Waste

S. K. Fiskum
C. J. Barinaga
J. P. Bramson
K. J. Carson
J. R. DesChane
O. T. Farmer
L. R. Greenwood
F. V. Hoopes
R. T. Ratner

D. R. Sanders
M. J. Steele
R. T. Steele
C. Z. Soderquist
R. G. Swoboda
K. K. Thomas
T. L. Trang-Le
M. W. Urie
J. J. Wagner

October 2000

Prepared for CH2M Hill Hanford Group
under Project Number 41503

Inorganic and Radiochemical Analysis of 241-C-104 Tank Waste

S. K. Fiskum
C. J. Barinaga
J. P. Bramson
K. J. Carson
J. R. DesChane
O. T. Farmer
L. R. Greenwood
F. V. Hoopes
R. T. Ratner

D. R. Sanders
M. J. Steele
R. T. Steele
C. Z. Soderquist
R. G. Swoboda
K. K. Thomas
T. L. Trang-Le
M. W. Urie
J. J. Wagner

October 2000

Prepared for
CH2M Hill Hanford Group
under Project Number 41503

Pacific Northwest National Laboratory
Richland, Washington 99352

Summary

Battelle received 2.3 kg of Hanford tank waste material from tank 241-C-104 distributed over 14 sample jars. The contents of all jars were mixed to provide a single composite. The composite was homogenized and representative sub-samples were collected, and then separated into supernatant and wet solids fractions. The individual fractions were analyzed for organic, radiochemical and inorganic composition, as defined in Test Plan BNFL-29953-30, in support of regulatory activities. This report presents the inorganic (including TCLP metals) and radiochemical results. Organic analyte results are reported in WTP-RPT-008 (Draft), Organic Analysis of C-104 Tank Waste.

The characterization analyses of the as received material for C-104 include:

- Inductively-coupled plasma spectrometry for Ag, Al, As, B, Ba, Be, Bi, Ca, Cd, Co, Cr, Cu, Fe, K, Li, Mg, Mn, Mo, Na, Ni, P, Pb, Pd, Rh, Sb, Se, Si, Sn, Tl, U, V, W, Y, Zn, and Zr (although not specified in the test plan Ce, La, Nd, Sr, Th, and Ti were also measured and are reported for information only)
- Radiochemical analyses for total alpha and total beta activity, H-3, C-14, Co-60, Se-79, Sr-90, Nb-94, Ru-106/Rh-106, Sb-125, Sn-126, Cs-134, Cs-137, Eu-154, Eu-155, Pu-238, Pu-239+240, Pu-241, Am-241 (by GEA and AEA), Cm-242, and Cm-243+244 (Pu-236 was also reported for information only)
- Inductively-coupled plasma mass spectrometry for Pr, Pt, Rb, Ta, Tc-99, I-127, I-129, Cs-133, U-233, U-234, U-235, U-236, Np-237, U-238, Pu-239, Pu-240 (total U was also reported for information only)
- Total uranium by kinetic phosphorescence
- Ion chromatography for Br^- , Cl^- , F^- , NO_2^- , NO_3^- , PO_4^{3-} , and SO_4^{2-} (oxalate, $\text{C}_2\text{O}_4^{2-}$, was also measured and reported for information only since oxalate is reported with organic anions as part of the organic analyte report)
- Mercury, cyanide, ammonia, and inorganic, organic, and total carbon
- Free hydroxide and pH determination (supernatant only)
- Flashpoint determination (supernatant only)

Except for a few cases, the characterization results met or exceeded the quality control requirements established by the governing quality assurance plan, and met or exceeded the minimum reportable quantity requirements specified by BNFL. Whenever possible the analyses were performed to SW-846 protocols so that the results can be used to support permit application, as well as to provide feed envelope characterization data.

Terms and Abbreviations

AEA	alpha energy analysis
ALARA	as low as reasonably achievable
ASR	analytical services request
BNFL	BNFL, Inc; subsidiary of British Nuclear Fuels, Ltd.
COC	chain of custody
CVAA	cold vapor atomic absorption
EQL	estimated quantitation level
GEA	gamma energy analysis
HLRF	High Level Radiation Facility
IC	ion chromatography
ICP	inductively coupled plasma/atomic emission spectrometry
ICP/MS	inductively coupled plasma/mass spectrometry
ISE	ion specific electrode
LCS	laboratory control standard
MDL	method detection limit
MRQ	minimum reportable quantity
MSA	method of standard addition
NIST	National Institute of Standards and Technology
%D	percent difference
PB	process blank
QA	quality assurance
QC	quality control
RPD	relative percent difference
RPL	Radiochemical Processing Laboratory
SAL	Shielded Analytical Laboratory
SRM	Standard Reference Material
TC	total carbon
TCLP	toxicity characteristic leaching procedure
TDS	total dissolved solids
TIC	total inorganic carbon
TOC	total organic carbon
W-DOE	Washington State Department of Ecology

Units

°C - °F degrees	Centigrade / degrees Fahrenheit
g	gram
g/mL	gram per milliliter
keV	kiloelectron volts
kPa	kilopascal
µg/g - µg/mL	microgram per gram / microgram per milliliter
µCi/g - µCi/mL	microcurie per gram / microcurie per milliliter
mL	milliliter
mmole/mL	millimole per milliliter
rpm	revolutions per minute
Vol%	volume percent
Wt%	weight percent

Contents

1.0	INTRODUCTION	1.1
2.0	SAMPLE PROCESSING	2.1
2.1	Total Dissolved Solids and Weight Percent Solids	2.1
2.2	Phase Separation	2.1
2.3	Supernatant Density Measurements	2.2
2.4	Initial Preparation of Supernatants and Solids	2.2
3.0	ANALYSIS RESULTS FOR ANALYTES OF INTEREST	3.1
4.0	TCLP METALS ANALYSIS AND EVALUATION	4.1
5.0	QUALITY CONTROL AND DATA EVALUATION	5.1
5.1	Metals Analysis by ICP – Table 3.1	5.1
5.2	Uranium Analysis by Kinetic Phosphorimetry– Table 3.1	5.2
5.3	Radiochemical Analysis –Table 3.2	5.2
5.3.1	Gamma Emitters by Gamma Energy Analysis (GEA)	5.2
5.3.2	Total Alpha and Total Beta.....	5.3
5.3.3	Plutonium, Americium, and Curium	5.3
5.3.4	Strontium-90	5.4
5.3.5	Tritium.....	5.4
5.3.6	Selenium-79	5.4
5.3.7	Carbon-14	5.5
5.4	Analysis by ICP/MS– Tables 3.3 and 3.4.....	5.5
5.5	TOC/TIC Analysis by Hot Persulfate/Coulometry – Table 3.5	5.7
5.6	Anion Analysis by IC – Table 3.5.....	5.8
5.7	Mercury Analysis by CVAA – Table 3.5	5.9
5.8	Ammonia Analysis by ISE – Table 3.5	5.9
5.9	Total Cyanide Analysis by Distillation/Colorimetry – Table 3.5.....	5.9
5.10	Flashpoint Determination – Table 3.5	5.10
5.11	Free Hydroxide and pH Analysis – Table 3.5.....	5.10
6.0	METHOD DETECTION LIMITS & MINIMUM REPORTABLE QUANTITIES	6.1
	APPENDIX A: TEST PLAN AND ASR.....	A.1
	APPENDIX B: ANALYTICAL DATA.....	B.1

Figures

Figure 1.1. Compositing and Sub-sampling for C-104 As-Received Analytical Samples	1.2
Figure 2.1. Flow Diagram for Analytical Preparation of Supernatant and Solids	2.2

Tables

Table 2.1. Slurry Vol% and Wt% Solids, TDS, and Centrifuged Solids Wt% Solids	2.1
Table 2.2. Density Results for C-104 Supernatant Composite	2.2
Table 3.1. C-104 As-Received --- ICP Metals Results	3.2
Table 3.2. C-104 As-Received --- Radiochemical Results	3.3
Table 3.3. C-104 As-Received --- ICP/MS Results	3.4
Table 3.4. C-104 As-Received Cs and U Mass Abundance Ratios	3.5
Table 3.5. C-104 As-Received --- Other Results	3.6
Table 4.1. TCLP Metals Predicted Maximum Concentrations	4.2
Table 5.1. Comparison of ICP/MS to Other Methods for Pu-239+240 and Total U	5.7
Table 6.1. Comparison of Measurement MDLs to Target MRQs	6.2

1.0 Introduction

This report presents the inorganic and radiochemical analytical results for Hanford waste tank 241-C-104 (C-104) as-received materials. The analyses were conducted in support of the BNFL Proposal No. 30406/29274 Task 5.0. The inorganic and radiochemical analysis results obtained from the as-received materials are used to provide initial characterization information for subsequent process testing and to provide data to support permit application activities. The governing Quality Assurance (QA) Plan “Conducting Analytical Work in Support of Regulatory Programs” provided the operational and quality control protocols for the analytical activities, and whenever possible, analyses were performed to SW-846 equivalent methods and protocols.

The inorganic and radiochemical analytes of interest and recommended methods are defined in the BNFL proposal and Test Plan BNFL-29953-30 Revision 0. All inorganic and radiochemical analytes of interest defined by these documents are reported. Estimated method detection limits (MDL) are provided where analytes of interest were not detected. Certain other originally requested analyses have not been performed based on agreements between Battelle, BNFL, and/or W-DOE. These inorganic analyses are total sulfide, reactive sulfide, reactive cyanide, total sulfur, total nitrogen, total iodine, and stainless steel corrosion testing.

Per the analysis protocols established by the QA Plan, process blanks, samples, duplicates, blank spikes (or lab control standards) and matrix spikes (or post spikes) were analyzed, as appropriate. Recoveries for quality control samples (such as matrix spikes and blank spikes) are discussed in this report and evaluated for their effect on the reported results if they failed to meet the acceptance criteria of the QA Plan. All analytical data and QC results are included in the Project File 29274 (Record Inventory and Disposition Schedule, Technical Support to BNFL for Phase 1B, T5.5).

The composite of the C-104 as-received material was prepared per Test Plan BNFL-29953-31, Revision 0. The C-104 composite (from 14 shipping jars) was prepared in a three-liter stainless steel vessel with a bottom drain spigot. A bladed stainless steel impeller was used to homogenize the material. While the composite was being stirred, the composite was drained into three 125-mL glass jars to demonstrate the ability to obtain representative sub-samples. These sub-samples were allowed to settle for a minimum of 16 hours. After this settling period, the volume percent of settled solids in each of the 125-mL glass jars was similar (i.e., 88.9% to 89.9%), providing indication that the sub-samples were representative of the composite. Following confirmation of representative sub-sampling, the remaining composite was re-agitated and three additional 500-mL glass bottles were used to sub-sample the remainder of the C-104 composite into fractions labeled C-104 Comp C, C-104 Comp D, and C-104 Comp E. These latter four fractions were allowed to stand for 5 weeks. The supernatant was collected and combined into one fraction, C-104 Sup A. The supernatant was observed to be red and the centrifuged solids were observed to be green.

Figure 1.1 provides the sample flow diagram for the preparation of the C-104 as-received analytical characterization sub-samples. Two containers of C-104 composite slurry (C-104 Comp A and C-104 Comp B) and one container of composite supernatant (C-104 SUP A) were allocated for organic, inorganic, and radiochemical characterization. The compositing and sub-sampling operations were conducted in the High Level Radiation Facility (HLRF). The sub-samples were transferred under chain-of-custody (COC) to the Shielded Analytical Laboratory (SAL) for characterization analysis preparation and distribution.




Figure 1.1. Compositing and Sub-sampling for C-104 As-Received Analytical Samples

2.0 Sample Processing

The inorganic and radiochemical analysis sample processing instructions were provided to the SAL via special instruction included with Analytical Service Request (ASR) number 5729 and the total dissolved solids (TDS), weight percent solids, and phase separation instructions were provided via Test Plan BNFL-TP-29953-080. The inorganic and radiochemical sub-sampling was performed after all organic sub-sampling had been completed, to minimize loss of volatile organic compounds.

2.1 Total Dissolved Solids and Weight Percent Solids

Duplicate aliquots (approximately 3 g each) were withdrawn from C-104 Comp A for determination of centrifuged weight percent solids (wt% solids) of the composite slurry, TDS of the supernatant, and wt% solids (dry) of the centrifuged solids phase. The aliquots were withdrawn from the C-104 Comp A jar while the contents were mechanically stirred providing homogeneous sub-samples. The aliquots were placed in volume-graduated centrifuge tubes and centrifuged at 1100 rpm for about one hour. Following centrifuging, the volume percent solids and wt% solids (wet) were determined on the slurry. Following phase separation by decanting, the wt% solids (dry) of the centrifuged solids fraction and the TDS of the supernatant fraction were determined. Table 2.1 provides the results for the TDS and percent solids.

Table 2.1. Slurry Vol% and Wt% Solids, TDS, and Centrifuged Solids Wt% Solids

Sample ID	Slurry		Supernatant	Centrifuged Solids
	Volume % Centrifuged Solids (Wet)	Weight % Centrifuged Solids (Wet)	TDS (%)	Weight % Solids (Dry)
C-104 Comp A	63	81.0	16.7	58.8
C-104 Comp A Dup	60	83.0	16.8	59.4

Based on the Slurry wt% wet centrifuged solids and the Centrifuged Solids wt% dry solids, the Slurry wt% solids (dry) averages 51.5%, of the as-received material.

2.2 Phase Separation

The contents of C-104 Comp A and C-104 Comp B were separated into solids and supernatant phases so that inorganic and radiochemical analyses could be performed on each phase. The phase separation was performed by centrifuging and decanting the supernatant. Each sample was centrifuged in its original jar at 1100 rpm for one hour, and the supernatant decanted and combined with C-104 SUP A. The wet centrifuged solids remained in the original jars. Following sub-sampling and processing for organic analysis, sub-samples of the supernatant and centrifuged solids were processed for inorganic and radiochemical analysis. Following phase separation, the RPL internal tracking number 00-1360 was used to identify the supernatant sample and 00-1361 was used to identify the centrifuged solids sample.

2.3 Supernatant Density Measurements

Due to the viscous nature of the as-received supernatants, all supernatant samples were processed by weight (i.e., most analytical sub-samples were aliquotted by weight instead of by volume). The density of the supernatant was determined by weighing 5-mL aliquots delivered from a calibrated 5-mL pipet. The delivery volume of the pipet was determined by five replicate measurements of water density corrected for the ambient temperature. The resulting average density was used to convert supernatant results from a per mass to a per volume basis, as necessary. Table 2.2 provides the density results obtained on the C-104 supernatant following phase separation.

Table 2.2. Density Results for C-104 Supernatant Composite

RPL Number	Sample ID	Density (g/mL)	Average Density (g/mL)
00-01360	Supernatant	1.163	1.161
	Supernatant Duplicate	1.160	
	Supernatant Triplicate	1.160	

2.4 Initial Preparation of Supernatants and Solids

The processing of the C-104 composite supernatant and solids and distribution of the processed samples are detailed in Figure 2.1. All processing was conducted in the SAL.




Figure 2.1. Flow Diagram for Analytical Preparation of Supernatant and Solids

The C-104 composite supernatant was prepared by acid digestion per procedure PNL-ALO-128 (HNO₃-HCl acid digestion) for metals analysis by inductively coupled plasma spectrometry (ICP), radiochemical analysis, and metal and radionuclides analysis by inductively coupled plasma – mass spectrometry (ICP/MS). The digested solutions had no visible residue or precipitate. All other analyses were performed directly on the supernatant or on water dilutions of the supernatant.

For the centrifuged solids, three preparative methods, PNL-ALO-129 (HNO₃-HCl acid digestion), PNL-ALO-115 (KOH-KNO₃ fusion), PNL-ALO-116 (Na₂O₂-NaOH-NaCl fusion), were performed on the dried centrifuged solids to provide analysis solutions for analytes of interest. The different preparative techniques were utilized in order to obtain optimal analyte information. For example, some analytes will go into solution only when fused, such as Si and refractory metals. Other analytes, such as Na and K, are better analyzed from an acid digestion where the fusion flux is absent. The wet centrifuged samples were initially dried to provide more consistent sub-sampling for the small aliquots taken for dissolution. The acid digestion and KOH-KNO₃ fusion preparations were analyzed for metals by ICP; the KOH-KNO₃ fusion preparations were used for radiochemical analyses and for metals and radionuclides by ICP/MS. The Na₂O₂-NaOH-NaCl fusion was prepared specifically to obtain solutions for analysis of platinum by ICP/MS. All acid digestion and fusion preparations produced clear solutions with no visible residue, except for a few of the samples prepared by the Na₂O₂-NaOH-NaCl fusion, which demonstrated a slight cloudiness. The wt% dry solids from the analysis of the wet centrifuged solids were used to adjust the measured results to the reported ‘per gram wet centrifuged solids’ basis.

Aliquots of wet centrifuged solids were diluted/leached per PNL-ALO-103. Aliquots of the water leach were analyzed for soluble anions by ion chromatography (following filtering), ammonia by ion specific electrode (ISE), and tritium by liquid scintillation counting.

Carbon (total carbon-TC, total inorganic-TIC, and total organic-TOC) , mercury, and cyanide analyses were performed directly on the wet centrifuged solid.

Sub-samples from the processing steps were delivered to specific laboratories for analysis under COC.

3.0 Analysis Results for Analytes of Interest

Tables 3.1 through 3.5 provide the results for all inorganic and radiochemical analyses performed on the C-104 as-received composite. Results for samples and duplicates, as well as processing blanks (PB), are reported. Although the supernatants were processed by weight, the density of the supernatants has been used to provide the results in $\mu\text{g/mL}$ or $\mu\text{Ci/mL}$, as appropriate. Solids are reported in $\mu\text{g/g}$ or $\mu\text{Ci/g}$, as appropriate, where g represents mass of centrifuged wet solids. These results may be converted to a dry weight basis using the wt% solids given in Table 2.1. The reported results have not been corrected for contributions present in the process blank.

The ICP/MS results are reported in both $\mu\text{g/mL}$ and $\mu\text{Ci/mL}$ for supernatants and $\mu\text{g/g}$ and $\mu\text{Ci/g}$ for solids (where activity units are relevant). The results are provided based on both curies and mass so that a direct comparison can be made against the minimum reportable quantity (MRQ) specifications. The radionuclides measured by ICP/MS have supernatant MRQs specified in $\mu\text{Ci/mL}$ and solids MRQs specified in $\mu\text{g/g}$.

To evaluate the concentrations of analytes of interest in the as-received slurry material, slurry results have been calculated from the concentrations measured in the supernatant and in the wet centrifuged solids and the weight fractions of each phase. To provide a conservative total slurry concentration, the highest measured concentration from either the sample or the duplicate, from either preparative technique (where applicable), for each phase is used in the calculation. Where no analyte concentration is measured (i.e., results are less than MDL), the lowest MDL is used in the calculation. The “maximum” slurry concentration is calculated by Equation (1).

$$C_m = ((C_1 / D_1) * W_1) + (C_s * W_s) \quad (1)$$

Where: C_m = Maximum slurry concentration in $\mu\text{g/g}$ or $\mu\text{Ci/g}$

C_1 = Analyte concentration in supernatant in $\mu\text{g/mL}$ or $\mu\text{Ci/mL}$

D_1 = Density of supernatant in g/mL (i.e., 1.161 g/mL , Table 2.2)

W_1 = Weight fraction of supernatant (i.e., 0.18, Table 2.1)

C_s = Analyte concentration in solids in $\mu\text{g/g}$ or $\mu\text{Ci/g}$

W_s = Weight fraction of wet centrifuged solids (i.e., 0.82, Table 2.1)

Table 3.1. C-104 As-Received --- ICP Metals Results

Tank Material Matrix Dissolution Lab ID Units	C-104 As-Received ⁽¹⁾												
	Supernatant				Centrifuged Wet Solids								
	Acid Digest				KOH-KNO ₃ fusion				Acid Digest				Max Slurry Conc. µg/g
	00-1360 PB	00-1360 Sample	00-1360-d Dup.	(2) RPD	00-1361 PB	00-1361 Sample	00-1361-d Dup.	(2) RPD	00-1361 PB	00-1361 Sample	00-1361-d Dup.	(2) RPD	
	µg/mL	µg/mL	µg/mL	(%)	µg/g	µg/g	µg/g	(%)	µg/g	µg/g	µg/g	(%)	
RNFI List													
Ag	< 0.1	[1.4]	[1.6]		< 13	210	158	28	< 0.8	[54]	[46]		170
Al	5.3	418	449	7	[51]	63,800	68,600	7	33	72,100	73,300	2	60,200
As	< 1.2	< 12	< 13		< 130	< 151	< 114		< 8	< 71	< 73		< 95
B	12.4	205	237	14	< 26	< 30	< 23		76	[71]	[71]		95
Ba	[0.08]	< 0.5	[0.5]		< 5	79	83	4	[0.5]	85	83	1	69
Be	< 0.05	< 0.5	< 0.5		< 5	[17]	[18]		< 0.3	[19]	[19]		16
Bi	< 0.5	< 4.9	< 5.1		< 52	< 61	< 46		< 3	< 29	< 29		< 24
Ca	< 1.2	[31]	[28]		< 130	2,020	2,020	0	< 8	2,140	2,140	0	1,760
Cd	< 0.1	9.0	9.8	9	< 8	388	393	1	< 0.5	411	420	2	584
Co	< 0.2	< 2.5	< 2.5		< 26	< 30	< 23		< 2	< 14	< 15		< 13
Cr	< 0.1	55.4	61	10	< 10	721	733	2	< 0.6	709	709	0	610
Cu	< 0.1	[6.9]	[7.7]		< 13	[106]	115		< 0.8	99	96	2	96
Fe	[0.18]	17.7	18.4	4	230	19,500	20,000	2	[1.1]	19,400	18,900	2	16,400
K	< 9.9	[620]	[690]		n/a	n/a	n/a		< 61	< 571	< 588		575
Li	< 0.1	21.0	22.9	9	< 16	205	207	1	< 0.9	249	252	1	210
Mg	< 0.5	[11]	[12]		< 52	[372]	[325]		< 3	[266]	[272]		307
Mn	< 0.2	[6.8]	[7.0]		[71]	4,430	4,490	1	< 2	4,830	4,850	0	3,980
Mo	< 0.2	[7.9]	[8.8]		< 26	< 30	< 23		< 2	< 14	< 15		13
Na	19.2	67,700	75,700	11	[709]	70,900	72,700	2	119	82,100	81,600	1	79,100
Ni	[0.35]	121	135	11	n/a	n/a	n/a		[2.2]	1,320	1,320	0	1,110
P	< 0.5	1,070	1,180	10	< 52	1,630	928	55	< 3	[89]	[65]		1,520
Pb	< 0.5	< 4.9	< 5.1		< 52	804	733	9	< 3	709	697	2	660
Pd	< 3.7	< 37	< 38		< 391	< 454	< 343		< 23	< 214	< 220		< 180
Rh	< 1.5	< 15	< 15		< 156	< 182	< 137		< 9	< 86	< 88		< 73
Sb	< 2.5	< 25	< 25		< 261	< 303	< 229		< 15	< 143	< 147		< 120
Se	< 1.2	< 12	< 13		< 130	< 151	< 114		< 8	< 71	< 73		< 60
Si	26.4	1,880	2,110	12	< 261	6,030	5,820	3	163	[768]	1,660		5,270
Sn	< 7.4	< 74	< 76		< 782	< 908	< 686		< 46	[585]	[585]		491
Tl	< 2.5	< 25	< 25		< 261	< 303	< 229		< 15	< 143	< 147		< 120
U	< 9.9	< 99	< 101		< 1040	21,300	21,300	0	< 61	23,600	23,600	0	19,400
U (KinPhos) ⁽³⁾	0.005	29	30	5	0.54	19,800	19,200	3	n/m	n/m	n/m		16,200
U (ICP-MS) ⁽³⁾	0.013	31.6	35.8	12	< 84	21,400	21,000	2	n/m	n/m	n/m		17,600
V	< 0.2	< 2.5	< 2.5		< 26	[31]	< 23		< 2	< 14	< 15		< 12
W	< 9.9	< 99	< 101		< 1040	< 1210	< 915		< 61	< 571	< 588		< 480
Y	< 0.2	< 2.5	< 2.5		< 26	< 30	< 23		< 2	[17]	[17]		14
Zn	< 0.2	< 2.5	< 2.5		< 26	[100]	[95]		< 2	[95]	[95]		83
Zr	< 0.2	[20]	[20]		< 26	23,600	24,000	1	< 2	17,200	17,500	2	19,700
Other Analytes Detected													
Ce	< 1.0	< 9.9	< 10		< 104	[266]	[177]		< 6	[154]	[136]		220
La	< 0.2	< 2.5	< 2.5		< 26	[71]	[59]		< 2	[65]	[59]		59
Nd	< 0.5	< 4.9	< 5.1		< 52	[183]	[130]		< 3	[136]	[136]		151
Sr	< 0.1	< 0.7	< 0.8		< 8	[38]	[41]		< 0.5	[40]	[40]		34
Th	< 5.0	< 49	< 51		< 521	26,100	27,300	5	< 31	30,600	30,900	1	25,400
Ti	< 0.1	< 1.2	< 1.3		< 13	[95]	[95]		< 0.8	[58]	[57]		78
(1) Overall error for reported results is estimated to be within ±15% (2-σ ; however results in brackets “[]” are less than the estimated quantitation level (i.e., 10-times MDL listed in Table 6.1) and error is anticipated to be greater than ±15%. (2) RPD only calculated when both sample and duplicate exceed estimated quantitation level. (3) U (KinPhos) by kinetic phosphorescence; U (ICP/MS) by inductively-coupled plasma mass spectrometry.													

Table 3.2. C-104 As-Received --- Radiochemical Results

Tank Material Matrix/Dissolution Lab ID	C-104 As-Received														
	Supernatant -- Acid Digest							Centrifuged Wet Solids -- KOH-KNO3 Fusion							Max Slurry Conc. μCi/g
	00-1360 PB		00-1360 Sample		00-1360-d Dup.		(1) RPD	00-1361 PB		00-1361 Sample		00-1361-d Dup.		(1) RPD	
	Units (%Error ±1σ)	μCi/mL %Err	μCi/mL %Err	μCi/mL %Err	μCi/mL %Err	(%)		μCi/g %Err	μCi/g %Err	μCi/g %Err	(%)				
Analyte															
Co-60 (GEA)	<4.E-6		4.22E-2	3	4.73E-2	3	11	<3E-4		1.13E-1	3	1.12E-1	3	1	1.00E-1
Se-79 ⁽²⁾			6.41E-5	4	6.50E-5	5	1	<4E-4		3.80E-3	6	3.94E-3	7	4	3.24E-3
Sr-90	<2.E-3		1.06E-1	16	1.08E-1	16		<1E-1		2.97E+2	3	3.14E+2	3	5	2.57E+2
Nb-94 (GEA)	<3.E-6		<2.E-3		<2.E-3			<3E-4		<2E-2		<2E-2			<1E-2
Ru-106/Rh-106 (GEA)	<3.E-5		<9.E-2		<9.E-2			<3E-3		<2E-1		<2E-1			<2E-1
Sb-125 (GEA)	<9.E-6		<6.E-2		<6.E-2			<1E-3		<1E-1		1.58E-1	20		1.39E-1
Sn-126 (GEA)	<3.E-6		<2.E-2		<3.E-2			<4E-4		<4E-2		<4E-2			<3E-2
Cs-134 (GEA)	<4.E-6		<2.E-3		<2.E-3			<4E-4		<1E-2		<1E-2			<1E-2
Cs-137 (GEA)	1.27E-4	5	3.66E+1	2	4.05E+1	2	10	4.72E-2	2	4.08E+1	2	4.10E+1	2	1	3.99E+1
Eu-154 (GEA)	<9.E-6		<3.E-3		<3.E-3			<1E-3		9.16E-1	2	9.28E-1	2	1	7.61E-1
Eu-155 (GEA)	<2.E-5		<4.E-2		<4.E-2			<1E-3		5.32E-1	5	5.48E-1	5	3	4.56E-1
Pu-236	<7.E-7		<2.E-6		<1.E-5			<3E-5		<2E-3		<1E-3			<1E-3
Pu-238	<2.E-6		1.78E-4	7	1.88E-4	8	5	1.34E-4	40	3.41E-1	6	3.43E-1	5	1	2.82E-1
Pu-239+Pu-240	<2.E-6		1.82E-3	4	1.82E-3	4	0	1.15E-4	34	2.97E+0	4	2.89E+0	4	3	2.43E+0
Pu-241	<1.E-4		5.07E-3	9	5.11E-3	9	1	<5E-3		8.21E+0	8	1.03E+1	8	22	8.43E+0
Am-241 (GEA)	<3.E-5		<4.E-2		<4.E-2			<1E-3		3.42E+0	3	3.40E+0	3	0	2.81E+0
Am-241 (AEA)	<4.E-6		2.01E-3	5	2.02E-3	5	0	2.91E-4	27	3.27E+0	5	3.25E+0	5	1	2.69E+0
Cm-242	<5.E-7		5.73E-6	40	1.02E-5	31		<2E-5		8.92E-3	28	5.54E-3	33		7.32E-3
Cm-243+Cm-244	<2.E-6		4.23E-5	15	3.81E-5	16		5.21E-5	49	3.45E-2	15	4.58E-2	12		3.76E-2
Beta	1.42E-3	9	3.00E+1	4	3.08E+1	4	3	4.20E-1	22	7.21E+2	4	6.80E+2	4	6	5.96E+2
Alpha	<1.E-4		4.03E-3	6	4.58E-3	5	13	<1E-2		5.79E+0	3	6.09E+0	3	5	4.99E+0
Alpha Sum ⁽³⁾	n/a		4.06E-3		4.08E-3		0	5.92E-4		6.63E+0		6.54E+0		1	5.43E+0
	Supernatant -- Direct							Centrifuged Wet Solids -- Water Leach							
H-3	n/a		4.53E-3	4	4.81E-3	4	6	1.28E-2	4	5.93E-2	5	1.14E-2	5	136	4.94E-2
	Supernatant -- Direct							Centrifuged Wet Solids -- Direct							
C-14	n/a		7.7E-4	5	7.71E-4	5	0	n/a		1.12E-3	7	1.28E-3	7	13	1.17E-3
(1) RPD is only calculated when both sample and duplicate have error uncertainties <10% (1-σ).															
(2) Se-79 analysis performed directly on supernatant material, not on acid digestion preparation.															
(3) Alpha Sum equals the μCi/mL or μCi/g summation of Pu-238, Pu-239+240, Am-241, Cm-242, and Cm-243+244.															

Table 3.3. C-104 As-Received --- ICP/MS Results

Tank Material Matrix Dissolution Lab ID Units	C-104 As-Received ⁽¹⁾												
	Supernatant								Centrifuged Wet Solids				Max. Slurry Conc.
	Acid Digest				Water Dilution				KOH-KNO ₃ Fusion				
	00-1360	00-1360	00-1360-d		00-1360	00-1360	00-1360-d		00-1361	00-1361	00-1361-d		
	PB	Sample	Dup.	RPD ⁽²⁾	PB	Sample	Dup.	RPD ⁽²⁾	PB	Sample	Dup.	RPD ⁽²⁾	
	µCi/mL	µCi/mL	µCi/mL	%	µCi/mL	µCi/mL	µCi/mL	%	µCi/g	µCi/g	µCi/g	%	
Analyte													
Tc-99	< 4E-5	1.40E-2	1.49E-2	6.2	< 1E-4	1.44E-2	1.45E-2	0.7	< 2E-3	2.65E-2	2.90E-2	9.0	3.77E-2
I-129	< 8E-7	[1.80E-4]	[2.17E-4]		< 3E-5	[2.13E-4]	1.95E-4		< 2E-4	[5.00E-4]	[4.10E-4]		6.43E-4
U-233	< 1E-6	3.37E-4	3.95E-4	16	< 1E-4	3.15E-4	2.18E-4	36	< 7E-3	2.56E-1	2.43E-1	5.2	3.12E-1
U-234	< 6E-6	1.19E-5	1.89E-5	45	< 3E-6	1.55E-5	1.31E-5	17	< 4E-3	1.01E-2	1.50E-2	39	1.83E-2
U-235	< 5E-9	4.79E-7	5.52E-7	14	< 2E-8	4.80E-7	3.65E-7	27	1.0E-5	3.35E-4	3.14E-4	6.5	4.09E-4
U-236	< 3E-8	6.26E-7	7.46E-7	17	< 7E-7	6.07E-7	4.27E-7	35	< 5E-5	3.86E-4	4.40E-4	13	5.37E-4
U-238	< 4E-9	1.05E-5	1.19E-5	13	< 3E-8	1.06E-5	7.87E-6	30	< 3E-5	7.13E-3	7.03E-3	1.4	8.70E-3
Np-237	< 2E-6	3.01E-5	3.09E-5	3	< 3E-7	3.58E-5	3.44E-5	4.0	< 2E-4	2.55E-3	2.75E-3	7.5	3.36E-3
Pu-239 ⁽³⁾	< 1E-5	2.36E-3	2.37E-3	0.4	9.8E-4	[9.60E-3]	4.1E-3		< 3E-1	[2.10E+0]	2.18E+0		1.79E+0
Pu-240 ⁽³⁾	< 4E-5	6.45E-4	[6.55E-4]		< 1E-3	[2.E-3]	[1.3E-3]		< 3E-2	6.77E-1	6.53E-1	3.6	5.55E-1
Units	µg/mL	µg/mL	µg/mL	%	µg/mL	µg/mL	µg/mL	%	µg/g	µg/g	µg/g	%	µg/g
Analyte													
Tc-99	< 2E-3	8.24E-1	8.76E-1	6.2	< 7E-3	8.47E-1	8.53E-1	0.7	< 1E-1	1.56E+0	1.71E+0	9.0	2.22E+0
I-129	< 5E-3	[1.02E+0]	[1.23E+0]		< 2E-1	[1.20E+0]	1.10E+0		< 1E0	[2.82E+0]	[2.32E+0]		3.64E+0
U-233	< 1E-4	3.50E-2	4.10E-2	16	< 1E-2	3.27E-2	2.26E-2	36	< 7E-1	2.66E+1	2.52E+1	5.2	3.24E+1
U-234	< 1E-3	1.91E-3	3.04E-3	45	< 5E-4	2.49E-3	2.10E-3	17	< 6E-1	1.62E+0	2.41E+0	39	2.94E+0
U-235	< 3E-3	2.50E-1	2.86E-1	14	< 1E-2	2.50E-1	1.90E-1	27	< 5E0	1.74E+2	1.63E+2	6.5	2.13E+2
U-236	< 5E-4	9.62E-3	1.15E-2	17	< 1E-2	9.33E-3	6.56E-3	35	< 8E-1	5.93E+0	6.76E+0	13	8.25E+0
U-238	< 1E-2	3.13E+1	3.54E+1	13	< 9E-2	3.15E+1	2.34E+1	30	< 9E1	2.12E+4	2.09E+4	1.4	2.59E+4
Np-237	< 3E-3	4.27E-2	4.38E-2	3	< 4E-4	5.08E-2	4.88E-2	4.0	< 3E-1	3.62E+0	3.90E+0	7.5	4.76E+0
Pu-239	< 2E-4	3.80E-2	3.82E-2	0.4	< 2E-2	[1.60E-1]	6.93E-2		< 5E0	3.38E+1	3.51E+1	3.7	4.29E+1
Pu-240	< 2E-3	1.59E-3	[2.09E-3]		< 4E-3	[1.19E-2]	[6.17E-3]		< 1E-1	2.98E+0	2.88E+0	3.6	3.64E+0
Cs-133	1.6E-2	9.3E-1	1.05E+0	12	3.5E-2	1.28E+0	1.28E+0	0	[4.E-1]	1.87E+0	[2.13E+0]		2.80E+0
I-127	[1.E-2]	[1.01E+0]	1.15E+0		< 1E-1	[7.60E-1]	[6.70E-1]		[1.1E+0]	[1.7E+1]	[1.9E+1]		2.33E+1
Pr	< 1E-3	2.51E-2	[2.90E-2]		3E-2	[7.30E-2]	[3.00E-2]		[4.E-1]	4.08E+1	4.38E+1	7.1	5.34E+1
Pt ⁽⁴⁾	n/m	n/m	n/m		n/m	n/m	n/m		8.0E-2	2.09E-1	3.14E-1	40	n/c
Rb	1.7E-2	5.54E-1	5.90E-1	6	7E-2	5.64E-1	5.90E-1	5	9.87E+1	1.70E+2	1.52E+2	11	2.07E+2
Ta	< 2E-3	[3.30E-3]	[5.20E-3]		< 3E-3	[3.6E-3]	< 3E-3		< 2E-1	1.06E+0	1.05E+0	0.9	1.29E+0
(1) Reported error is within +/-15%; bracketed results indicate the error exceeds +/-15% (2-σ).													
(2) RPD is calculated on sample and duplicate values where the individual errors are <15% (2-σ) .													
(3) The maximum slurry concentration is calculated using the supernatant acid digestion value as it is considered more accurate.													
(4) Pt was measured from the Na ₂ O ₂ -NaOH-HCl fusion preparation.													
n/m: not measured; n/c: not calculated													

Table 3.4. C-104 As-Received Cs and U Mass Abundance Ratios

<i>Tank Material</i> <i>Matrix</i> <i>Dissolution</i> <i>Lab ID</i>	C-104 As-Received					
	Supernatant			Centrifuged Wet Solids		
	Acid Digestion			KOH-KNO ₃ Fusion		
	00-1360 Sample	00-1360-d Dup.	RPD	00-1361 Sample	00-1361-d Dup.	RPD
<i>Units</i>	% mass abundance		%	% mass abundance		%
Analyte						
Cs-133	5.53E+1	5.59E+1	1.1	6.94E+1	7.22E+1	4.0
Cs-135	1.97E+1	1.93E+1	2.1	1.33E+1	1.19E+1	11
Cs-137	2.50E+1	2.48E+1	0.8	1.74E+1	1.60E+1	8.4
U-233	1.11E-1	1.15E-1	3.5	1.03E-1	9.57E-2	7.3
U-234	6.07E-3	8.50E-3	33	7.83E-3	8.91E-3	13
U-235	7.04E-1	7.17E-1	1.8	6.98E-1	7.15E-1	2.4
U-236	3.05E-2	3.22E-2	5.4	2.93E-2	2.78E-2	5.3
U-238	9.91E+1	9.91E+1	0.020	9.92E+1	9.92E+1	0.010

Table 3.5. C-104 As-Received --- Other Results

Tank Material Matrix Lab ID Units	C-104 As-Received ⁽¹⁾										
	Supernatant					Centrifuged Wet Solids					Max. Slurry Conc. μg/g
	Type of Prep	00-1360 PB	00-1360 Sample	00-1360-d Dup.	⁽²⁾ RPD	Type of Prep	00-1361 PB	00-1361 Sample	00-1361- Dup.	⁽²⁾ RPD	
		μg/mL	μg/mL	μg/mL	(%)		μg/g	μg/g	μg/g	(%)	
Analyte											
TIC	Persulfate	n/a	8,330	8270	1	Persulfate	n/a	4,200	3,800	10	4,730
TOC	Persulfate	n/a	6,500	6,720	3	Persulfate	n/a	10,300	7,700	29	9,490
TC (sum)	Persulfate	n/a	14,800	15,000	1	Persulfate	n/a	14,500	11,500	23	14,200
TC	Furnace	n/a	14,900	14,100	6	Furnace	n/a	24,800	22,100	12	22,600
Fluoride	Dir./Dil.	n/a	9,710 ⁽³⁾	9,500 ⁽³⁾	2	Water	< 24	46,200 ⁽²⁾	48,300 ⁽²⁾	2	41,100
Chloride	Dir./Dil.	n/a	790	720	9	Water	[26]	250	220	12	330
Nitrite	Dir./Dil.	n/a	34,200	29,100	16	Water	< 48	10,500	10,500	0	13,900
Bromide	Dir./Dil.	n/a	3,270	2,920	11	Water	< 24	1,020	1,020	0	1,350
Nitrate	Dir./Dil.	n/a	17,600	16,100	9	Water	< 48	5,630	5,590	1	7,350
Phosphate	Dir./Dil.	n/a	3,040	2,640	14	Water	< 48	9,650	2,600	115	8,400
Sulfate	Dir./Dil.	n/a	3,870	3,410	13	Water	< 48	1,430	1,410	1	1,800
Oxalate	Dir./Dil.	n/a	3,590	3260	10	Water	< 48	7,690	7,440	3	6,900
Mercury	Acid Digest	0.014	0.722	0.602	20	Acid Digest	< 0.05	41.1	40.2	2	34
Ammonia	Dir./Dil.	n/a	17.4	19.2	10	Water	1.05	3.38	3.09	9	5.7
Cyanide (total)	Distillation	<0.01	7.4	8.5	14	Distillation	<0.04	11.4	13.8	19	13
Units		°F	°F	°F							
Flashpoint	Direct	n/a	220 ⁽⁴⁾	218 ⁽⁴⁾							
Units		mmole/mL	mmole/mL	mmole/mL							
Hydroxide	Dir./Dil.	< 0.01 ⁽⁵⁾	0.81	0.82	0.4						
Units		pH	pH	pH							
pH	Direct	n/m	12.1	12.1	0						

(1) Overall error for reported results is estimated to be within ±15% (2-σ) ; bracketed results indicate the error exceeds +/- 15% (2-σ)

(2) RPD only calculated when sample and duplicate results above threshold for method’s RPD calculation (calculated prior to rounding).

(3) IC system quantifies F based on retention time; however, fluoride, formate and acetate can not be resolved. Reported value reflects contribution formate and/or acetate.

(4) Flashpoint is attributed to a “false flash” due to water volatilizing to steam.

(5) No titration inflection point detected; free hydroxide estimated at <0.01 mmole/mL.

dir./dil.= direct or dilution; n/a = not applicable; n/m = not measured due to applicability of method

4.0 TCLP Metals Analysis and Evaluation

The TCLP, SW-846 Method 1311, was not performed on C-104 waste materials for toxic metals. The estimated TCLP metals concentrations are calculated from 1) the concentrations of the supernatant TCLP metals, 2) the concentrations from acid digestion of the solids TCLP metal (assuming all metals would be leached 100% using Method 1311), 3) the density of the supernatant, and 4) the centrifuged wet wt% solids. The centrifuged wet wt% solids are used instead of the filtered wet wt% solids from Method 1311; however, the two methods for determining the wet wt% solids are considered reasonably comparable for this exercise. The concentrations of the TCLP metals are estimated by assuming that the supernatants and solids are analyzed separately and combined mathematically per Method 1311. The estimated concentrations of the TCLP metals in the as-received tank waste materials, assuming a 100 g initial sample size for processing, is provided in Equation 2:

$$C = [(L * (V_1/D_1)) + (S * V_2)] / [(V_1/D_1) + (V_2 * F/D_2)] \quad (2)$$

Where:

- C = Waste material TCLP metal concentration in µg/mL
- L = average supernatant TCLP metal concentration in µg/mL
- S = average solids TCLP metal concentration in µg/g
- D₁ = density of supernatant in g/mL (1.161 g/mL)
- D₂ = 1, approximate density in g/mL of the TCLP extraction fluid
- V₁ = mass in g of supernatant of nominal 100 grams of waste material = (100 g) * (1 – W/100); i.e., 18 g
- V₂ = mass in g of TCLP fluid to add to solids fraction of waste material for TCLP extraction = (100 g) * (W/100); i.e., 82 g
- F = 20, the TCLP fluid to solids extraction ratio
- W = centrifuged wt% solids (82%).

The TCLP metals concentrations in the solids from the acid digestion preparations are used for the calculation. The acid digestion results are considered to be conservative since the nitric-hydrochloric acid digestion is significantly more rigorous than the TCLP acetic acid leach. Additional conservatism is ascribed to these calculations in that the results used were not corrected for contributions present in the process blank. Table 4.1 provides the predicted maximum TCLP metals concentration results for the C-104 as-received waste material.

The contribution of the solids only to the TCLP metals leach concentration is also provided in Table 4.1 under the heading “20:1 Leach Equivalent.” This concentration is calculated according to Equation 3:

$$C_s = S / (F/D_2) \quad (3)$$

Where: C_s = the solid TCLP concentration in µg/mL.

The results indicate that the C-104 waste materials may have TCLP metal concentrations that exceed the regulatory threshold, specifically cadmium, chromium, mercury, and lead. Due to the dilutions required for the analyses to support ALARA (as low as reasonably achievable) radiation exposure concerns and the low regulatory threshold for selenium (i.e., 1 µg/mL), it cannot be determined if selenium exceeds the threshold. Nickel is included in the TCLP table at the request of BNFL; however, there is no TCLP threshold associated with nickel.

Table 4.1. TCLP Metals Predicted Maximum Concentrations

TCLP Analytes	TCLP Limit µg/mL	C-104 As-Received			Predicted Maximum TCLP Conc. ⁽¹⁾ µg/mL
		Supernatant	Wet Solids		
		Acid Digest 00-1360 Average µg/mL	Acid Digest 00-1361 Average µg/g	20 : 1 Leach Equivalent	
				Average µg/mL	
Ag	5.0	[1.5]	[50]	[4.2]	2.5
As	5.0	< 13	< 72	< 1.4	< 3.7
Ba	100.0	[0.5]	84	7.1	4.2
Cd	1.0	9.4	415	35	20.7
Cr	5.0	58	709	60	35.7
Hg	0.20	0.66	40.7	2.03	2.02
Ni	--	128	1,320	112	66.6
Pb	5.0	< 5.0	703	60	34.9
Se	1.0	< 13	< 72	< 6.1	< 3.7
Values in [] are above the MDL but below the EQL and have uncertainties >15% at 2-σ. Shaded and boxed values exceed or potentially exceed regulatory threshold.					

- (1) The predicted maximum TCLP metals concentration is determined from a nitric/hydrochloric acid leach of the wet centrifuged solids and supernatant. A true TCLP leach could result in significantly lower TCLP metal concentrations.

5.0 Quality Control and Data Evaluation

5.1 Metals Analysis by ICP – Table 3.1

Aliquots of the acid-digested and fused samples were submitted to the ICP workstation. The samples were analyzed in two analytical batches following procedure PNL-ALO-211. Where analytes were not detected, the results are reported as less than the MDL. Results shown in brackets “[]” are less than the estimated quantitation level (EQL), and have uncertainties exceeding $\pm 15\%$, $2\text{-}\sigma$. For the ICP, the EQL is defined as ten times the MDL. Above the EQL, results are expected to have $2\text{-}\sigma$ uncertainties of less than $\pm 15\%$, and typically less than $\pm 10\%$.

The analyte concentrations reported for the wet centrifuged solids prepared by acid digestion and KOH-KNO₃ fusion agree reasonably well. Two analytes, Si and Zr, are exceptions; their concentrations are significantly lower in the acid digestion preparation. The fusion preparation method is much better than acid digestion in dissolving Si and Zr compounds, thus concentrations derived from the fusion preparation are considered more reliable for Si and Zr.

Quality control for the ICP analysis consists of duplicates, matrix spikes, blank spikes, post spikes, process blanks, serial dilution, laboratory control standards, and calibration verification check standards. An evaluation of each of the quality control (QC) criteria was performed and a summary is presented below.

Duplicates: Except for a very few cases, the relative percent differences (RPD) for analytes of interest were within the acceptance criterion of 20%. Exceptions are for the fusion preparation of solids for silver (28%) and phosphorous (55%).

Matrix Spikes: A matrix spike was not required to be run with the fusion preparation. Matrix spikes associated with the acid digestion of the liquids and solids recovered within the tolerance limit of 75% to 125% except silver (24% and 27%), barium (56%), and arsenic (50%). Chloride from the hydrochloric acid used in the acid digestion likely precipitated the silver as AgCl, resulting in low recovery. Low barium recovery may be caused by the presence of sulfate in the sample precipitating barium as BaSO₄.

Blank Spikes: Blank spikes were prepared with the acid digestion procedures; a blank spike was not required for the fusion preparation. All spikes recovered within the tolerance limit of 80% to 120% except silver (21%). Chloride from the hydrochloric acid used in the digestion procedure may have precipitated the silver as AgCl causing low recovery.

Post Spikes: All post-digestion spikes recovered within the tolerance limits of 75% to 125%.

Process Blanks: Analytes of interest detected in the processing blanks for the acid digestions of the supernatants and solids and the KOH-KNO₃ fusions were below the EQL or $<5\%$ of the sample concentration, except for boron in both the acid digestions of the supernatant and solid, and silicon in the acid digestion of solids. The boron concentration was about 6% of the concentration of the supernatant samples and about 100% of the concentration in the solids digested samples. The boron and silicon contamination is probably a result of leaching from the borosilicate glass digestion vessel. The boron measured in the acid-digested solid samples appears to be entirely from contamination and the actual boron results should be considered less than the MDL of 26 $\mu\text{g/g}$.

Serial Dilution: The calculated analyte concentrations from the sample analysis and the five-fold dilution of the sample met the acceptance criterion of $\pm 10\%$, where analyte concentrations exceeded the EQL,

with one exception. The sodium concentration determined from the 5X dilution of the wet solids fusion preparation was high by approximately 12% relative to the undiluted preparation. This indicates the Na concentration determined from the fusion preparation is potentially low by 12%. The average Na concentration determined from the acid digestion is higher than the average Na concentration determined from the fusion preparation by 14%, supporting the low bias indication of the fusion result. Thus the acid digestion result for Na is more reliable.

Laboratory Control Standard (LCS): A NIST SRM-2710 (Montana Soil) reference standard was processed with the fusion-prepared samples as a LCS. The blank spike served as the LCS for the acid digest samples. For all analytes in the LCS above the EQL, recoveries were within acceptance criteria.

Calibration Verification Check Standards: All standards provided results within acceptance criteria, except for a few analytes. Acceptance criteria for the QC Check Standard are $\pm 10\%$ of true value. Palladium measured low by 20% to 27% in the mixed QC standard run with the fusion-prepared sample series. A single-element palladium standard recovered within $\pm 3\%$. The acid digested samples were run separately and the mixed QC standard analytes recovered within $\pm 10\%$ except for magnesium (11% high in one of four measurements) and palladium (20% low). Again, the single element palladium standard recovered within $\pm 10\%$. These deviations are not expected to impact the reported analyte results.

5.2 Uranium Analysis by Kinetic Phosphorimetry– Table 3.1

Uranium was measured directly in dilutions of the SAL solids fusion and supernatant acid digestion preparations by kinetic phosphorescence analysis (KPA) following procedure PNL-ALO-4014. The diluted samples analyzed were within the concentration range of $1.E-4$ to $1.E+0$ $\mu\text{g/ml}$. The instrument performance was stable over this range as determined by uranium standards analyzed before and after the sample measurements where standard yields varied between 96% and 105%. Duplicate sample results showed good agreement with RPD values $< 5\%$. The uranium concentrations measured in the hot cell process blanks were negligible relative to the uranium in the samples. Uranium was not detected in the laboratory blanks. Post-digestion matrix spikes showed excellent recovery at 101% for the supernate and 99% for the solids. The uranium KPA results are in good agreement with ICP and ICP-MS results.

5.3 Radiochemical Analysis –Table 3.2

5.3.1 Gamma Emitters by Gamma Energy Analysis (GEA)

The sample solids fusion and supernatant acid digestion preparations from the SAL were gamma counted following procedure PNL-ALO-450. Most of the gamma emission from the samples was from Cs-137. Other detected gamma emitters were Co-60 in the supernatant and solids, and Sb-125, Eu-154, Eu-155, and Am-241 in the solids. All of these gamma emitters were at much lower concentration than the Cs-137. No gamma activity was detectable for Nb-94, Ru/Rh-106, Sb-125 (supernatant), Sn/Sb-126, or Cs-134. The SAL process blanks had detectable quantities of Cs-137, but at insignificant levels (three orders of magnitude lower) when compared to the Cs-137 levels in the samples. No other gamma emitters were detected in the blanks. All RPD results of detected analytes were $\leq 10\%$. The Am-241 results were in excellent agreement with the alpha energy analyses (AEA) discussed below for the solid samples. However, the AEA results had a much lower detection limit and were able to detect Am-241 in the supernatant samples below the GEA detection limit. Since gamma energy analyses are direct sample measurements not involving chemical separations, sample and reagent spikes were not required.

5.3.2 Total Alpha and Total Beta

For total alpha and total beta activity measurements, the SAL solids fusion and supernatant acid digestion sample preparations were further diluted and small aliquots evaporated on planchets for counting following procedures RPG-CMC-4001 and -408. The total alpha results were in good agreement with the sum of the individual alpha emitters. The supernatant total alpha and alpha sum averaged 4.31 $\mu\text{Ci/mL}$ and 4.07 $\mu\text{Ci/mL}$, respectively, representing a 6% difference. The wet centrifuged solids total alpha and alpha sum averaged 5.94 $\mu\text{Ci/g}$ and 6.58 $\mu\text{Ci/g}$, respectively, reflecting an 11% difference. (The sum of the alpha emitters is a better indicator of the total alpha activity as direct plating results in potential mass attenuation effects of the total alpha emissions.) The duplicate samples showed good agreement with $\pm 13\%$ RPD. Alpha activity was not detected in the SAL process blanks or laboratory blanks. Blank spikes for the solids and liquids showed acceptable recoveries; however, the solids sample alpha spike recovery was low at 73%, probably due to mass attenuation effects. This effect was not an issue with the sum of the individual alpha emitters, as discussed previously.

The total beta results were in reasonable agreement with the sum of the beta emitters, mainly Cs-137 and twice (to allow for Y-90) the Sr-90 activities. The total beta activity for the supernatant averaged 30.4 $\mu\text{Ci/mL}$ and the sum of the beta emitters averaged 38.8 $\mu\text{Ci/mL}$, representing a 28% difference. The total beta activity for the wet centrifuged solids averaged 700 $\mu\text{Ci/g}$ and the sum of the beta emitters averaged 652 $\mu\text{Ci/g}$, representing a 7.5% difference. The duplicate beta activity results agreed within 6% RPD. The SAL process blanks had beta activity concentrations three to four orders of magnitude less than the samples. The total beta matrix and blank spikes showed excellent recoveries ranging from 98% to 100%.

5.3.3 Plutonium, Americium, and Curium

Plutonium, americium, and curium were separated from diluted SAL solids fusion and supernatant acid digestion preparations using Eichrom TRU resin according to procedure PNL-ALO-417. The separated fractions were mounted for alpha spectroscopy by co-precipitation with a neodymium fluoride (NdF_3) carrier (procedure PNL-ALO-496) and counted by alpha energy analysis according to procedure PNL-ALO-422. Absolute activity of the alpha emitters was calculated relative to NIST-traceable Pu-242 and Am-243 tracers added to the sample aliquots at the start of the chemistry in the laboratory.

The SAL process blanks indicated detectable alpha emitters for the solids, but the activities were about three orders of magnitude lower than the samples. Where the counting uncertainties were less than 10% for the sample and duplicate, the plutonium and americium RPD results were $<5\%$ and well-within the acceptance criterion of $<20\%$. The blank spike and sample spike showed good yield-corrected recoveries of 82%-103%.

The plutonium sample mounts were placed into scintillation cocktail and counted according to PNL-ALO-474. The Pu-241 activity was determined by integrating the 2-20 keV region. Radiochemical yields, assessed through alpha spectrometry, were applied to the sample activity calculations. Because the laboratory was not notified of the need for Pu-241 determination until after the Pu-239+240 analyses were completed, Pu-241 blank spikes and matrix spikes were not prepared. The RPD for the Pu-241 supernatant was 1%; the RPD for the Pu-241 in the solids was 23%, greater than the $<20\%$ criterion. The mean difference of the solids duplicates was 0.95 indicating the results were not significantly different given the error of the method.¹

¹ The mean difference value indicates whether the results are statistically different at the 95% confidence level. Where the mean difference is greater than or equal to 1.96, there is 95% confidence the two results are not equal.

5.3.4 Strontium-90

Small aliquots of the SAL solids fusion and supernatant acid digested samples were taken for Sr-90 analysis. The Sr-90 analyses were conducted according to procedure PNL-ALO-476, which utilizes Sr-Spec resin that contains a crown-ether for the selective extraction of strontium from the radioactive and inactive matrix. After thorough washing, the strontium was back-extracted from the resin with water. The water was dried onto 2-inch planchets and counted with a gas-flow proportional counter according to procedure RPG-CMC-408. Radiochemical yields were determined with a Sr-85 tracer (added prior to radiochemical separation) counted by GEA according to procedure PNL-ALO-450. The beta count rate was corrected for the interference from the Sr-85 tracer and Y-90 in growth. The samples were analyzed in two batches; the supernatants were analyzed in one batch and the solids material analyzed in another batch. The wet centrifuged solids sample and duplicate showed good agreement with an RPD of 5%, well within acceptance criteria of <20%. The RPD was not reported for the supernatant sample and duplicate because the analytical error for each result exceeded 15%. No contamination was detected in either of the SAL process blanks or the laboratory blank. Sample matrix spikes and blank spikes were prepared in the radioanalytical laboratory and were processed with the sample batches. The blank spike and matrix spike yield-corrected recoveries were excellent at 92-97%. Radiochemical yields were >95%.

5.3.5 Tritium

Tritium was isolated directly from the supernatant sample material and from SAL water leachates of the solids. Tritium was distilled per procedure PNL-ALO-418, followed by liquid scintillation counting of the distillate per procedure PNL-ALO-474. For the liquid samples, the sample duplicates were in good agreement, no tritium was detected in the laboratory blank, and the blank spike showed good recovery at 95%. However, for the solid samples, the sample duplicates showed very poor agreement with an RPD of 136%. The SAL process blank for the water leach of the solids showed significant tritium activity, higher than one sample and at about 20% of the activity in the other sample. The SAL hot cells are known to have high levels of tritium contamination. Hence, the solids samples appear to be badly contaminated and the solids data are thus only useful as an upper limit to the tritium concentration in the samples. No tritium was detected in the solids blank prepared in the laboratory and a blank spike prepared in the laboratory showed good recovery at 103%. NIST-traceable standards were used to determine the detector efficiency. Due to an oversight, matrix spikes were not prepared for tritium distillation and analysis with either the liquid or solids samples.

5.3.6 Selenium-79

The Se-79 was isolated using procedure PNL-ALO-440 in samples of the direct supernatant and in aliquots of the fused solids. In this method the selenium is separated from the sample by precipitation, followed by ion exchange, and then distillation. The product selenium is measured by liquid scintillation counting following procedure PNL-ALO-474. Since a Se-79 calibration standard is not commercially available, blank spikes or matrix spikes could not be prepared. Carbon-14 (which has a nearly identical beta energy) was used to determine the detector counting efficiency. Selenium-79 was not detected in the hot cell process blank for the fusion or in laboratory blanks prepared with each batch of samples. The Se-79 activities measured in the supernatant and solid resulted in 1% and 4% RPD respectively. The centrifuged wet solid duplicate sample was also run in replicate by the radioanalytical laboratory and resulted in 49% higher Se-79 concentration (40% RPD). This discrepancy is attributable to the relatively low radiochemical yield of the replicate sample and may also be linked to the general variability of the method near the MDL.

5.3.7 Carbon-14

Carbon-14 was isolated from direct supernatant sample aliquots and wet solids using hot acidic persulfate oxidation and extraction in a Coulometrics Carbon Analyzer Acidification unit followed by CO₂ collection in a trap according to procedure PNL-ALO-482. The C-14 was then measured by liquid scintillation counting according to procedure PNL-ALO-474. Both the supernatant and solid sample duplicates showed good agreement with 0% and 13% RPDs, respectively. The blank spike showed good recovery of C-14 at 96%, and matrix spikes showed good recoveries at 88% and 97%, for the solids and supernatants, respectively. Carbon-14 was not detected in the blank samples and there was no evidence of C-14 carry-over into the samples or standards during the combustion process. NIST-traceable C-14 standards were used to determine the net combustion and collection efficiency for the procedure, as well as the detector counting efficiency.

5.4 Analysis by ICP/MS– Tables 3.3 and 3.4

Selected radionuclide and metal analyses were performed by ICP/MS per procedures PNL-ALO-280, 281, and 282. The radionuclide and metal analytes of interest were analyzed on both the acid digestions and water dilutions of the supernatants and on the KOH-KNO₃ fusion preparation. The supernatant water dilution/analysis was evaluated relative to the acid digestion/analysis with respect to iodine. It is chemically feasible to sustain losses of I by volatilization (as HI) during the acid digestion preparation. The potential for the loss is eliminated with the straight sample dilution. The Na₂O₂-NaOH-HCl fusion preparation was used solely for the analysis of platinum. The radionuclide concentrations are presented in both terms of mass (μg) and activity (μCi).

Off-line interference corrections were required for I-129 (for xenon correction). Uranium isotopic analyses were conducted on sample fractions processed through TRU-Resin to remove polyatomic ion interferences. Uranium isotope ratios were then multiplied by the total uranium concentration (determined by summing the U-238 and U-235 concentrations) to report isotopic concentrations. Similarly Pu was purified using TEVA Resin. Plutonium-242 was used as an internal tracer to correct for yield losses and for instrument drift.

The ICP/MS was calibrated relative to isotope-specific standards in all cases except for Pu-240. In this case, the Pu-240 concentration was determined by comparison of its response to the calibration curve for Pu-239. Thus, the Pu-240 concentration results should be considered semi-quantitative.

The analyte RPDs were calculated from duplicate sample results where the individual error was <15%, 2-σ. The acid digest preparations of the duplicate supernatant samples were within the 20% acceptance criterion, except for U-234 where the RPD was 45%. The precision between the sample and duplicate from the water dilution were generally >20% for U isotopes. Notably Tc-99, I-129 and I-127, Cs, and Rb were <20% RPD and are chemically stable in dilute caustic solution. The RPDs for the KOH-KNO₃ fusion were within acceptance criteria. The platinum RPD for the Na₂O₂-NaOH-HCl fusion of solids was 40%.

Preparation matrix spikes or blank spikes for ICP/MS were not prepared. However, post matrix spikes were prepared and analyzed at the ICP/MS workstation. The post spike recoveries ranged from 79% to 125%, within the acceptance criteria of 75% to 125%.

In general, the results of the continuing calibration verification (CCV) check standard were within acceptance criteria. However, one CCV result exceeded the acceptance criteria as follows: rubidium in the water dilution run series--84%, technetium in the fusion run series--113%, and platinum in the Na₂O₂-NaOH-HCl fusion--89%. The second CCV from each series did meet the acceptance criteria. The

potential bias introduced by the failure of some of the check standards is considered insignificant, since most of the failures were only marginally outside the acceptance window.

The reported Tc-99 results assume that the ruthenium present is exclusively fission-product ruthenium, and therefore does not have an isotope at mass 99. The calculated results assume that everything observed at mass 99 is due to technetium. The observed ruthenium mass spectra are not typical of natural ruthenium and are consistent with spectra observed in previous tank waste analyses. Therefore, the assumption that observed mass 99 is primarily technetium should be valid.

The water dilution blank preparation appears to have a significant praseodymium contamination, containing about the same concentration found in the samples. The acid digestion blank result does not demonstrate this contamination and should be used instead. The rubidium and Pu-239 process blank results from the same sample preparation also show evidence of contamination representing 12% and 10%, respectively, of the sample concentration. The fusion preparation blank also exhibits contamination relative to the sample concentration for several analytes. The preparation blank contains Rb at 65% sample concentration, Pt at 38%, Cs-133 at 20%, and I-127 at 6%.

For the water soluble analytes, (I, Tc, Rb and Cs), comparison of the acid digestion and water dilution preparations is generally good. The ^{129}I concentration agrees well between the acid digestion (1.12 $\mu\text{g/mL}$) and the water dilution (1.15 $\mu\text{g/mL}$) samples. The ^{127}I should agree equally well, however, the water dilution value (0.72 $\mu\text{g/mL}$) is 34% lower than that from the acid digestion (1.08 $\mu\text{g/mL}$). This indicates volatilization of I under the acid digestion processing conditions was not significant. Uranium and plutonium showed greater variability in the water dilution as evidenced by higher RPDs between duplicates. For these analytes, the acid digestion method is considered to produce more reliable results.

The ICP/MS results for Pu-239+240 wet solids fusion preparation compare very favorably to the results obtained by AEA. The supernatant Pu-239+240 concentrations differ by 53%, much greater than the error associated with the two methods. Both methods utilized Pu-242 tracer to correct for yield biases. However, it appears the ICP/MS method is biased high or the radiochemistry method is biased low, or possibly a combination of both. The ICP/MS results for total uranium (i.e., U-238+235) compare well with the results obtained by kinetic phosphorescence and ICP. In general, the average results between the methods vary by less than 10%, which is considered very good agreement for a method-to-method comparison. Table 5.1 presents the comparison for these results. The ICP/MS cannot distinguish between U-238 and Pu-238. However, since the Pu-238 concentration (in $\mu\text{g/g}$ or $\mu\text{g/mL}$) is negligible, the ICP/MS response at mass 238 is attributed solely to U-238.

Table 5.1. Comparison of ICP/MS to Other Methods for Pu-239+240 and Total U

<i>Tank Material Matrix Dissolution</i>		C-104 As-Received	
		Supernatant	Centrifuged Wet Solids
		Acid Digest	KOH-KNO₃ fusion
Analyte	Method	μCi/mL	μCi/g
Plutonium 239+240	ICP/MS	2.79E-3	2.81E+0
	Radiochemistry (AEA)	1.82E-3	2.93E+0
	Difference from ICP/MS	53%	4%
Analyte	Method	μg/mL	μg/g
Total Uranium	ICP/MS ⁽²⁾	34	21,200
	Kinetic Phosphorescence	30	19,500
	Difference from ICP/MS	12%	9%
Total Uranium	ICP/MS ⁽²⁾	34	21,200
	ICP	<100	21,300
	Difference from ICP/MS	n/a	0.5%
(1) All results are average of sample and duplicate results from Table 3.1 to Table 3.3			
(2) ICP/MS Total Uranium = sum of U-238 and U-235			

5.5 TOC/TIC Analysis by Hot Persulfate/Coulometry – Table 3.5

The analyses of the C-104 as-received supernatant and solids samples were performed by the hot persulfate wet oxidation method, PNL-ALO-381 and the furnace oxidation method, PNL-ALO-380. The hot persulfate method uses acid decomposition for total inorganic carbon (TIC) and acidic potassium persulfate oxidation at 92-95°C for TOC (total organic carbon), all on the same weighed sample, with total carbon (TC) being the sum of the TIC and TOC. The furnace oxidation method determines TC by oxidizing all forms of carbon (i.e., inorganic and organic) in oxygen at 1000 °C. Per the analytical method, the TOC, TIC, and TC results are bias-corrected for average percent recovery of system calibration standards and are also corrected for contribution from the system blank.

The QC for the methods involves system calibration blanks, system calibration standards, sample duplicates, and matrix spikes. The QC system calibration standards were all within acceptance criteria, except for the hot persulfate TOC, which demonstrated an average recovery of 88%. Although this recovery is slightly lower than the acceptance criteria, the recovery results were consistent. Because the final results are corrected for the average organic carbon recovery, the slightly low standard recovery is not expected to bias the results. The calibration blanks run at the beginning, middle, and end of the analysis runs were acceptable and the standard deviations for the TIC and TOC blanks were at or below the historical pooled standard deviation used to establish the MDLs.

Under normal conditions, the furnace method and hot persulfate method should provide equivalent TC results. The supernatant results demonstrated good agreement between the furnace and hot persulfate methods, with the average hot persulfate TC being 14,900 μg/ml and the furnace TC being 14,500 μg/ml.

The wet centrifuged solids TC from the furnace method is nearly twice the level measured from the hot persulfate method; i.e., approximately 23,000 versus 13,000 µg/g, respectively. The disagreement between the furnace and hot persulfate TC for the centrifuged solids strongly suggests that the carbon compounds (most likely organic carbon compounds) are not well decomposed by the hot persulfate method.

The accuracy of the carbon measurements can be estimated by the recovery results from the matrix spike. All spike recoveries were within the acceptance criteria of 75% to 125%. However, the matrix spike for the hot persulfate method demonstrated somewhat low recoveries for the solids; i.e., from 79% to 87% for TIC, TOC, and TC. Although these recoveries are within the acceptance criteria, the low recoveries again indicate some difficulties either in subsampling the solids sample or in ability of the hot persulfate method to produce consistent results from the specific sample matrix.

5.6 Anion Analysis by IC – Table 3.5

The as-received supernatant samples were diluted 10-fold to 2000-fold at the ion chromatography (IC) workstation to ensure that all anions of interest were within the calibration range. The wet solid samples were leached using procedure PNL-ALO-103 in the SAL and further diluted at the IC workstation resulting in a 10-fold to 2000-fold dilution. The supernatant and solid leach solutions were analyzed by IC for inorganic anions per procedure PNL-ALO-212.

Although oxalate is an analyte of interest for the as-received material, it is measured by organic IC analysis and reported as an organic anion in the C-104 tank waste organic report (WTP-RPT-008 [draft]). The oxalate results reported in Table 3.4 from the inorganic IC analysis are for information only. The reported fluoride results must be used with caution. For the IC column and parameters used, fluoride cannot be isolated from acetate and formate. It is unlikely the levels of fluoride quantified are present in the C-104 tank waste, and since both acetate and formate could be present, the fluoride results should be used with reservation. Both acetic acid and formic acid were characterized by organic IC analysis and are reported as organic anions in the C-104 organic analysis report.

Matrix spikes were prepared at the IC workstation following the dilution at the IC workstation on the solid leachate sub-sample. The matrix spike demonstrated recoveries between 100% and 108%, well within the acceptance criteria of 75% to 125%. The blank spike recoveries were within the 90% to 110% acceptance criteria, except for nitrate (78%). Other standards analyzed during the analytical run demonstrated good nitrate recovery and the poor nitrate recovery from the blank spike is not considered to affect the reported results. The analytical system blanks, as well as the dilution blanks and leach processing blank, were all within acceptance criteria except for chloride. The leaching blank chloride concentration represents as high as 19% of the solids chloride concentration, exceeding the <5% criterion. However, the blank chloride concentration was virtually at the instrument detection limit and has an associated uncertainty of 100%.

For both the solid leachates and the supernatant samples, the RPD was 16% or less for all anions, with the exception of phosphate on the solids (RPD = 115%). The effectiveness of the water leach to maintain phosphate in solution is considered the primary cause of the large discrepancy in the phosphate results. Although sample heterogeneity cannot be ruled out as a cause for the large discrepancy, the fact the other anions were in close agreement diminish this hypothesis. The phosphorous concentration determined by ICP analysis of the KOH-KNO₃ fusion also resulted in a high RPD (55%). The phosphorous concentration determined from the acid dissolutions of the solids was a small fraction relative to the fusion preparation. Again this points to a solubility problem and a possible heterogeneity problem. Within the range defined by the IC phosphate results, the ICP phosphorous results are consistent with the IC results.

As required by the governing QA Plan, mid-range verification standards were analyzed at the beginning of the analysis, after every 10 injections, and at the end of the analysis. For all reported results, all analytes of interest were recovered within the acceptance criteria of 90% to 110% for the verification standard. However, due to column degradation caused by a sample from another ASR, one verification standard produced low recoveries (i.e., 80% to 90%). Column performance was recovered following flushing by the eluant. The reported results are considered valid.

5.7 Mercury Analysis by CVAA – Table 3.5

The supernatant and solids samples were analyzed by cold vapor atomic absorption spectrophotometry for inorganic mercury. Approximately 0.10 g mass of wet centrifuged solid samples and approximately 0.5 ml (0.57 g weight) of supernatant liquid samples were transferred to glass digestion vessels by the SAL. Samples were processed and diluted to a final volume of 25.5 ml to 27 ml per procedure PNL-ALO-131. The digestion procedure requires organic matrix destruction using potassium permanganate. The supernatant samples were processed with 0.5 g additional potassium permanganate and the centrifuged solids were processed with 1 g additional potassium permanganate. The increased amount of potassium permanganate was used to ensure complete oxidation of potential organic material in the samples. Quality control was assessed with process blanks, blank-spike and matrix-spiked samples that were treated similarly with increased potassium permanganate addition. Following digestion, the samples were analyzed according to PNL-ALO-201. Analytical dilution of 2 to 51-fold was necessary for some samples.

The sample RPDs were within the acceptance criterion of $\leq 20\%$. The supernatant process blank result was $<5\%$ of the sample concentration; the wet solids process blank result was less than the detection limit. The blank spikes and supernatant matrix spike recovered 96% to 108%, well within the acceptance criteria. The Hg spiked in the wet solids matrix was insufficient relative to the sample Hg concentration and the difference could not be measured. The LCS for the solids and liquids recovered 100% to 113%, well within the acceptance criteria. Three mid-range instrument calibration verification checks recovered 96% to 105%.

5.8 Ammonia Analysis by ISE – Table 3.5

Ammonia was measured directly in the supernatant and in water leachates of the wet centrifuged solids using an ammonia ion specific electrode (ISE). The analysis was performed per procedure PNL-ALO-226. The method of standard additions was used to determine the ammonia concentrations by first taking a direct reading and then adding a known standard to each sample. Duplicate results are in good agreement for both the liquid and solid samples with RPD values of 10% and 9%, respectively. The method detection limit was estimated at 0.2 $\mu\text{g/ml}$ for the liquids. The process blank prepared in the SAL with the water leach sample preparation of the solids shows significant ammonia contamination at about 30% of the concentration in the sample. It should be noted that the direct sample measurements for the wet solids (before addition of the standards) were below the lowest ammonia standard at 1.E-6 $\mu\text{g/ml}$. Hence, the measurements for the wet solids are very close to the estimated detection limit of about 0.8 $\mu\text{g/g}$, based on half the concentration of our lowest standard.

5.9 Total Cyanide Analysis by Distillation/Colorimetry – Table 3.5

Cyanide (CN) was measured in the C-104 supernatant and centrifuged wet solids after distillation by a colorimetric method using an autoanalyzer. Because of the high sample dose rate, the SAL aliquoted small sample aliquots directly into distillation tubes. These were then transferred to the CN workstation. Sulfamic acid was added to the samples prior to distillation to ensure minimal interference from the high nitrate concentration present in the samples. The samples were distilled according to procedure PNL-ALO-287. Cyanide was measured in the distillates according to procedure PNL-ALO-289 using the

Lachat QuickChem AE Autoanalyzer. Data quality is assessed through the use of sample duplicates, process blanks, blank spikes, matrix spikes, and calibration verification standards.

The RPD measured in both matrices (i.e., 14% for supernatant and 13% for solids) was within the acceptance criterion of <20%. However, these RPDs are higher than typically obtained with this method. The relatively small sample sizes (0.3-g centrifuged wet solids and 0.05-mL supernatant) used to minimize personnel exposure are most likely a major contributor to the poor precision. The process blanks associated with both matrices were less than the instrument detection limit, indicating sample CN contamination was not measurable. A blank spike, used as the supernatant LCS, recovered 101%. A solid LCS was run with the wet centrifuged solids and recovered well within the certified advisory CN concentration range. The matrix spike recoveries were 94% (supernatant) and 111% (wet centrifuged solids), well within the acceptance criteria of 75% to 125%. The calibration verification standards gave recoveries of 97% to 101%, well within the acceptance criteria.

5.10 Flashpoint Determination – Table 3.5

The C-104 supernatant composite was subjected to a closed-cup flash point test using a Grabner Miniflash apparatus according to procedure PNL-ALO-234. This instrument produces a flash point test equivalent to the SW-846 Pensky-Martin closed-cup method for determining ignitability. However, the Grabner Miniflash apparatus uses only 2-mL sample sizes instead of the 50-mL sample sizes used for the typical Pensky-Martin flash point testers. The 2-mL sample size allows the testing of highly radioactive liquids in the laboratory (versus in a shielded hot cell facility). Dodecane was used as the control standard and water was also tested with the sample set.

The average C-104 flashpoint measured by the Grabner Miniflash tester at 219°F is most likely a “false flash” caused by the rapid production of steam at the boiling point of water. The C-104 supernatant composite is essentially an aqueous caustic matrix with essentially no highly volatile or low boiling point organic compounds present (as determined by various organic analyses). When water was subjected to the closed-cup flash point test, a “false flash” at approximately the same flash point (216°F) was measured. Also, the low flash point pressure (averaging 5.9 kPa in the duplicate supernatant samples) is indicative of the steam “false flash”. The “false flash” pressure of water was 6.4 kPa. An actual ignition flash point produces a much higher pressure as was evidenced by the control standard dodecane pressures (averaging 26 kPa).

Dodecane tested prior to, and following, sample analysis must produce a flash point of 184 ± 4 °F. The initial dodecane test met the acceptance criteria. The dodecane measurement immediately after the C-104 supernatant measurements failed to meet the acceptance criteria. Residual water or water vapor from the previous C-104 aqueous matrix is suspected of creating this problem. An additional dodecane test was performed following sample analysis that did meet the acceptance criteria.

5.11 Free Hydroxide and pH Analysis – Table 3.5

Analysis of free hydroxide was performed on supernatant subsamples according to procedure PNL-ALO-228. The samples were titrated with normalized hydrochloric acid solution. Quality control check standards were prepared from recently standardized sodium hydroxide solution. Duplicate analyses of the QC check standard resulted in measured hydroxide concentrations within 0.7% of the true hydroxide concentration.

The total hydroxide concentration of 0.81 millimoles OH per milliliter was calculated from the first equivalence point on the titration curve, pH 7.64 and pH 8.16 for the sample and duplicate with a RPD of 0.4%. To verify that this equivalence point is associated with hydroxide, the supernatant was spiked with sodium hydroxide standard and titrated. The matrix spike first equivalence point was pH 7.87,

corresponding to the pH equivalence of the unspiked samples. Recovery of the matrix spike (first equivalence point) was 98%.

The pH measurement was performed directly on one supernatant aliquot per procedure PNL-ALO-225. Because the tank waste was expected to be outside of the calibration buffer range of pH 4 and pH 10, a standard NaOH solution providing pH 13.07 was also determined. The standard resulted in pH 12.83, within 0.24 pH units of true. The C-104 supernatant was determined to be pH 12.1

6.0 Method Detection Limits & Minimum Reportable Quantities

The MDLs for specific analytes of interest vary significantly based on the procedures used for preparing the samples for analysis (e.g., acid digestion, fusion), the sample size taken for the analysis, required dilutions for ALARA safety considerations, and the magnitude of interfering analytes. For the work presented in this report, effort was made to optimize the sample preparation parameters (e.g., minimal dilutions). Table 6.1 provides a direct comparison of each analyte MDL to the target minimum reportable quantity (MRQ) provided by BNFL. The MDLs are nominal values based on average sample sizes used for analysis. The MDLs are presented for both liquids and solids. Where solids are prepared by both acid digestion and fusion, both the acid digestion MDL and fusion MDL are provided for comparison. The MDLs that are shaded and boxed exceed the BNFL requested MRQs.

As is evident from the Table 6.1, some analytes of interest have not been measured at the target MRQ. Many of the high MDLs are within a factor of five from the target MRQ. These include the supernatant potassium, fluoride, Co-60, and Eu154 and the wet centrifuged solids cobalt molybdenum zinc, chloride, nitrate, TIC, TOC, Eu-155, Pu-238, and U-238. Optimization of sample size and analytical dilutions may help achieve the target MRQs. The sample size increase must always be balanced with the corresponding additional dose to the analyst at the workstation.

Given the sample matrix and processing conditions, the Am-241 by GEA analysis and Pu-241 (in solids) MRQs will probably be unattainable. The Am-241 photopeak is fairly low energy at 59 keV and background continuum from higher energy gamma emitters will adversely affect the Am-241 detection limit. Thus the higher the Cs-137 concentration (as well as other gamma emitters), the higher the Am-241 detection limit will be. However, the Am-241 analysis by AEA did meet the MRQ by two orders of magnitude. It is unlikely that any preparative technique will allow the quantification of Pu-241 in a typical tank waste at the 1.2 pCi/g level unless very large sample volumes can be prepared for counting.

It is also unlikely that the MRQ of 3 µg/mL chloride can be achieved consistently on tank waste supernatants by using IC as the analysis method. The presence of other anions at high concentrations (e.g., nitrate and nitrite) requires significant dilution of the samples prior to analysis to prevent IC column overloading. This required dilution and the presence of interfering organic anions significantly limit the chloride MDL.

Table 6.1 Comparison of Measurement MDLs to Target MRQs

Analyte	Liquids		Solids			Radionuclide	Liquids		Solids	
	MDL (1)	BNFL MRQ	MDL (1)	MDL (Fusion)	BNFL MRQ		MDL (1)	BNFL MRQ	MDL (Fusion)	BNFL MRQ
	μg/mL	μg/mL	μg/g	μg/g	μg/g		μCi/mL	μCi/mL	μCi/g	μCi/g
Ag	1.2E+0	1.75E+1	7.1E+0	1.1E+1	9.00E+2	H-3	1E-4	n/a	4E-4	n/a
Al	3.0E+0	7.50E+1	1.7E+1	2.7E+1	3.30E+2	C-14	3.7E-7	n/a	2.2E-6	n/a
As	1.2E+1	NMRQ	7.1E+1	1.14E+2	NMRQ	Co-60 (GEA)	3.8E-3	2.10E-3	2.9E-3	1.20E-2
B	2.5E+0	NMRQ	1.4E+1	2.3E+1	NMRQ	Se-79	2E-6	NMRQ	7E-4	NMRQ
Ba	5.0E-1	7.80E+1	2.9E+0	4.6E+0	6.00E+2	Sr-90	2E-3	1.50E-1	4.0E+0	7.01E+1
Be	5.0E-1	NMRQ	2.9E+0	4.6E+0	NMRQ	Nb-94 (GEA)	2E-3	NMRQ	1.3E-2	NMRQ
Bi	4.9E+0	NMRQ	2.9E+1	4.6E+1	NMRQ	Ru-106/Rh-106 (GEA)	3E-5	NMRQ	1.5E-1	NMRQ
Ca	1.2E+1	1.50E+2	7.1E+1	1.1E+2	1.80E+2	Sb-125 (GEA)	6E-2	NMRQ	9.5E-2	NMRQ
Cd	7.4E-1	7.50E+0	4.3E+0	6.9E+0	1.10E+1	Sn-126 (GEA)	2E-2	NMRQ	3.1E-2	NMRQ
Co	2.5E+0	3.00E+1	1.4E+1	2.3E+1	3.00E+0	Cs-134 (GEA)	2E-3	NMRQ	7.1E-3	NMRQ
Cr	1.0E+0	1.50E+1	5.7E+0	9.2E+0	1.20E+2	Cs-137 (GEA)	7.9E-3	9.00E+0	1.5E-2	6.00E-2
Cu	1.2E+0	1.70E+1	7.1E+0	1.1E+1	1.80E+1	Eu-154 (GEA)	3E-3	2.00E-3	8.9E-3	6.00E-2
Fe	1.2E+0	1.50E+2	7.1E+0	1.1E+1	1.40E+2	Eu-155 (GEA)	4E-2	9.00E-2	7.0E-2	6.00E-2
K	1.0E+2	7.50E+1	5.7E+2	9.2E+2	1.50E+3	Pu-238	2E-6	9.60E-3	7.1E-5	6.00E-5
La	2.5E+0	3.50E+1	1.4E+1	2.3E+1	6.00E+1	Pu-239+Pu-240	2E-6	NMRQ	3.66E-5	NMRQ
Li	1.5E+0	NMRQ	8.6E+0	1.4E+1	NMRQ	Pu-241	1E-4	9.60E-3	3.4E-1	1.20E-6
Mg	4.9E+0	1.50E+2	2.9E+1	4.6E+1	5.40E+2	Am-241(GEA)	4E-2	7.20E-4	7.7E-2	1.20E-3
Mn	2.5E+0	1.50E+2	1.4E+1	2.3E+1	3.00E+2	Am-241 (AEA)	4E-6	7.20E-4	1.1E-4	1.20E-3
Mo	2.5E+0	9.00E+1	1.4E+1	2.3E+1	6.00E+0	Cm-242	5E-7	NMRQ	2.2E-5	NMRQ
Na	7.4E+0	7.50E+1	4.3E+1	6.9E+1	1.50E+2	Cm-243+Cm-244	2E-6	1.50E-1	2.2E-5	6.00E-5
Ni	1.5E+0	3.00E+1	8.6E+0	1.4E+1	1.60E+2	Beta	2.1E-4	NMRQ	2.5E-1	NMRQ
P	4.9E+0	NMRQ	2.9E+1	4.6E+1	NMRQ	Alpha	1E-4	2.30E-1	7.1E-3	1.00E-3
Pb	4.9E+0	3.00E+2	2.9E+1	4.6E+1	6.00E+2	Sum Alpha	1E-5	NMRQ	2.6E-4	NMRQ
Pd	3.7E+1	NMRQ	2.14E+2	3.4E+2	NMRQ	Radionuclide	μCi/mL	μCi/mL	μg/g	μg/g
Rh	1.5E+1	NMRQ	8.6E+1	1.4E+2	NMRQ	Tc-99 (ICP/MS)	3.4E-5	1.50E-3	2E-3	6.00E+0
Sb	2.5E+1	NMRQ	1.4E+2	2.3E+2	NMRQ	I-129 (ICP/MS)	81E-6	1.10E-3	2.4E-4	3.00E+1
Se	1.2E+1	NMRQ	7.1E+1	1.1E+2	NMRQ	U-233 (ICP/MS)	2E-5	1.80E-3	7E-3	6.00E+0
Si	2.5E+1	1.70E+2	1.4E+2	2.3E+2	3.00E+3	U-234 (ICP/MS)	6E-6	NMRQ	7E-7	NMRQ
Sn	7.4E+1	NMRQ	4.3E+2	6.9E+2	NMRQ	U-235 (ICP/MS)	4E-8	3.30E-6	2E-5	6.00E+0
Ti	1.2E+0	1.70E+1	7.1E+0	1.1E+1	1.50E+2	U-236 (ICP/MS)	8E-8	NMRQ	8E-5	NMRQ
Tl	2.5E+1	NMRQ	1.4E+2	2.3E+2	NMRQ	U-238 (ICP/MS)	2E-7	5.00E-7	3.5E-7	6.00E+0
U	9.9E+1	6.00E+2	5.7E+2	9.1E+2	6.00E+2	Np-237(ICP/MS)	2.4E-6	2.70E-2	3E-4	1.80E+0
Total U ⁽²⁾	5E-3	6.00E+2	n/a	4E-1	6.00E+2	Pu-239 (ICP/MS)	2.5E-5	9.60E-3	2.6E-2	6.00E+0
V	2.5E+0	NMRQ	1.4E+1	2.3E+1	NMRQ	Pu-240 (ICP/MS)	1.3E-4	NMRQ	3.8E-2	NMRQ
W	9.9E+1	NMRQ	5.7E+2	9.1E+2	NMRQ	Analyte	μg/mL	μg/mL	μg/g	μg/g
Y	2.5E+0	NMRQ	1.4E+1	2.3E+1	NMRQ	Cs(ICP/MS)	4E-3	NMRQ	3E-1	NMRQ
Zn	2.5E+0	1.65E+1	1.4E+1	2.3E+1	6.00E+0	I(ICP/MS)	2E-3	NMRQ	6E-1	NMRQ
Zr	2.5E+0	NMRQ	1.4E+1	2.3E+1	6.00E+2	Pr(ICP/MS)	1E-3	NMRQ	4E-1	NMRQ
						Pt(ICP/MS)	n/a	NMRQ		NMRQ
Br	2.5E+2	NMRQ	2.5E+2	n/a	NMRQ	Rb(ICP/MS)	6E-4	NMRQ	5E-1	NMRQ
Cl	2.5E+2	3.00E+0	2.5E+2	n/a	2.30E+2	Ta(ICP/MS)	2E-3	NMRQ	1.2E-1	NMRQ
F	2.5E+2	1.50E+2	2.5E+2	n/a	7.50E+3	OH (free, total)	1.0E+2	1.70E+2	n/a	n/a
NO ₂	5.0E+2	NMRQ	5.0E+2	n/a	NMRQ	Hg	1.0E-2	2.00E+0	5E-2	1.50E+0
NO ₃	5.0E+2	3.00E+3	5.0E+2	n/a	4.50E+2	CN	2.5E-1	NMRQ	2E-1	NMRQ
PO ₄	5.0E+2	2.50E+3	5.0E+2	n/a	6.00E+2	← PO ₄ solids MDL and MRQ as P ← SO ₄ solids MDL and MRQ as S (1) Acid Digestion, Water Leach, or Direct Analysis, as applicable (2) Total uranium by kinetic phosphorescence (3) TC by the furnace oxidation method NMRQ: no MRQ provided; n/a: not analyzed				
SO ₄	5.0E+2	2.30E+3	5.0E+2	n/a	1.20E+3					
C ₂ O ₄	5.0E+2	NMRQ	5.0E+2	n/a	NMRQ					
TIC	7.0E+1	1.50E+2	1.2E+2	n/a	3.00E+1					
TOC	2.0E+2	1.50E+3	3.5E+2	n/a	6.00E+1					
TC ⁽³⁾	1.8E+2	NMRQ	5.0E+2	n/a	NMRQ	Note: Shaded and boxed MDLs exceed the target MRO				
NH ₃	0.2	NMRQ	0.8	n/a	NMRQ					

APPENDIX A

Appendix A: Test Plan and ASR

APPENDIX B

Appendix B: Analytical Data

Distribution

No. of Copies		No. of Copies	
OFFSITE		ONSITE	
2	DOE/Office of Scientific and Technical Information	4	<u>CH2M Hill Hanford Group</u> M. E. Johnson (4) H4-10 A. N. Thompson H4-02
1	Harold Sturm Savannah River Technology Center PO Box 616, Road 1 Building 773-A, Room A-233 Aiken, SC 29808	24	<u>Pacific Northwest National Laboratory</u> C. J. Barinaga P7-07 J. P. Bramson P8-08 K. J. Carson P7-25 J. R. DesChane P7-25 O. T. Farmer P8-08 S. K. Fiskum P7-22 L. R. Greenwood P7-22 F. V. Hoopes P7-22 R. T. Ratner P7-22 D. R. Sanders P7-22 M. J. Steele P7-22 R. T. Steele P7-22 C. Z. Soderquist P7-22 R. G. Swoboda P7-22 K. K. Thomas P7-22 T. L. Trang-Le P7-22 M. W. Urie P7-22 J. J. Wagner P7-22 Project File P7-28 Technical Report Files (5) K1-06
1	Paul Townson BNFL, Inc 3000 George Washington Way Richland, WA 99352		
1	Ed Higginbotham BNFL, Inc 3000 George Washington Way Richland, WA 99352		

APPENDIX A

Appendix A: Test Plan and ASR



902 Battelle Boulevard
P.O. Box 999
Richland, Washington 99352
Telephone (509) 376-1982
Email eugene.morrey@pnl.gov
Fax (509) 376-7127

January 28, 2000

Mr. Michael Johnson
Contracting Officer's Technical Representative
3000 George Washington Way
Mailstop: BN-FL
Richland, WA 99352

29953-114

Dear Mr. Johnson:

**TRANSMITTAL OF FINAL TEST PLAN "INORGANIC, ORGANIC AND
RADIOCHEMICAL CHARACTERIZATION OF C-104 HLW SAMPLE"
BNFL-29953-030, REV 0.**

Reference: 1) "Quality Assurance Project Plan for Testing Programs: Savannah River
Technology Center (SRTC) and Pacific Northwest National Laboratory
(PNNL), QP-W375-EN00002, Rev. 0, dated June 7, 1999.

Enclosed is a fully signed test plan of BNFL-29953-030, "Inorganic, Organic and Radiochemical Characterization of C-104 HLW Sample." The test plan details the regulatory characterization analyses to be conducted on material from Tank C-104. The test plan does not include all analyses identified in Appendix B of the recently distributed "Quality Assurance Project Plan for Testing Programs, dated June 7, 1999 (Reference 1). The electronic copy of the test plan was transmitted to you on 1/28/00 by Chrissy Charron.

Battelle's deviation from Appendix B of the referenced QA Plan is the same as those agreed to for the analysis of materials from Tanks AN-107 and AW-101. The exceptions include deletion of specific analytical tests, deletion of a few organic analytes of interest, and deletion of TCLP leach test and analysis. The Exception Section of the test plan provides further details. No costs were included in the recent Baseline Change Request (BCR) to cover the deleted analyses or analytes.

Technical matters shall be referred to Mike Urie, 376-9454.

PNNL Test Plan

Document No.: BNFL-29953-030
Rev. No.: 0

Title: Inorganic, Organic and Radiochemical Characterization of C-104 HLW Sample

Work Location:
325/SFO, 325/general labs; 329/general labs

Page 1 of 9

Author: Michael W. Urie

Effective Date: Upon final signature
Supersedes Date: New

Use Category Identification: Reference

Identified Hazards:

- ☐ Radiological
- ☐ Hazardous Materials
- ☐ Physical Hazards
- ☐ Hazardous Environment
- ☐ Other:

Required Reviewers:

- | | |
|--|---|
| <input checked="" type="checkbox"/> Technical Reviewer | <input checked="" type="checkbox"/> Project Manager |
| <input type="checkbox"/> Building Manager | <input checked="" type="checkbox"/> RPL Manager |
| <input type="checkbox"/> Radiological Control | <input checked="" type="checkbox"/> SFO Manager |
| <input type="checkbox"/> ES&H | <input checked="" type="checkbox"/> AO&AM Manager |
| <input checked="" type="checkbox"/> Quality Engineer | |

Are One-Time Modifications Allowed to this Procedure?

☒ Yes ☐ No

NOTE: If Yes, then modifications are not anticipated to impact safety. For documentation requirements of a modification see SBMS or the controlling Project QA Plan as appropriate.

On-The Job Training Required? ☐ Yes or ☒ No

FOR REVISIONS:

Is retraining to this procedure required? ☐ Yes ☒ No

Does the OJT package associated with this procedure require revision to reflect procedure changes? ☐ Yes ☒ No

Approval

Signature

Date

Author Michael W. Urie 12-20-99

Technical Reviewer Dee A. Kling 12-20-99

RPL Manager LO Casagga 11/3/2000

SFO Manager Rich A. Hale for RE THORNTON 12/20/99

Project Manager Eugene J. Mooney 12/27/99

AO&AM Manager Steven C. John 1/13/00

Quality Engineer Taffey Almeida 1-11-2000


BNFL Michael Johnson 1/19/2000

Mr. Michael Johnson

January 28, 2000

Page 2

Sincerely,

A handwritten signature in cursive script that reads "Eugene V. Morrey". The signature is written in dark ink and is positioned above the printed name.

Eugene V. Morrey
Project Manager

EVM:c²

Enclosure

Cc: Mike Urie, Battelle (w/attachment)
BNFL Project File/LB

Integrity of the sub-samples and processed samples distributed throughout the laboratory will be maintained by chain-of-custody documentation. Changes to this Test Plan (initialed markups are allowed) shall be approved by the Task Manager.

Exceptions

Based on the history of the C-104 sample, exceptions are being taken to the preservation, temperature control, and hold time requirements specified by SW-846 protocols. The samples are not preserved and no refrigeration of the samples is practical at this time. Hold times, based on sampling dates, have been exceeded prior to sample receipt and starting the analytical characterization.

In some cases, sample sizes based on SW-846 protocols are not attainable due to limited sample quantity. A limited quantity of material is available for the characterization analyses, and to the extent possible, the sample material is allocated based on the PNNL method sensitivity and ability to meet Minimum Reportable Quantities (MRQ). The sample volumes and weights used for analyses may be less than the recommended values in SW-846. The effect of small sample size on detection limits and reproducibility will be discussed in the final report. Specifically, the quantity of supernatant available for analysis is insufficient to ensure that all the MRQs are met. All the supernatant from the C-104 "as received" material is targeted to support the regulatory analyses, including inorganic, radiochemical, and organic analytes of interest.

Due to the limited sample quantity, deviations from SW-846 preparation methods may be necessary (e.g., modification to organic extraction procedure). Per the QA Planning Subject Area Exhibit, modifications (e.g., single organic extraction protocol) require Task Leader approval prior to performing the analysis. Formal method qualification of minor modifications will not be performed, but the modification will be validated by the use of duplicate, matrix spikes and surrogates. Modifications, as well as minor deviations to procedures or SW-846 protocols that do not effect data quality, will be documented in the final report.

Per discussion with WDOE and BNFL, certain analyses included in the Battelle Proposal No. 29274/30406 (for AN-107, AW-101, and C-104 tank waste materials) are not being performed, specifically, Total Oil and Grease, Sulfide, Iodide, Nitrogen, Corrosion Test, Reactive Cyanide, Reactive Sulfide, and ZHE for VOA. Also, three organic analytes (ammonium perfluorooctanoate, oxirane, and picric acid) are being omitted from the organic analysis analyte list following discussions with BNFL and WDOE. Also, per letter communication from BNFL, no TCLP extractions of the solids are being conducted for either inorganic or organic constituents.

Based on radiological dose considerations, the analytical samples may be diluted to reduce the dose to laboratory staff. This may significantly impact the ability to meet the MRQs for some analytes.

Work Instructions

A simple flowchart for the sub-sampling activity is provided in Figure 1. The analysis methods are contained in Appendix A of the Battelle Proposal No. 29274/30406 and are not duplicated in this Test Plan. Analytical work is either initiated by a standard Analytical Service Request that will identify each test to be performed on the various samples and sub-samples or through the implementation of an analysis-specific test plan.

Applicability

This Test Plan describes work to be performed under Task 5.0, Double Shell Tank Analytical Support Change No. 1, for tank wastes from C-104. A composite generated from Test Plan TP-29953-031, "C-104 Sample Compositing", provide the starting material for the inorganic, organic, and radiochemical characterization of the "as received" tank waste material. Per TP-29953-031, two bottles containing approximately 340 grams of slurry and one jar containing approximately 175 grams of decanted supernatant are allocated to support the "as received" characterization analysis. The representative slurry and supernatant sub-samples are extracted from the C-104 HLW composite sample in the High Level Radiation Facility and transferred to the Shielded Analytical Laboratory for analytical sub-sampling, digestion, extraction, and distribution for analysis.

The characterization of the "as received" tank waste materials is conducted to provide key characterization information for processing, as well as to provide limited information for the permitting activities. This Test Plan covers the sub-sampling and processing of analytical samples, and the inorganic, organic and radiochemical analysis of these samples to provide both precise and accurate compositional results that meet, when possible, regulatory requirements.

This Test Plan does not cover physical properties testing on the C-104 material. Physical properties testing is to be conducted under an alternate test plan. Also, this Test Plan does not include analyses to support the dilution of the C-104 material for the CUF activities, nor does it include the inorganic and radiochemical analysis for the resulting diluted material.

Prerequisites

The majority of sub-sampling, analytical processing, and inorganic, organic and radiochemical analysis are being conducted per established and approved Battelle procedures or analytical test plans written specifically to support the work detailed in this Test Plan. The Battelle technical procedures and test plans supporting the characterization activity adhere to SW-846 protocols to the extent possible considering the limited sample volume, radiological condition, and extended target analyte list.

Hazards Assessment and Mitigation

All hazards associated with work conducted to this Test Plan have either been evaluated as part of each laboratory's Hazard Awareness Summary or as hazards unique to a specific analytical preparation or specific analytical procedures or test plans. The Hazard Awareness Summaries are posted for all laboratories in the Radiological Processing Laboratory. Hazards unique to analysis procedures are identified in the applicable procedures or test plans, and where applicable, specific Chemical Processing Permits are obtained.

Quality Control

Quality control is governed by Quality Assurance Planning Subject Area, including Exhibit "Conducting Analytical Work in Support of Regulatory Programs". The Subject Area Exhibit specifies calibration and verification requirements for analytical systems, as well as batch processing quality control samples to monitor preparation and extraction processing (i.e., blanks, duplicates, matrix spikes, matrix spike duplicates, and laboratory control standards). This Test Plan identifies those analyses for which duplicates and matrix spikes are to be performed, and the approximate quantity of sample to be used for each analysis.

Technical procedures used to support the characterization of the HLW material are either from Chemical Measurement Center Core Capabilities Manual or are project-specific procedures/test plans written specifically to support activities identified in this Test Plan. Necessary method modifications and deviations from technical procedures, test plans, or SW-846 protocols shall be documented in the final report.

1.0 Sub-Sampling and Phase Separation

The slurry and supernatant materials for "as received" characterization analysis are contained in three sample containers as described in Test Plan BNFL-29953-031. Table 1 details the container tare values and the sample masses associated with each container.

Table 1. "As Received" Sub-Samples for Characterization

Sample Material	Bottle ID	Bottle Tare (g)	Total Mass (g)	Supernatant or Slurry Mass (g)
Composite Slurry	C-104 Comp A	133.8	302.7	168.9
Composite Slurry	C-104 Comp B	133.5	303.8	170.3
Supernatant	C-104 Sup A	248.8	424.5	175.7

The composite slurry samples are to be centrifuged to provide solids and supernatant phase separation. The supernatant from the slurry samples is decanted from the "wet solids" and combined with the supernatant in C-104 Sup A. The "wet solids" remaining are to be sub-sampled immediately for weight percent solids (in duplicate) and then sub-sampled for all organic analyses, water leaching analyses (i.e., anions, tritium, and ammonia), and mercury analysis as soon as practical. Following the sub-sampling for organic analysis, water leaching analyses, and mercury analysis, the remaining solids are to be dried to allow representative sub-sampling for all other analyses to be performed at a later date (i.e., without the necessity of additional weight percent solids measurements).

2.0 Organic Analysis

Special care is taken handling both the supernatants and "wet solids" to ensure sample integrity is maintained and representative sub-samples are extracted for analysis. Organic analyses (either direct or following extraction processing) are performed on the supernatant and "wet solids" fractions, and Table 2 details the estimated sub-sampling quantities for each analysis. Appendix A identifies the organic analyte list and associates each compound with an analysis method. Organic compounds other than those listed in Appendix A that are identified during analysis will be noted in the final report.

Test plans will be used to establish the extraction protocols for each extraction process used to generate samples for organic analysis (i.e., SVOA, PCB/Pest, and/or Dioxin). In order to conserve sample material, the Matrix Spikes and Matrix Spike Duplicates may be prepared using half the sample size used for the Sample and Duplicate.

3.0 Inorganic and Radiochemistry Sub-Sampling

Where required by the analysis method, sample preparation by digestion, fusion, or leaching are performed to established and approved Battelle procedures. Table 3 details the estimated sub-sampling quantities of the supernatants, "wet solids", and "dried solids". Inorganic analytes and radionuclides of interest are included in Appendix B. Inorganic analytes and radionuclides other than those listed in Appendix A that are identified during analysis will be noted in the final report.

4.0 Analytical Service Request and Special Laboratory Instructions

This Test Plan details the sub-sampling and sample quantity requirements for processing the HLW C-104 "as received" material for inorganic, radiochemistry, and organic analysis. The Analytical Service Request form is to be used to assign unique sample identification numbers to all samples and to identify specific analyses to be performed on each sub-sample. As part of the ASR, special laboratory instructions are to be provided to the laboratory staff to ensure that all sub-sampling and preparation activities are accomplished per this Test Plan. The ASR and the special instruction require review and approval of the Task Leader and become part of the project record once approved and implemented. Changes to the ASR or special instructions also require the approval of the Task Leader.




Figure 1. Analytical Sub-Sampling Flowchart

The starting analysis material consists of two containers of representative composite slurry and one container of decanted supernatant. The supernatant from the two slurry containers and the decanted supernatant represent essentially all of the supernatant available for characterization analysis. If slurry from the two containers have to be combined prior to sub-sampling, the entire contents of the containers shall be thoroughly homogenized, by mechanical mixing, prior to extracting any sub-samples. All material sub-sampling and most analytical processing (e.g., digestions, fusions, and organic extractions) will be performed in the Shielded Analytical Laboratory due to dose levels.

Appendix A: Organic Analytes of Interest List and MRQs

CAS	Compound/Element	MRQ ug/Kg	CAS	Compound/Element	MRQ ug/Kg
PNL-ALO-346(9056)					
144-62-7	Oxalic acid	—	64-19-7	Acetic acid	—
64-18-6	Formic acid	—	79-10-7	2-Propenoic acid	—
PNL-ALO-346(3810/5021)					
121-44-8	Triethylamine	500	71-23-8	n-Propyl alcohol (1-propanol)	—
64-17-5	Ethyl alcohol	—	71-36-3	n-Butyl alcohol	900
67-56-1	Methyl alcohol (Methanol)	—	75-65-0	2-Methyl-2-propanol	—
67-63-0	2-Propyl alcohol (Isopropanol)	—	78-92-2	1-Methylpropyl alcohol (2-butanol)	—
PNL-ALO-346(8082)					
1336-36-3	Polychlorinated biphenyls (PCBs)	3300	58-89-9	gamma-BHC (Lindane)	—
309-00-2	Aldrin	22	60-57-1	Dieldrin	43
319-84-6	alpha-BHC	22	72-20-8	Endrin	43
319-85-7	beta-BHC	22	72-54-8	4,4'-DDD	—
465-73-6	Isodrin	22	76-44-8	Heptachlor	22
50-29-3	4,4'-DDT	—	8001-35-2	Toxaphene	900
PNL-ALO-345(8270C)					
100-00-5	p-Nitrochlorobenzene	—	2234-13-1	Octachloronaphthalene	—
100-25-4	1,4-Dinitrobenzene	800	50-32-8	Benzo(a)pyrene	1100
100-51-6	Benzyl alcohol	—	53-70-3	Dibenz[a,h]anthracene	2700
106-46-7	1,4-Dichlorobenzene	—	541-73-1	1,3-Dichlorobenzene	—
108-95-2	Phenol	2100	62-75-9	N-Nitroso-N,N-dimethylamine	800
110-86-1	Pyridine	5300	67-72-1	Hexachloroethane	—
1319-77-3	Cresol (1)	—	82-68-8	Pentachloronitrobenzene (PCNB)	1600
95-48-7	2-Methylphenol (Cresol isomer)	—	87-68-3	Hexachlorobutadiene	1900
106-44-5	4-Methylphenol (Cresol isomer)	—	87-86-5	Pentachlorophenol	—
117-81-7	Di-sec-octyl phthalate	—	88-85-7	2-sec-Butyl-4,6-dinitrophenol (Dinoseb)	—
117-84-0	n-diocetyl phthalate	—	91-20-3	Naphthalene	—
118-74-1	Hexachlorobenzene	3300	92-52-4	1,1'-Biphenyl	—
120-82-1	1,2,4-Trichlorobenzene	—	95-50-1	1,2-Dichlorobenzene	2000
122-39-4	N,N-Diphenylamine (2)	4300	98-86-2	Acetophenone	3200
126-73-8	Tributyl phosphate	—	98-95-3	Nitrobenzene	4700
128-37-0	2,6-Bis(tert-butyl)-4-methylphenol	—			
TEST Plan per 8290					
1746-01-6	2,3,7,8-Tetrachlorodibenzo-p-dioxin	—	57117-31-4	2,3,4,7,8-Pentachlorodibenzofuran	—
19408-74-3	1,2,3,7,8,9-Hexachlorodibenzo-p-dioxin	—	57117-41-6	1,2,3,7,8-Pentachlorodibenzofuran	—
3268-87-9	1,2,3,4,6,7,8,9-Octachlorodibenzo-p-dioxin	—	57117-44-9	1,2,3,6,7,8-Hexachlorodibenzofuran	—
35822-39-4	1,2,3,4,6,7,8-Heptachlorodibenzo-p-dioxin	—	57653-85-7	1,2,3,6,7,8-Hexachlorodibenzo-p-dioxin	—
39001-02-0	1,2,3,4,6,7,8,9-Octachlorodibenzofuran	—	60851-34-5	2,3,4,6,7,8-Hexachlorodibenzofuran	—
39227-28-6	1,2,3,4,7,8-Hexachlorodibenzo-p-dioxin	—	67562-39-4	1,2,3,4,6,7,8-Heptachlorodibenzofuran	—
40321-76-4	1,2,3,7,8-Pentachlorodibenzo-p-dioxin	—	70648-26-9	1,2,3,4,7,8-Hexachlorodibenzofuran	—
51207-31-9	2,3,7,8-Tetrachlorodibenzofuran	—	72918-21-9	1,2,3,7,8,9-Hexachlorodibenzofuran	—
55673-89-7	1,2,3,4,7,8,9-Heptachlorodibenzofuran	—			

Table 2: Organic Analytical Sub-Sampling Quantities Required ⁽¹⁾

Phase	Analysis or Procedure	Sample	Duplicate	MS/MSD	SW-846 ⁽²⁾
Wet Solids	VOA	0.5 g	0.5 g	0.5 g	5 g
	Water Leach (IC Org.)	1 g	1 g	1 g	n/a
	Extraction (SVOA)	5 g	5 g	5 g	30 g
	Extraction (PCB/Pest)	5 g	5 g	5 g	30 g
	Extraction (Dioxins)	5 g	5 g	5 g	30 g
	Sub Total	16.5 g	16.5 g	16.5 g	
Total		49.5 g			
Supernatant	VOA	2 ml	2 ml	2 ml	5 ml
	Headspace	2 ml	2 ml	2 ml	10 g
	IC (organic anions)	1 ml	1 ml	1 ml	n/a
	Extraction (SVOA)	35 ml	35 ml	35 ml	3000 ml
	Extraction (PCB/Pest)	35 ml	35 ml	35 ml	3000 ml
	Extraction (Dioxins)	10 ml	10 ml	10 ml	3000 ml
	Sub Total	85 ml	85 ml	85 ml	
Total		255 ml			

(1) Subsampling quantities are estimates; actual quantities used for the analyses will be dictated by the total quantity of material available for analysis.

(2) Typical SW-846 total volume for sample, duplicate, matrix spike, and matrix spiked duplicate extraction

Table 3: Inorganic/Radiochemistry Analytical Sub-Sampling Quantities Required ⁽¹⁾

Phase	Analysis or Procedure	Sample	Duplicate	MS	SW-846 ⁽²⁾
Dried Solids	Acid Digest (ICP, ICP/MS)	1 g	1 g	1 g	3 g
	KOH Fusion (ICP, ICP/MS, Radiochemistry)	0.3 g	0.3 g	0.3 g	n/a
	Na ₂ O ₂ Fusion (ICP, ICP/MS)	0.3 g	0.3 g	0.3 g	n/a
	Total CN	0.5 g	0.5 g	0.5 g	75 g
	TOC/TIC/TC	0.5 g	0.5 g	0.5 g	n/a
	Carbon-14	0.5 g	0.5 g	0.5 g	n/a
	Selenium-79	1 g	1 g	1 g	n/a
	Wt% Solids	3 g	3 g	n/a	n/a
Wet Solids	Water Leach (IC, Ammonia, H-3)	2 g	2 g	2 g	n/a
	Mercury	0.3 g	0.3 g	0.3 g	0.6 g
	Sub Totals	9.4 g	9.4 g	6.4 g	
Total		25.2 g			
Supernatant	Acid Digest (ICP, ICP/MS, Radiochemistry)	8 ml	8 ml	8 ml	300 ml
	Dilution (ICP/MS)	1 ml	1 ml	1 ml	n/a
	IC (inorganic anions)	1 ml	1 ml	1 ml	n/a
	Mercury	1 ml	1 ml	1 ml	300 ml
	Total CN	1 ml	1 ml	1 ml	1500 ml
	TOC/TIC/TC	1 ml	1 ml	1 ml	n/a
	Carbon-14	1 ml	1 ml	1 ml	n/a
	Ammonia	2 ml	2 ml	n/a	n/a
	Tritium (H-3)	2 ml	2 ml	2 ml	n/a
	Hydroxide (OH) & pH	5 ml	5 ml	n/a	n/a
	Flashpoint	2 ml	2 ml	n/a	150 ml
	Total Dissolved Solids	5 ml	5 ml	n/a	n/a
	Density	2 ml	2 ml	n/a	n/a
	Sub Totals	32 ml	32 ml	16 ml	
Total		80 ml			

(1) Subsampling quantities are estimates; actual quantities used for the analyses will be dictated by the total quantity of material available for analysis.

(2) Typical SW-846 total volume for sample, duplicate, and matrix spike.

Appendix B: Inorganic and Radiochemistry Analytes of Interest List

(Note: No MRQs Provided For Inorganic Analytes or Radionuclides of Interest)

ICP Analytes			
Silver	Iron	Antimony	
Aluminum	Potassium	Selenium	
Arsenic	Lanthanum ⁽¹⁾	Silicon	
Boron	Lithium	Tin	
Barium	Magnesium	Strontium ⁽¹⁾	
Beryllium	Manganese	Tellurium ⁽¹⁾	
Bismuth	Molybdenum	Thorium ⁽¹⁾	
Calcium	Sodium	Titanium ⁽¹⁾	
Cadmium	Neodymium ⁽¹⁾	Thallium	
Cerium ⁽¹⁾	Nickel	Uranium	
Cobalt	Phosphorus	Vanadium	
Chromium	Lead	Tungsten	
Copper	Palladium	Yttrium	
Dysprosium	Rhodium	Zinc	
Europium	Ruthenium ⁽¹⁾	Zirconium	
IC Analytes			
Bromide	Nitrite	Nitrate	Phosphate
Chloride	Fluoride	Sulfate	
ICP-MS Analytes			
Iodine-127	Plutonium-240	Uranium-233	
Iodine-129	Praseodymium	Uranium-234	
Neptunium-237	Rubidium	Uranium-235	
Platinum	Tantalum	Uranium-236	
Plutonium-239	Technitium-99	Uranium-238	
Radiochemistry Analytes			
Alpha, Total	Cobalt-60	Plutonium-239/240 ⁽¹⁾	
Americium-241 (AEA)	Curium-242 (AEA)	Plutonium-241	
Americium-241 (GEA) ⁽¹⁾	Curium-243/244 (AEA)	Ruthenium-106/Rhodium-106	
Beta, Total	Europium-154 (GEA)	Selenium-79	
Carbon-14	Europium-155 (GEA)	Strontium-90/Yttrium-90	
Cesium-134 (GEA)	Niobium-94 (GEA)	Tritium	
Cesium-137 (GEA)	Plutonium-238	Uranium-Fluorimetry	
Other Analytes ⁽¹⁾			
Ammonia/Ammonium	Mercury	Wt% Dissolved Solids	
Cyanide	pH (Supernatant)	Wt% Suspended Solids	
Flashpoint (Supernatant)	Total Organic Carbon		
Hydroxide (Supernatant)	Total Inorganic Carbon		
Analytes Not Analyzed per Change Request Proposal			
Total Nitrogen	Total Sulfur	Total Iodine	
Total Oil/Grease	Reactive Sulfur	Reactive Cyanide	
SS Corrosion Testing	TCLP Extractions/Analysis		

(1) Additional Analytes of Interest Measured and Reported

Appendix A: Organic Analytes of Interest List and MRQs

CAS	Compound/Element	MRQ ug/Kg	CAS	Compound/Element	MRQ ug/Kg
PNL-ALO-335(8260B)					
100-41-4	Ethyl benzene	3300	141-78-6	Acetic acid ethyl ester	11000
100-42-5	Styrene	—	142-82-5	n-Heptane	—
10061-01-5	cis-1,3-Dichloropropene	6000	287-92-3	Cyclopentane	—
10061-02-6	trans-1,3-Dichloropropene	6000	4170-30-3	2-Butenaldehyde (2-Butenal)	—
106-35-4	3-Heptanone	—	56-23-5	Carbon tetrachloride	2000
106-42-3	p-Xylene & m-Xylene	3300	563-80-4	3-Methyl-2-butanone	—
106-93-4	Ethylene dibromide	5000	591-78-6	2-Hexanone	—
106-97-8	Butane	—	627-13-4	Nitric acid, propyl ester	—
106-99-0	1,3-Butadiene	—	684-16-2	Hexafluoroacetone (3)	—
107-02-8	Acrolein	—	67-64-1	2-Propanone (Acetone)	53300
107-05-1	3-Chloropropene	10000	67-66-3	Chloroform	2000
107-06-2	1,2-Dichloroethane	2000	71-43-2	Benzene	3300
107-12-0	Propionitrile	120000	71-55-6	1,1,1-Trichloroethane	2000
107-13-1	Acrylonitrile	28000	74-83-9	Bromomethane	5000
107-87-9	2-Pentanone	—	74-87-3	Chloromethane	10000
108-10-1	4-Methyl-2-pentanone	11000	75-00-3	Chloroethane	—
108-38-3	m-Xylene (See 106-42-3)	3300	75-01-4	1-Chloroethene	2000
108-87-2	Methylcyclohexane	—	75-05-8	Acetonitrile	12700
108-88-3	Toluene	3300	75-09-2	Dichloromethane (Methylene Chloride)	10000
108-90-7	Chlorobenzene	2000	75-15-0	Carbon disulfide	—
108-94-1	Cyclohexanone	—	75-34-3	1,1-Dichloroethane	2000
109-66-0	n-Pentane	—	75-35-4	1,1-Dichloroethene	2000
109-99-9	Tetrahydrofuran	—	75-43-4	Dichlorofluoromethane	—
110-12-3	5-Methyl-2-hexanone	—	75-45-6	Chlorodifluoromethane	—
110-43-0	2-Heptanone	—	75-69-4	Trichlorofluoromethane	10000
110-54-3	n-Hexane	—	75-71-8	Dichlorodifluoromethane	2400
110-82-7	Cyclohexane	—	76-13-1	1,2,2-Trichloro-1,1,2-trifluoroethane	10000
110-83-8	Cyclohexene	—	76-14-2	1,2-Dichloro-1,1,2,2-tetrafluoroethane	—
111-65-9	n-Octane	—	78-87-5	1,2-Dichloropropane	—
111-84-2	n-Nonane	—	78-93-3	2-Butanone	12000
123-19-3	4-Heptanone	—	79-00-5	1,1,2-Trichloroethane	2000
123-38-6	n-Propionaldehyde	—	79-01-6	1,1,2-Trichloroethylene	2000
123-86-4	Acetic acid n-butyl ester	—	79-34-5	1,1,2,2-Tetrachloroethane	2000
123-91-1	1,4-Dioxane	—	95-47-6	o-Xylene	3300
126-98-7	2-Methyl-2-propenenitrile	28000	96-22-0	3-Pentanone	—
127-18-4	1,1,2,2-Tetrachloroethene	2000			
PNL-ALO-345(8270C) - Standards Unavailable			PNL-ALO-346(8260B) - Very reactive		
1321-64-8	Pentachloronaphthalene	—	57-14-7	1,1-Dimethylhydrazine	—
1335-87-1	Hexachloronaphthalene	—	60-34-4	Methylhydrazine	—
1335-88-2	Tetrachloronaphthalene	—	624-83-9	Methyl isocyanate	—
Deleted per BNFL					
3825-26-1	Ammonium perfluorooctanoate	—	88-89-1	Picric acid	—
75-21-8	Oxirane	—			

(1) Cresol measured as independent Methylphenols.

(3) Toxic gas, not previously analyzed

(2) Not be distinguished from Diphenylamine

(4) "—" = No MRQ provided by BNFL

PNNL Test Plan

Document No.: BNFL-TP-29953-031

Rev. No.: 1

only working copy

Title: C-104 Sample Compositing

Work Location: 325/SFO

Page 1 of 6

Author: Paul Bredt

Effective Date: Upon Final Signature

Supersedes Date: New

Use Category Identification: Reference

Identified Hazards:

- ☐ Radiological
☐ Hazardous Materials
☐ Physical Hazards
☐ Hazardous Environment
☐ Other:

Required Reviewers:

- ☒ Author
☒ Technical Reviewer
☒ RPL Manager
☒ Project Manager
☒ RPG Quality Engineer
☐ BNFL

Are One-Time Modifications Allowed to this Procedure? ☒ Yes ☐ No

NOTE: If Yes, then modifications are not anticipated to impact safety. For documentation requirements of a modification see SBMS or the controlling Project QA Plan as appropriate.

On-The Job Training Required? ☐ Yes or ☒ No

FOR REVISIONS:

Is retraining to this procedure required? ☐ Yes ☒ No

Does the OJT package associated with this procedure require revision to reflect procedure changes?

☐ Yes ☐ No ☒ N/A

Approval

Signature

Date

Author Paul Bredt 5/13/99Technical Reviewer DE Kursth 5/18/99RPL Manager [Signature] 5/13/99Project Manager Eugene V. Morisy 5/13/99RPG Quality Engineer [Signature] 5-13-99BNFL Michael E. Johnson 5/18/99

Applicability

This Test Plan describes work to be performed under Task 2.01, LAW and HLW Feed Characterization. This work is defined under BNFL letter W375-98-0018 dated September 29, 1998. Approximately 1.7 L of material from Tank 241-C-104 have been transferred from the 222-S laboratory to the 325 HLRF. All of this material is to be used to prepare a C-104 composite.

Approximately 250 ml of the homogenous composite are to be collected for delisting and permitting activities. These samples will be withdrawn from the composite in a manner which will provide representative samples for chemical, radiochemical, and physical testing. To support the delisting and permitting, this test plan will generate samples that will allow measurement of chemical properties of the waste that are both precise and accurate. Integrity of the subsamples will be maintained consistent with prior sampling and storage history. No preservation or temperature control of the subsamples are planned. Sampling protocols in SW-846 are not strictly applicable since these protocols are targeted at sampling in the field.

Following collection of the homogenous delisting and permitting samples, all remaining standing liquid will be removed from the composite. This liquid will be submitted for additional characterization activities. The remaining solids will only contain a limited amount of interstitial liquid.

Objectives

The objectives of this test plan are the following:

- 1) Homogenize the C-104 samples shipped from 222-S to 325
- 2) Subsample the homogenous composite for chemical and radiochemical characterization
- 3) Decant all standing liquid for additional chemical and radiochemical characterization
- 4) Subsample solids for solids washing and leaching studies

Note

1. Sample material is not to contact plastic as this could complicate organic analyses. This precludes the use of plastic transfer pipettes.
2. Use "Qorpak" jars with TFE-lined closures. These bottles/closures do not introduce contamination to the samples.
3. Secondary containment is to be used wherever practical to prevent sample loss.

Quality Control

Quality control has been implemented in the work instructions.

Since this document will be used to record an experimental process, markups as specified in the RPL Operations manual section 16.6 will be allowed. The staff member performing the change initials markups to this Test Plan. The Cognizant Scientist overseeing the work initials and dates changes to the Test Plan. Changes made by the Cognizant Scientist do not require additional reviews or approvals. If changes occur to multiple pages then the Cognizant scientist shall note the effected pages and initialize the note. Superseded text shall be lined out, but not obscured, initialed and dated.

**PNNL Test Plan
Supplemental Signature Page**

Document No.: BNFL-29953-031
Rev. No.: 1

Title: C-104 Sample Compositing

Work Location: 325/SFO

Page: Supplemental

Author: Paul Bredt

Effective Date: Upon Final Signature
Supersedes Date: New

Use Category Identification: Reference

Identified Hazards:

- ☐ Radiological
- ☐ Hazardous Materials
- ☐ Physical Hazards
- ☐ Hazardous Environment
- ☐ Other:

Supplemental Reviewers:

- ☒ SFO Manager
- ☐ Building Manager
- ☐ Radiological Control
- ☐ ES&H
- ☐ Other

Approval

Signature

Date

SFO Manager



5/13/89

Building Manager

Radiological Control

ES&H

Other

Other

Other

R/G = red liquid
Green
settled solids

- 2) Weigh the sample jars listed below to ± 0.01 g. Transfer all material from the jars to the mixing vessel. If necessary, use supernatant from the jars or vessel to rinse the solids into the vessel. Reweigh the empty jars and record the mass to ± 0.01 g in the space provided.

initial + transfer on 6/17/99

Sample Label	Mass (Full)	Mass (Empty)	Mass Transferred	
16273..	273.768	123.722	150.046	R/G
16274.. chunky	290.118	132.480	157.638	R/G
16275.. chunky ^{some solid in jar}	301.270	124.835	176.435	liquid and solids on
16276..	284.182	126.970	157.212	R/G
16277.. chunky + thick ^{some solid in jar}	302.310	139.660	162.650	no standing liquid
16278.. some solids ^{still in jar}	301.512	136.640	164.872	R/G
16279.. some solids ^{still in jar}	288.623	138.978	149.645	R/G
16280..	266.863	125.061	141.802	R/G
16281..	270.904	128.296	142.608	R/G
16282.. chunky, some ^{solid in jar}	299.436	139.091	160.345	no standing liquid
16283.. some solids ^{in jar}	284.721	125.549	159.172	R/G
16284.. chunky	288.493	128.242	160.251	R/G
16285.. chunks	283.223	135.922	147.301	R/G
16286..	281.264	129.612	151.652	R/G

Examined 16281, no visible organic layer

- 3) The goal of this step is to homogenize the sample using as little force as possible. Stir the sample by slowly increasing the motor speed until the solids are mobilized. Given this work is being conducted in a steel vessel, observations need to be made with the lid off the vessel. Stir for a minimum of one hour. Record the hot cell temperature. Started stirrer 8:30am 6/23/99

collected samples starting
Time at 9:50am Date 6/23/99 Temperature 33.7 °C

- 4) Clearing the valve: While the solids are mobilized, collect ~50 ml of sample in a clean jar. This fraction is probably high in solids due to the geometry of the vessel, so return this sample to the vessel and continue to stir the vessel.
- 5) Collect 3 ~100 ml samples in volume-graduated tared bottles listed below by removing material using the 3/4" ball valve located on the bottom of the vessel. Sufficient sample is to be collected in each jar as to minimize headspace in the jars. Weight the full bottles to ± 0.01 g and record the masses below.

collected last sample at 9:57am with cell temp of 33.8 °C.

C-104 COMP A

C-104 COMP B

C-104 GL

Total 302.685 g

Tare 133.7596 g

Slurry 89 g

168.925 PRB 6/23/99

Total 303.839 g

Tare 133.4967 g

Slurry 170.342 g

Total 291.094 g

Tare 134.5266 g

Slurry 156.567 g

- 6) Turn off the stirring motor, record the date and time. Cover the vessel using a blank flange.

Day 6/23/99 Time 10:00am

- 7) Allow C-104 COMP A, C-104 COMP B, and C-104 GL to settle for a minimum of 16 hours.

allowed vessel to settle until 6/24/99. Removed standing liquid and used to rinse the 6 jars that still contained solids
PRB 6/23/99

• very little standing liquid (<5%) on 6/24/99 @ 9:00am / AB

M&TE List:

Balance 1: Calib ID 384-06-01-004 Calib Exp Date 8/99
Location 601 rm

Balance 2: Calib ID 388-06-01-020 Calib Exp Date 8/99
Location C-Cell

Thermocouple: Calib ID 2531³²⁵⁻⁴¹⁶₀₂₉₇₁ Calib Exp Date 5/01
Location 601 Thermocouple type K

Digital Thermometer: Calib ID 2531 Calib Exp Date 5/00
Location 601

Bath Balance 3: ID 362-0601-049 exp 8/99 location B-cell

Work Instructions

- 1) The composite is to be prepared in a 3L stainless steel vessel. Secondary containment will be used to allow recovery from a possible breach of a 3L vessel or failure of the tap valve. The recommended parts for the kettles are listed below. Viton O-rings are to be used for sealing the vessel. No grease is to be used. All components (including the valve) are to be rinsed with methanol and then placed in a 102°C oven for 12 hours. The valve (packed with ultra high molecular weight polyethylene) is lightly greased with silicone. Since the valve will only see limited use, removing this grease with the methanol rinse should not effect its performance. The system is then to be assembled and leak tested using deionized water. Do not use teflon tape to assemble the vessel.

Description	Part	Vendor
UHMWPE packed ¾" Ball Valve	SS-63ES12	Seattle Valve and Fitting
5"ID x 9.87" pipe nipple with 6.75" Comflat flange	FNF0500	Varian
6.75" blank off flange	F06750000NC4	Varian
6.75" viton gasket	FG0675VU	Varian
Nut and bolt set	FB0600C06	Varian
Clamping ring	Z12,171-1	Sigma-Aldrich
¾" swagelok to pipe thread	SS-12-TA-1-12	Seattle Valve and Fitting
Stir rod	14-500-18	Fischer

used 0.01M NaOH to Rinse Jars (original jars from 222-S)
 then added to vessel.
 PRB 7/2/99
 BNFL-29953-031 Rev. 1
 Page 6 of 6

14) Drain the vessel into a 250 ml jar labeled C-104 RIN.

C-104 RIN

Total 372.187 g
 Tare 249.512 g
 Slurry 122.674 g

23 Na
 160
 1 H
 40 g/mole

15) Add another 50mL of 0.01M NaOH to the vessel and agitate.

16) Drain the vessel into C-104 RIN.

C-104 RIN

Total 524.96 g
 Tare 249.5128 g
 Slurry 272.447 g

17) Place sample jars C-104 COMP C, C-104 COMP D, C-104 COMP E, and C-104 RIN in a secondary container and retain for CUF studies.

0.01 M NaOH

Solution #1
 $\frac{0.01 \text{ M NaOH}}{1000 \text{ ml}} \cdot 0.1 \text{ l} = \frac{0.001 \text{ moles NaOH}}{100 \text{ ml}}$
~~Shot~~
 Shot PRB 7/13/99
 $0.001 \text{ moles} \cdot \frac{40 \text{ g}}{\text{mole}} = 0.04 \text{ g}$

Using DI in #201, added 0.0664g NaOH Fisher Brand
 Lot # 961969

and placed in plastic volumetric Flask. Brought up to
 100 ml. PRB 7/2/99

Solution #2 0.0727 g NaOH in 100 ml H₂O

PRB 7/2/99 Rinsed vessel again with another another double
 shot of 0.01M NaOH.

C-104 RIN 2

total 390.49 g
 Tare 249.5786 g
 Slurry 140.911 g

and a leaf?
 8 rocks ~1/4" in Bottom of
 vessel after draining. Yellow/Brown
 Transferred Rocks to
 C-104 SUPC
 total 265.908 g
 Tare 250.5623 g
 Rocks 15.3457 g

- 8) Record the date and time, and total volume of the slurries and volume of the settled solids in C-104 COMP A, C-104 COMP B, and C-104 GL.

Day 7/2/99 Time 8:45 am

C-104 COMP A

C-104 COMP B

C-104 GL

Total 117 ml ^{89.1}
Solids 104 ml

Total 120 ml ^{89.2}
Solids 107 ml

Total 109 ml ^{89.9}
Solids 98 ml

- 9) If the volume percent settled solids in the 3 samples are within ~10%, then the samples are representative of the whole composite and proceed to step 10. If the volume percent settled solids vary by much more than 10%, then return the slurry samples in jars C-104 COMP A, C-104 COMP B, and C-104 GL to the kettle, increase the stirring rate and repeat steps 3 through 9. Record new information and attach to this test plan.
- 10) Turn the stirrer on and allow the system to stir for ~10 minutes. While the stirrer is on, collect all the remaining material in 500 ml jars as labeled below. It is possible that up to 3 jars may be required. Record the time and date.

Day 7/2/99 Time 9:25 am

C-104 COMP C

C-104 COMP D

C-104 COMP E

Total 951.16 g
Tare 345.4623 g
Slurry 605.698 g

Total 955.90 g
Tare 347.3564 g
Slurry 608.54 g

Total 472.76 g
Tare 347.5600 g
Slurry 125.20 g

- 11) Allow samples C-104 COMP C, C-104 COMP D, and C-104 COMP E to settle for at least 3 days then transfer all standing liquid on samples C-104 COMP C, C-104 COMP D, C-104 COMP E, and C-104 GL to 250 ml jars as labeled below. This transfer is to be conducted by decanting or using clean glass pipettes. It is possible that up to 3 jars may be required. Record the time and date.

C-104 GL decanted early 8/11/99

Day 8/11/99 Time 11:45 am

C-104 SUP A

C-104 SUP B

C-104 SUP C

Total 424.51 g
Tare 248.8005 g
Slurry _____ g

Total _____ g
Tare 249.9560 g
Slurry _____ g

Total _____ g
Tare 250.5623 g
Slurry _____ g

contains several Rocks - see page 7 PAB 8/13/99

- 12) Transfer sample C-104 COMP A, C-104 COMP B, C-104 GL, C-104 SUP A, C-104 SUP B, and C-104 SUP C to the SAL with a chain of custody.

- 13) Add 50mL of 0.01M NaOH to the vessel and agitate.

C-104 SUP A after addition of sup from C-104 GL = 264.912g PAB 7/29/99
" after addition of sup from C-104 comp C = 336.017g PAB 8/11/99
" after addition of sup from C-104 comp D = 410.44g PAB 8/11/99
" after addition of sup from C-104 comp E = 424.51g REC 8-11-99

After sup removal → Comp D = 880.64g Comp C = 878.52g Comp E = 458.23g

PNNL Test Plan

Document No.: BNFL-29953-080
Rev. No.: 1

Title: Organic Extraction of C-104 Samples and sub-sampling for VOA, Headspace, and Anions

Work Location:
325/SFO, 325/general labs; 329/general labs

Page 1 of 17

Author: Michael W. Urie

Effective Date: Upon final signature
Supersedes Date: New

Use Category Identification: Reference

Identified Hazards:

- ☒ Radiological
- ☒ Hazardous Materials
- ☐ Physical Hazards
- ☐ Hazardous Environment
- ☐ Other:

Required Reviewers:

- ☒ Technical Reviewer
- ☐ Building Manager
- ☐ Radiological Control
- ☐ ES&H
- ☒ Quality Engineer
- ☒ Project Manager
- ☒ RPL Manager
- ☒ SFO Manager
- ☒ AO&AM Manager

Are One-Time Modifications Allowed to this Procedure?

☒ Yes ☐ No

NOTE: If Yes, then modifications are not anticipated to impact safety. For documentation requirements of a modification see SBMS or the controlling Project QA Plan as appropriate.









On-The Job Training Required? ☐ Yes or ☒ No

FOR REVISIONS:

Is retraining to this procedure required? ☐ Yes ☒ No

Does the OJT package associated with this procedure require revision to reflect procedure changes? ☐ Yes ☒ No

Approval

	Signature	Date
Author (VOA, SVOA)/Reviewer		6-5-00
Author (PCB, Headspace)/Reviewer		6-5-00
Author (Dioxins/Furans, Anions)/Reviewer		6-5-00
RPL Manager		6/6/00
SFO Manager		6/6/00
Project Manager/Reviewer		6-5-00
AO&AM Manager		6-5-00
Quality Engineer		6/5/00

The extractions of these C-104 HLW samples will be performed in the Shielded Analytical Laboratory within the 325 facility.

1.0 Total Dissolved Solids and Weight Percent Solids Determination

Because these samples may contain reduced iron or other magnetically separable particles, a magnetic stir-bar and magnetic stir table should not be used. A better approach is to perform the stirring with an impeller-type stirrer, such as a Teflon coated spatula rotated by a variable speed drill. After a few minutes of stirring, and once the solids appear to be suspended, a 1-g to 3-g aliquot is placed in a tared graduated centrifuge tube, weighed, and centrifuged at 1000 RPM for approximately one hour. After centrifuging, note and record the volume of both the liquid and the solids in the tube. Decant the liquid into a tared beaker, weigh and dry at 105°C overnight. Weigh the beaker after at least 12 hours of drying to determine the total dissolved solids for the supernatant. Weight percent solids determination will be performed on the centrifuged solids, remaining in the centrifuge tube, in accordance with PNL-ALO-504.

1.1 Separation of the Wet Solids from the Slurry

Centrifugation of the slurry (i.e., C104 Comp A and C104 Comp B) may be more convenient than filtration for the separation of the wet solids from the slurry. In order to centrifuge the 120-mL jars, they must first be balanced to ± 1 g. Weigh each jar and transfer the appropriate quantity of liquid from the heavier jar to the lighter jar to balance them. Place the jars in clean polyethylene sleeves, and centrifuge at no greater than 1000 RPM for 1 hour. *As a precaution, it is prudent to perform a "dry-run" first, using balanced jars containing approximately 100 mL of deionized water, and centrifuging at 1100 RPM.* After the jars containing the slurries have been centrifuged, carefully remove them from the centrifuge and the plastic sleeves. Carefully decant the supernatant into a clean jar or combine with the jar containing C-104 supernatant (i.e., container C104 SUP. A) if room is available in the container. Weigh the jar containing the wet centrifuged solids, and record this weight on the benchsheet. In the event the total quantities of supernatant and wet solids are less than those listed in test plan BNFL-29953-30, contact Michael W. Urie, 376-9454.

1.2 Sub-sampling for VOA and Headspace analysis

VOA and headspace aliquots shall be made prior to introducing methylene chloride, or other solvents, into the hot-cells.

Headspace samples should be aliquotted into clean 10-mL headspace vials and sealed with a septa-lined cap immediately afterward. A 1-mL supernatant sample, sample duplicate, sample triplicate and blank will be prepared for each sample as described in Test Plan TP-29953-030, Table 2. (Note: The sample triplicate is an additional sub-sample not identified in TP-29953-030.) A 1-mL supernatant matrix spike and matrix spike duplicate will also be aliquotted at this time. The headspace vials should be tared on an analytical balance, and each 1-mL aliquot weighed and recorded, so that the density of the supernatant can be determined during this step. Additionally, 50-microliter aliquots each of the supernatant sample, sample duplicate, sample triplicate, matrix spike, and matrix spike duplicate shall also be prepared to permit quantitation of analytes that may be outside the calibration range for a 1-mL sample size.

VOA samples should be aliquotted into clean 40-mL VOA vials and sealed with a septa-lined cap immediately afterward. A 2-mL supernatant sample, sample duplicate and blank will be prepared for each sample as described in Test Plan TP-29953-030. A 1-mL supernatant matrix spike, and matrix spike duplicate will also be aliquotted at this time. Additionally, 50-microliter aliquots of each the supernatant sample, sample duplicate, matrix spike, matrix spike duplicate shall also be prepared to permit quantitation of analytes that maybe outside the calibration range for a 2-mL sample size. Half gram aliquots of the wet centrifuged solids will be aliquotted into clean 40-mL VOA vials, diluted with organic-free water to a volume of 5 mL and sealed immediately with a septa-lined cap. The aliquots

Applicability

This Organic Extraction Test Plan describes work to be performed under Test Plan TP-29953-030, Inorganic, Organic and Radiochemical Characterization of C-104 Samples. These samples are slurries, which contain solids, and decanted liquid. Together these samples provide the starting material for the organic characterization of the "as received" materials. Per the TP-29953-030, two bottles containing about 340 grams of slurry and one jar containing about 175 grams of supernatant will be sub-sampled for VOA, headspace analysis, organic anions, SVOA, pesticide/PCB, and Dioxin/Furan analysis, as well as inorganic and radiochemistry analysis specified in the test plan. Sub-sampling and dilutions for VOA and headspace analysis will be performed prior to beginning extractions so as not to contaminate these sub-samples with solvent vapors.

Based on the history of the samples, and the limited quantities available, exceptions are being taken to the preservation, temperature control, sample size, and hold time requirements specified by SW-846 protocols. The choice of spiking solutions and extraction solvents is based upon SW-846 methods 8270C, 8081A/8082 and 8290 guidelines, where applicable.

This revision provides final documentation for the actual work performed for phase separation of the C-104 slurry, sub-sampling activities for the VOA and Headspace analyses, and the organic extraction process performed for preparing the SVOA, PCB, and Dioxin/Furan samples.

Hazards Assessment and Mitigation

The radioactive work conducted under this Test Plan is comprised of analytical organic analysis preparative operations that have been conducted routinely in the RPL and 329 Facilities. The organic extractions with small quantities of methylene chloride or methylene chloride/acetone mixtures have been performed in the Shielded Analytical Laboratory (SAL) many times and are included as a standard preparative activity on the RPL Analytical Service Request. The organic solvent extraction operations are included in the SAL work authorization. Since all of the analytical preparative operations fall within current work authorizations, no further assessment of the hazards is detailed in this Test Plan.

Quality Control

Per TP-29953-030, quality control is governed by PNNL's web-based Quality Assurance Planning Subject Area, "Conducting Analytical Work in Support of Regulatory Programs". The organic analyses will be performed in duplicate using a sample size that will closely meet regulatory reporting level for waste material. Sample sizes are specified in Test Plan TP-29953-030. Surrogate spike compounds will be added to the sample, sample duplicate, and matrix spikes in order to provide information on analyte recoveries. Separate laboratory control samples (LCS) will be prepared outside the hot-cell.

Integrity of the sub-samples and processed extracts distributed throughout the laboratory will be maintained by chain-of-custody documentation. The Task Manager shall approve changes to this Test Plan (initialed markups are allowed).

Work Instructions

An extraction scheme for the SVOA extraction activity is provided in Figure 1. Extraction schemes for PCB/pesticide and dioxin extractions are provided in Figures 2 and 3, respectively.

Total dissolved solids of the supernatant and weight percent solids of the centrifuged solids will be determined prior to sub-sampling and extracting.

Table 3 Surrogate Spike Compounds and Levels added to Samples		
Analysis	Spike Compounds	Amounts Added (ug)
Semivolatiles	phenol-d ₅	75
	2-fluorophenol	75
	2-chlorophenol-d ₄	75
	2,4,6-tribromophenol	75
	1,2-dichlorobenzene-d ₄	50
	nitrobenzene-d ₅	50
	2-fluorobiphenyl	50
Dibenzodioxins and Dibenzofurans	p-terphenyl-d ₁₄	50
	¹³ C ₁₂ -2,3,7,8 TCDD	0.05
	¹³ C ₁₂ -2,3,7,8 TCDF	0.05
	¹³ C ₁₂ -1,2,3,7,8 PeCDD	0.05
	¹³ C ₁₂ -1,2,3,7,8 PeCDF	0.05
	¹³ C ₁₂ -2,3,4,7,8 PeCDF	0.05
	¹³ C ₁₂ -1,2,3,4,7,8 HxCDD	0.05
	¹³ C ₁₂ -1,2,3,6,7,8 HxCDD	0.05
	¹³ C ₁₂ -1,2,3,4,7,8 HxCDF	0.05
	¹³ C ₁₂ -1,2,3,6,7,8 HxCDF	0.05
	¹³ C ₁₂ -1,2,3,7,8,9 HxCDF	0.05
	¹³ C ₁₂ -2,3,4,6,7,8 HxCDF	0.05
	¹³ C ₁₂ -1,2,3,4,6,7,8 HpCDD	0.05
	¹³ C ₁₂ -1,2,3,4,6,7,8 HpCDF	0.05
	¹³ C ₁₂ -1,2,3,4,7,8,9 HpCDF	0.05
Pesticides and PCBs	¹³ C ₁₂ -OCDD	0.1
	tetrachloro-m-xylene	0.040
	decachlorobiphenyl	0.040

2.1 Extraction of the supernatant portion of the HLW samples

Extractions for the SVOA supernatant sample and duplicate are performed on 20-mL aliquots, with the extractions for the SVOA matrix spike and matrix spike duplicates being performed on 10-mL aliquots. Extractions for all pesticides and PCB supernatant samples are performed on 10-mL aliquots. And, extractions for dioxins/furans supernatant sample and duplicate are performed on 15-mL aliquots, with the extractions for the dioxins/furans matrix spike and matrix spike duplicate being performed on 7.5-mL aliquots. The quantity of matrix spike used is given in Table 4. Extraction blanks shall be prepared using the same quantity of organic-free water as the quantity of supernatant sample. Stepwise instructions for performing the extractions are given in Sections 6.1, 7.1 and 8.1.

Semivolatiles

As shown in Figure 1, the supernatant portion of the as received sample is diluted with 25 mL of 0.01 N NaOH (prepared from organic-free water) prior to extraction. Following dilution the supernatant sample is extracted three times with equal portions of methylene chloride.

The supernatant sample is then pH adjusted by slow drop-wise addition of phosphoric acid while the sample is cooled in an ice-bath during the acidification. The pH-adjusted supernatant sample is extracted three times with equal portions of methylene chloride.

If during the acidification process any solids are formed at a relative quantity >1% by volume, the solids are separated, desiccated with sodium sulfate, and ultrasonic extracted three times using equal portions of methylene chloride.

All SVOA extracts from the supernatant portion of the as received sample are combined and concentrated to 1 mL outside the hot-cells.

for the VOA MS and MSD shall be 0.25-g rather than the 0.5-g aliquots used for the sample and duplicate. In a like manner, a second set of wet centrifuged solids will be aliquotted using a 50-mg sample size for each the sample, duplicate, MS and MSD.

VOA and headspace samples will be transferred from the hot-cell immediately after preparation. For further guidance or questions regarding VOA sub-sampling contact George S. Klinger, 372-0448. For further guidance or questions regarding headspace sub-sampling contact Eric W. Hoppe, 376-2126.

2.0 Extraction samples for SVOA, PCB/pesticides and Dioxins analysis

General Comments:

The quantities of the sample, sample duplicate, matrix spike, and matrix spike duplicate are given in Table 2 of Test Plan BNFL-29953-030 and restated in Section 2.1.

Teflon separatory funnels, with FEP caps, are used for the liquid-liquid extraction processing and teflon centrifuge tubes are used for the subsequent solids ultrasonic processing.

Phosphoric acid is used to adjust the pH prior to extraction of the liquids, as appropriate.

A small (0.5 ml) portion of the liquid is potentiometricly titrated to determine the quantity of phosphoric acid required to adjust the pH of the sample. The amount of precipitate formed during acidification will be evaluated and the precipitate extracted separately, if required.

Spiking solutions will be added to the sample prior to extraction. If solids formed as a result of pH adjustment warrant a separate extraction step, additional spikes will not be added as these extracts will be recombined with the "like" phase extracts.

The nominal MDLs for liquids and solids are shown in Tables 1 and 2, respectively. The surrogate spikes and quantities added are shown in Table 3. The appropriate spiking materials shall be provided by G. Klinger for SVOA, by E. Hoppe for pesticides/PCB, and J. Campbell for dioxins/furans.

Table 1 Liquid portion HLW organic analysis MDLs

Analysis	MDL (ppb, 1 L water)	MDL (ppb, 25 mL sample)
Semivolatiles	10 to 25	400 to 1000
Pesticides and PCBs	0.1 to 1	4 to 40
Dibenzodioxins and Dibenzofurans	1×10^{-4} to 1×10^{-3}	4×10^{-3} to 4×10^{-2}

Table 2 Solid portion HLW organic analysis MDLs

Analysis	MDL (ppm, 1 g solid)	MDL (ppm, 5 g sample)
Semivolatiles	10 to 25	2 to 5
Pesticides and PCBs	0.1 to 1	0.02 to 0.2
Dibenzodioxins and Dibenzofurans	1×10^{-4} to 1×10^{-3}	2×10^{-3} to 2×10^{-2}

Pesticide/PCBs

As shown in Figure 2, the solids portion of the sample is leached (with ultrasonic agitation) twice with 40 mL of organic-free 0.01 N NaOH solution. Based upon the earlier dissolution test using a 0.5-g aliquot, any solids remaining at a level greater than 1% of the original solids portion are separated and extracted separately. The NaOH leachate (i.e., dissolved solids) is extracted three times with equal portions of methylene chloride.

The NaOH leachate is then pH adjusted by slow drop-wise addition of phosphoric acid while the sample is cooled in an ice-bath during the acidification. If a solid precipitate is formed at a relative quantity of >1% by volume, it is separated and extracted separately. The pH-adjusted NaOH leachate is extracted three times with equal portions of methylene chloride.

The undissolved solids and any solids formed during the acidification process are combined, desiccated with sodium sulfate, and ultrasonic extracted three times using a 1:1 methylene chloride/acetone solution.

All pesticide/PCB extracts from the solids portion of the as received sample are combined and concentrated to 1 mL outside the hot-cells.

Dioxins/Furans

As shown in Figure 3, no liquids will be added to the solid portion of the solids sample, as was done for the SVOA and pesticide/PCB extractions. The dioxin extractions do not require a pH adjustment of the wet centrifuged solids. A desiccant is mixed with the wet solids to retain any water, and the desiccated solids are ultrasonically extracted three times with a 1:1 methylene chloride/acetone solution. The dioxin extracts are combined and concentrated to 1 mL outside the hot-cells.

3.0 Preparation and Extraction of Matrix Spikes and LCS for SVOA, Dioxins/Furans and pesticide/PCB analysis

A separate LCS will be prepared for each analysis outside the hot-cells using the sample reagents used for the extraction of the HLW samples. The LCS matrix will consist of 1 Liter of distilled water. The LCSs will be extracted using liquid-liquid extraction. The LCSs will be spiked with the compounds and levels listed in Table 4. Separate LCSs will be prepared for SVOA, Dioxin/Furans, pesticides, and PCBs. The LCS will be spiked with the same surrogates as listed in Table 3.

Table 4		
CAS Reg. No.	Compound	ug
Semivolatile MS and LSC spike compounds		
100-51-6	Benzyl alcohol	50
106-46-7	1,4-Dichlorobenzene	50
108-95-2	Phenol	50
117-81-7	Di-sec-octyl phthalate	50
117-84-0	n-dioctyl phthalate	50
118-74-1	Hexachlorobenzene	50
120-82-1	1,2,4-Trichlorobenzene	50
50-32-8	Benzo(a)pyrene	50
53-70-3	Dibenz[a,h]anthracene	50
541-73-1	1,3-Dichlorobenzene	50
62-75-9	N-Nitroso-N,N-dimethylamine	50
67-72-1	Hexachloroethane	50
87-68-3	Hexachlorobutadiene	50

Pesticides/PCB

As shown in Figure 2, the supernatant portion of the as received sample is diluted with 25 mL of 0.01 N NaOH (prepared from organic-free water) prior to extraction. Following dilution the supernatant sample is extracted three times with equal portions of methylene chloride.

The supernatant sample is then pH adjusted by slow drop-wise addition of phosphoric acid while the sample is cooled in an ice-bath during the acidification. The pH-adjusted supernatant sample is extracted three times with equal portions of methylene chloride.

If during the acidification process any solids are formed at a relative quantity >1% by volume, the solids are separated, desiccated with sodium sulfate, and ultrasonic extracted three times using equal portions of a 1:1 methylene chloride/acetone mixture.

All extracts from the supernatant portion of the as received sample are combined and concentrated to 1 mL outside the hot-cells.

Dioxins/Furans

Adjustment of the pH is presumed not to be necessary for the dioxin/furan extractions. To dilute the sample, 25 mL of 0.01 N NaOH (prepared from organic-free water) will be added to the sample prior to extraction. As shown in Figures 3, a supernatant sample is extracted (liquid-liquid) three times with equal portions of methylene chloride. The extracts from the supernatant portion of the as received sample are combined and concentrated to 1 mL outside the hot-cells.

2.2 Extraction of the centrifuged solids portion of the HLW samples

The solid sample and duplicate will be extracted using 5 g of the solids portion of the as received sample. A matrix spike and spike duplicate will be extracted using 2.5 g of sample. The quantity of matrix spike used is given in Table 4. Leach blanks shall be prepared using the same quantity of organic-free water as the quantity of 0.01 N NaOH added to the sample. Stepwise instructions for performing the extractions are given in Sections 6.2, 7.2 and 8.2.

SVOAs

As shown in Figure 1, the solids portion of the as received sample is leached (with ultrasonic agitation) once with 50 mL of organic-free 0.01 N NaOH solution. Based upon the earlier dissolution test using a 0.5-g aliquot, any solids remaining at a level greater than 1% of the original solids portion are separated and extracted separately. The NaOH leachate (i.e., dissolved solids) is extracted three times with equal portions of methylene chloride.

The NaOH leachate is then pH adjusted by slow drop-wise addition of phosphoric acid while the sample is cooled in an ice-bath during the acidification. If a solid precipitate is formed at a relative quantity of >1% by volume, it is separated and extracted separately. The pH-adjusted NaOH leachate is extracted three times with equal portions of methylene chloride.

The undissolved solids and any solids formed during the acidification process are combined, desiccated with sodium sulfate, and ultrasonic extracted three times using methylene chloride.

All SVOA extracts from the solids portion of the as received sample are combined and concentrated to 1 mL outside the hot cells.

- 1) Transfer a 0.5-mL aliquot of the supernatant (or soluble solids fraction) into a tared 100-mL beaker and weigh.
- 2) Add 10 mL of 0.01 N sodium hydroxide solution (prepared from organic-free water) and a clean magnetic stir bar to the beaker containing the aliquot. Measure and record the initial pH.
- 3) Titrate the sample to pH 2 using 0.1 N H_3PO_4 solution. Record the acid volume, temperature and pH at $\Delta 0.1 - 0.2$ pH units. Note the acid volume and pH at the point where any precipitation begins to occur, or redissolve. Repeat this titration using 0.1 N HNO_3 solution.
- 4) Using the titration spreadsheet, plot the curves for both the supernatant and soluble solids fraction.
- 5) Closely examine the curves. Find a region of the curve where the pH is near 6.5 and exhibits some buffering behavior. Calculate the quantity of acid needed per gram of sample to adjust the pH to the midpoint of this region. Review the data with the cognizant scientist prior to adjusting the pH of the extraction sample.

5.2 Determination of Insoluble Solids Content

- 1) Transfer a 0.5-g aliquot of the centrifuged solids into a tared centrifuge tube and weigh.
- 2) Add 10 mL of 0.01 N NaOH solution in 1-mL aliquots. After each addition, swirl the centrifuge tube for a few minutes and observe and record any dissolution of the solid that appears to occur after each addition. If all of the solids dissolve before 10 mL of 0.01 N NaOH solution have been added, record this volume for use in Step 1, Sections 6 and 7.
- 3) Centrifuge the tube at the highest safe speed for the centrifuge tube for approximately 15 minutes. Carefully decant the liquid portion and reweigh the centrifuge tube containing the residual centrifuged solids.
- 4) Calculate the percentage of solids remaining.
- 5) If the solids remaining are less than one percent of the original wet solids, 0.01 N NaOH solution water should be added to the solids and then extracted as a liquid sample. If the solids remaining are greater than 1% then the dissolved portion will be extracted as a liquid and the insoluble solids will be extracted using ultrasonication extraction.

6.0 Stepwise Instructions for Preparation of Semi-volatile Organic Samples

Note: Prior to performing SVOA extractions, perform activities defined in Sections 1.0 and 1.1 and Section 5.0. Figure 1 provides a schematic of the following steps.

6.1 Solids

- 1) Transfer 5-g aliquot (2.5-g aliquot for MS and MSD) of the centrifuged solids to a tared 200-mL centrifuge tube and weigh.
- 2) Add the surrogate spiking solution to all samples (including blank) and the target compound spiking solution to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.

Table 4		
CAS Reg. No.	Compound	ug
87-86-5	Pentachlorophenol	50
91-20-3	Naphthalene	50
95-50-1	1,2-Dichlorobenzene	50
98-95-3	Nitrobenzene	50
100-00-5	p-Nitrochlorobenzene	50
100-25-4	1,4-Dinitrobenzene	50
110-86-1	Pyridine	50
122-39-4	N,N-Diphenylamine	50
126-73-8	Tributyl phosphate	50
128-37-0	2,6-Bis(tert-butyl)-4-methylphenol	50
1319-77-3	Cresol	50
2234-13-1	Octachloronaphthalene	50
82-68-8	Pentachloronitrobenzene (PCNB)	50
88-85-7	2-sec-Butyl-4,6-dinitrophenol (Dinoseb)	50
92-52-4	1,1'-Biphenyl	50
98-86-2	Acetophenone	50
PCB MS and LCS spike compounds		
11097-69-1	PCB Arochlor 1254	0.5
Pesticides MS and LCS spike compounds		
58-89-9	Gamma-BHC	0.2
50-29-3	4, 4'-DDT	0.8
72-20-8	Endrin	0.8
76-44-8	Heptachlor	0.2
309-00-2	Aldrin	0.2
60-57-1	Dieldrin	0.8
Dioxins/Furans MS and LCS spike compounds		
1746-01-6	2,3,7,8-Tetrachlorodibenzo-p-dioxin (TCDD)	8.0
40321-76-4	1,2,3,7,8-Pentachlorodibenzo-p-dioxin (PeCDD)	40
57653-85-7	1,2,3,6,7,8-Hexachlorodibenzo-p-dioxin (HxCDD)	40
35822-39-4	1,2,3,4,6,7,8-Heptachlorodibenzo-p-dioxin (HpCDD)	40
3268-87-9	1,2,3,4,6,7,8,9-Octachlorodibenzo-p-dioxin (OCDD)	80
51207-31-9	2,3,7,8-Tetrachlorodibenzofuran (TCDF)	8.0
57117-41-6	1,2,3,7,8-Pentachlorodibenzofuran (PeCDF)	40
57117-44-9	1,2,3,6,7,8-Hexachlorodibenzofuran (HxCDF)	40
67562-39-4	1,2,3,4,6,7,8-Heptachlorodibenzofuran (HpCDF)	40
39001-02-0	1,2,3,4,6,7,8,9-Octachlorodibenzofuran (OCDF)	80

4.0 Preparation of Organic Anion Samples

The organic anion sample preparation uses a sodium-form of a cation exchange column to remove most of the radioactive cesium and strontium to reduce the overall radioactivity in the samples. Organic anion samples (1-mL supernatant samples and 1 g wet solids samples) are prepared in accordance with procedure AOAM-03. For further guidance and questions regarding execution of this procedure contact James A. Campbell, 376-0899.

5.0 Initial Testing

5.1 Determination of Titration Curves for Supernatants and Soluble Fraction of Wet Centrifuged Solids

Note: If solids are formed that do not redissolve, centrifuge and decant the liquid back into the separatory funnel used in Step 1. Cap the centrifuge tube containing the wet solids and set aside for ultra-sonic extraction.

- 5) Transfer supernatant to the separatory funnel used in Step 1 and perform a second set of three sequential separatory funnel shakeout extractions of the pH-adjusted liquid using 25-mL portions of methylene chloride. Collect and combine the three extracts in the 250-mL amber bottle labeled in Step 3.
- 6) To any solids formed in Step 4, add 2-3 times amount of anhydrous sodium sulfate desiccant and stir with a glass or metal rod until a sandy texture is obtained.
- 7) Add 25 ml of methylene chloride and ultrasonicate (pulsed) for 2 minutes. Settle (or centrifuge if necessary) and decant the extract into the 250-mL amber bottle labeled in Step 3.
- 8) Repeat Step 7 two additional times and combine the extracts.

For further guidance and questions regarding execution of these steps, and those described in Appendix A, for extraction of SVOA samples contact George S. Klinger, 372-0448.

7.0 Stepwise Instructions for Preparation of Pesticide/PCB Organic Samples

Note: Prior to performing pesticide/PCB extractions, perform activities defined in Sections 1.0 and 1.1 and Section 5.0. Figure 2 provides a schematic of the following steps.

7.1 Solids

- 1) Transfer 5-g aliquot (2.5-g aliquot for MS and MSD) of the centrifuged solids to a tared 200-mL centrifuge tube and weigh.
- 2) Add the surrogate spiking solution to all samples (including blank) and the target compound spiking solution to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.
- 3) Add 40 mL of organic-free 0.01 N NaOH solution to the centrifuge tube and ultrasonicate (pulsed) for 2 minutes.
- 4) Centrifuge the tube and decant the liquid into a tared bottle, labeled PPCB C-104 SF1.
- 5) Repeats Steps 3 and 4 and weigh bottle PPCB C-104 SF1. Set aside the wet solids for ultrasonic extraction (Step 8).
- 6) Transfer the NaOH leachate sample to a centrifuge tube and while stirring vigorously, very slowly adjust the pH of the soluble solids to near 6.5 and verify final pH. This step should be done using an ice bath to cool the sample.

Note: The quantity of acid required for adjusting the pH to near 6.5 is determined by titrating an aliquot of the NaOH leachate (i.e., soluble solids fraction) per Section 5.1.

- 3) Add 50 mL of organic-free 0.01 N NaOH solution to the centrifuge tube and ultrasonicate (pulsed) for 2 minutes.
- 4) Centrifuge the tube and decant the liquid into a tared bottle, labeled SVOA C-104 SF1, and weigh. Set aside the wet solids for ultrasonic extraction (Step 7).
- 5) Transfer the NaOH leachate sample to a centrifuge tube and while stirring vigorously, very slowly adjust the pH of the soluble solids to near 6.5 and verify final pH. This step should be done using an ice bath to cool the sample.

Note: The quantity of acid required for adjusting the pH to near 6.5 is determined by titrating an aliquot of the NaOH leachate (i.e., soluble solids fraction) per Section 5.1.

Note: If solids are formed that do not redissolve, centrifuge and decant the liquid into a separatory funnel. Cap the centrifuge tube containing the wet solids and set aside for ultrasonic extraction (Step 7).

- 6) Transfer leachate to a separatory funnel and perform a set of three sequential separatory funnel shakeout extractions of the pH-adjusted liquid using 25-mL portions of methylene chloride. Collect and combine the three extracts in the 250-mL amber bottle labeled as designated below.

C104-S-y-z

Where,

y = S for solid (centrifuged solids fraction), L for liquid (supernatant fraction)

z = B for blank, S for sample, D for sample duplicate, MS for matrix spike,
MSD matrix spike duplicate

- 7) Combine the solids reserved in Step 4 and any solids formed in Step 5 and add 2-3 times amount of anhydrous sodium sulfate desiccant and stir with a glass or metal rod until a sandy texture is obtained.
- 8) Add 25 mL of methylene chloride and ultrasonicate (pulsed) for 2 minutes. Settle (or centrifuge if necessary) and decant the extract into the 250-mL amber bottle labeled in Step 6.
- 9) Repeat Step 8 two additional times and combine the extracts.

6.2 Supernatant

- 1) Transfer 20-mL aliquot (10-mL aliquot for MS and MSD) of the C-104 supernatant into a separatory funnel and dilute with 25 mL of 0.01 N NaOH.
- 2) Add the surrogate spiking solution to all samples (including blank) and the target compound spiking solution to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.
- 3) Perform three sequential separatory funnel shakeout extractions of the supernatant using 25-mL portions of methylene chloride. Collect and combine the three extracts in a 250-mL amber bottle labeled as designated in Section 6.1 Step 6.
- 4) Transfer the sample to a centrifuge tube and while stirring vigorously, very slowly adjust the pH of the sample with the quantity of acid calculated in Section 5.1 for supernatant sample and verify final pH. This step should be done using an ice bath to cool the sample.

- 7) Add 25 ml of methylene chloride/acetone mixture (1:1) and ultrasonicate (pulsed) for 2 minutes. Settle (or centrifuge if necessary) and decant the extract into the 250-mL amber bottle labeled in Step 3.
- 8) Repeat Step 7 two additional times and combine the extracts.

For further guidance and questions regarding execution of these steps for pesticide/PCB extractions, contact Eric W. Hoppe, 376-2126.

8.0 Stepwise Instructions for Preparation of Dioxin/Furan Samples

Note: Prior to performing Dioxin/Furan extractions, perform activities defined in Sections 1.0 and 1.1 and Section 5.0. Figure 3 provides a schematic of the following steps.

- 1) Transfer 5-g aliquots (5-g aliquot for MS and MSD) of the centrifuged solids to a tared 200-mL centrifuge tube and weigh. Add the labeled spiking solution (i.e., surrogates) to all samples (including blank) and the unlabeled spiking solution (i.e., spikes) to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.
- 2) Add 2-3 times the amount of anhydrous sodium sulfate desiccant. Stir with glass or metal rod until it forms a sandy texture. Add 25 mL of methylene chloride/acetone mixture (1:1) and ultrasonicate (pulsed) for 2 minutes. Settle (or centrifuge, if necessary) and decant the extract into 250-mL amber bottle labeled as indicated below. Repeat methylene chloride/acetone extraction two more times and combine extracts.

C104-D-y-z

Where,

y = S for solid (centrifuged solids fraction), L for liquid (supernatant fraction)

z = B for blank, S for sample, D for sample duplicate, MS for matrix spike,
MSD for matrix spike duplicate.

- 3) Transfer 15 mL of the C-104 supernatant (7.5 mL for MS and MSD) into a separatory funnel and add 25 mL of 0.01 N NaOH to the separatory funnel. Add the labeled spiking solution (i.e., surrogates) to all samples (including blank) and the unlabeled spiking solution (i.e., spikes) to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.
- 4) Perform three sequential separatory funnel shakeout extractions of the supernatant using three 25-mL portions of methylene chloride. Collect and combine the three extracts in a 250-mL amber bottle labeled in Step 2.

For further guidance and questions regarding execution of these steps contact James A. Campbell, 376-0899.

Note: If solids are formed that do not redissolve, centrifuge and decant the liquid into a separatory funnel. Cap the centrifuge tube containing the wet solids and set aside for ultrasonic extraction (Step 8).

- 7) Transfer leachate to a separatory funnel and perform a set of three sequential separatory funnel shakeout extractions of the pH-adjusted liquid using 25-mL portions of methylene chloride. Collect and combine the three extracts in the 250-mL amber bottle labeled as designated below.

C104-P-y-z

Where,

y = S for solid (centrifuged solids fraction), L for liquid (supernatant fraction)

z = B for blank, S for sample, D for sample duplicate, MS for PCB matrix spike, MSD for PCB matrix spike duplicate, MSP for pesticide spike, MSDP for pesticide matrix spike duplicate

- 8) Combine the solids reserved in Step 5 and any solids formed in Step 6 and add 2-3 times amount of anhydrous sodium sulfate desiccant and stir with a glass or metal rod until a sandy texture is obtained.
- 9) Add 25 ml of methylene chloride/acetone mixture (1:1) and ultrasonicate (pulsed) for 2 minutes. Settle (or centrifuge if necessary) and decant the extract into the 250-mL amber bottle labeled in Step 7.
- 10) Repeat Step 9 two additional times and combine the extracts.

7.2 Supernatant

- 1) Transfer 10-mL aliquot of the C-104 supernatant into a separatory funnel and dilute with 25 mL of 0.01 N NaOH.
- 2) Add the surrogate spiking solution to all samples (including blank) and the target compound spiking solution to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.
- 3) Perform three sequential separatory funnel shakeout extractions of the supernatant using 25-mL portions of methylene chloride. Collect and combine the three extracts in a 250-mL amber bottle labeled as designated in Section 7.1 Step 7.
- 4) Transfer the sample to a centrifuge tube and while stirring vigorously, very slowly adjust the pH of the sample with the quantity of acid calculated in Section 5.1 for supernatant sample and verify final pH. This step should be done using an ice bath to cool the sample.

Note: If solids are formed that do not redissolve, centrifuge and decant the liquid back into the separatory funnel used in Step 1. Cap the centrifuge tube containing the wet solids and set aside for ultra-sonic extraction.

- 5) Transfer supernatant to the separatory funnel used in Step 1 and perform a second set of three sequential separatory funnel shakeout extractions of the liquid using 25-mL portions of methylene chloride. Collect and combine the three extracts in the 250-mL amber bottle labeled in Step 3.
- 6) To any solids formed in Step 4. Add 2-3 times amount of anhydrous sodium sulfate desiccant and stir with a glass or metal rod until a sandy texture is obtained.

Figure 2: Pesticide/PCB Extraction Process Diagram





Figure 1: SVOA Extraction Process Diagram



Appendix A: Semivolatile Research Sample

Prior work done on AW-101 and AN-107 samples using phosphoric acid to adjust the pH was complicated by large quantities of formed solids. It is assumed that some of the formed solids were the results of aluminum precipitation at pH less than 11 and greater than 3. It is also likely that some of the formed solids were insoluble phosphates, which were formed upon addition of the phosphoric acid.


The use of nitric acid to adjust the pH of the sample to pH 3 may have certain advantages in reducing or eliminating "formed solids" in the supernatant and the soluble portion of the centrifuged solids. Additionally, it is likely that phosphate acts in a similar fashion to sulfate in its ability to catalyze nitrate (which is present in the C-104 material at a concentration of approximately 30,000 ppm) to form the reactive nitronium ion (NO_3^+), which is a powerful nitrating agent for a variety of organics.

Nitric acid alone produces only a small quantity of "auto-catalyzed" nitronium ion. We believe that the use of nitric acid, rather than phosphoric acid, to adjust the pH of the sample may eliminate or reduce formed solids, thus reducing the number of extraction steps, and also reduce or eliminate the quantity of nitration "artifacts".

Reaction of organic amines, such as chelator fragments found in some tank samples, with nitrous acid (HONO) may also be reduced by the addition of nitric acid.

In order to test this idea for application to potential future work, one additional semivolatile sample (supernatant only) will be processed using the procedure described in Sections 5.1 and 6, using 0.1 N nitric acid, rather than phosphoric acid, for the titration of the sample and pH adjustment during the extraction.

The supernatant used for this test is to be decanted/pipetted from container "C104 COMP E".

Figure 3: Dioxin/Furan Extraction Process Diagram

APPENDIX A

Appendix A: Test Plan and ASR



902 Battelle Boulevard
P.O. Box 999
Richland, Washington 99352
Telephone (509) 376-1982
Email eugene.morrey@pnl.gov
Fax (509) 376-7127

January 28, 2000

Mr. Michael Johnson
Contracting Officer's Technical Representative
3000 George Washington Way
Mailstop: BN-FL
Richland, WA 99352

29953-114

Dear Mr. Johnson:

**TRANSMITTAL OF FINAL TEST PLAN "INORGANIC, ORGANIC AND
RADIOCHEMICAL CHARACTERIZATION OF C-104 HLW SAMPLE"
BNFL-29953-030, REV 0.**

Reference: 1) "Quality Assurance Project Plan for Testing Programs: Savannah River
Technology Center (SRTC) and Pacific Northwest National Laboratory
(PNNL), QP-W375-EN00002, Rev. 0, dated June 7, 1999.

Enclosed is a fully signed test plan of BNFL-29953-030, "Inorganic, Organic and Radiochemical Characterization of C-104 HLW Sample." The test plan details the regulatory characterization analyses to be conducted on material from Tank C-104. The test plan does not include all analyses identified in Appendix B of the recently distributed "Quality Assurance Project Plan for Testing Programs, dated June 7, 1999 (Reference 1). The electronic copy of the test plan was transmitted to you on 1/28/00 by Chrissy Charron.

Battelle's deviation from Appendix B of the referenced QA Plan is the same as those agreed to for the analysis of materials from Tanks AN-107 and AW-101. The exceptions include deletion of specific analytical tests, deletion of a few organic analytes of interest, and deletion of TCLP leach test and analysis. The Exception Section of the test plan provides further details. No costs were included in the recent Baseline Change Request (BCR) to cover the deleted analyses or analytes.

Technical matters shall be referred to Mike Urie, 376-9454.

PNNL Test Plan

Document No.: BNFL-29953-030
Rev. No.: 0

Title: Inorganic, Organic and Radiochemical Characterization of C-104 HLW Sample

Work Location:
325/SFO, 325/general labs; 329/general labs

Page 1 of 9

Author: Michael W. Urie

Effective Date: Upon final signature

Use Category Identification: Reference

Supersedes Date: New

Identified Hazards:

- ☐ Radiological
- ☐ Hazardous Materials
- ☐ Physical Hazards
- ☐ Hazardous Environment
- ☐ Other:

Required Reviewers:

- | | |
|--|---|
| <input checked="" type="checkbox"/> Technical Reviewer | <input checked="" type="checkbox"/> Project Manager |
| <input type="checkbox"/> Building Manager | <input checked="" type="checkbox"/> RPL Manager |
| <input type="checkbox"/> Radiological Control | <input checked="" type="checkbox"/> SFO Manager |
| <input type="checkbox"/> ES&H | <input checked="" type="checkbox"/> AO&AM Manager |
| <input checked="" type="checkbox"/> Quality Engineer | |

Are One-Time Modifications Allowed to this Procedure?

☒ Yes ☐ No

NOTE: If Yes, then modifications are not anticipated to impact safety. For documentation requirements of a modification see SBMS or the controlling Project QA Plan as appropriate.

On-The Job Training Required? ☐ Yes or ☒ No

FOR REVISIONS:

Is retraining to this procedure required? ☐ Yes ☒ No

Does the OJT package associated with this procedure require revision to reflect procedure changes? ☐ Yes ☐ No

☒ N/A

Approval

Signature

Date

Author Michael W. Urie 12-20-99

Technical Reviewer Gregory A. Kling 12-20-99

RPL Manager LO Casagga 11/3/2000

SFO Manager Rich A. Hale for RE THORNTON 12/20/99

Project Manager Eugene J. Mooney 12/27/99

AO&AM Manager Steven C. John 1/13/00

Quality Engineer Taffey Almeida 1-11-2000


BNFL Michael Johnson 1/19/2000

Mr. Michael Johnson

January 28, 2000

Page 2

Sincerely,

A handwritten signature in cursive script that reads "Eugene V. Morrey".

Eugene V. Morrey
Project Manager

EVM:c²

Enclosure

Cc: Mike Urie, Battelle (w/attachment)
BNFL Project File/LB

Integrity of the sub-samples and processed samples distributed throughout the laboratory will be maintained by chain-of-custody documentation. Changes to this Test Plan (initialed markups are allowed) shall be approved by the Task Manager.

Exceptions

Based on the history of the C-104 sample, exceptions are being taken to the preservation, temperature control, and hold time requirements specified by SW-846 protocols. The samples are not preserved and no refrigeration of the samples is practical at this time. Hold times, based on sampling dates, have been exceeded prior to sample receipt and starting the analytical characterization.

In some cases, sample sizes based on SW-846 protocols are not attainable due to limited sample quantity. A limited quantity of material is available for the characterization analyses, and to the extent possible, the sample material is allocated based on the PNNL method sensitivity and ability to meet Minimum Reportable Quantities (MRQ). The sample volumes and weights used for analyses may be less than the recommended values in SW-846. The effect of small sample size on detection limits and reproducibility will be discussed in the final report. Specifically, the quantity of supernatant available for analysis is insufficient to ensure that all the MRQs are met. All the supernatant from the C-104 "as received" material is targeted to support the regulatory analyses, including inorganic, radiochemical, and organic analytes of interest.

Due to the limited sample quantity, deviations from SW-846 preparation methods may be necessary (e.g., modification to organic extraction procedure). Per the QA Planning Subject Area Exhibit, modifications (e.g., single organic extraction protocol) require Task Leader approval prior to performing the analysis. Formal method qualification of minor modifications will not be performed, but the modification will be validated by the use of duplicate, matrix spikes and surrogates. Modifications, as well as minor deviations to procedures or SW-846 protocols that do not effect data quality, will be documented in the final report.

Per discussion with WDOE and BNFL, certain analyses included in the Battelle Proposal No. 29274/30406 (for AN-107, AW-101, and C-104 tank waste materials) are not being performed, specifically, Total Oil and Grease, Sulfide, Iodide, Nitrogen, Corrosion Test, Reactive Cyanide, Reactive Sulfide, and ZHE for VOA. Also, three organic analytes (ammonium perfluorooctanoate, oxirane, and picric acid) are being omitted from the organic analysis analyte list following discussions with BNFL and WDOE. Also, per letter communication from BNFL, no TCLP extractions of the solids are being conducted for either inorganic or organic constituents.

Based on radiological dose considerations, the analytical samples may be diluted to reduce the dose to laboratory staff. This may significantly impact the ability to meet the MRQs for some analytes.

Work Instructions

A simple flowchart for the sub-sampling activity is provided in Figure 1. The analysis methods are contained in Appendix A of the Battelle Proposal No. 29274/30406 and are not duplicated in this Test Plan. Analytical work is either initiated by a standard Analytical Service Request that will identify each test to be performed on the various samples and sub-samples or through the implementation of an analysis-specific test plan.

Applicability

This Test Plan describes work to be performed under Task 5.0, Double Shell Tank Analytical Support Change No. 1, for tank wastes from C-104. A composite generated from Test Plan TP-29953-031, "C-104 Sample Compositing", provide the starting material for the inorganic, organic, and radiochemical characterization of the "as received" tank waste material. Per TP-29953-031, two bottles containing approximately 340 grams of slurry and one jar containing approximately 175 grams of decanted supernatant are allocated to support the "as received" characterization analysis. The representative slurry and supernatant sub-samples are extracted from the C-104 HLW composite sample in the High Level Radiation Facility and transferred to the Shielded Analytical Laboratory for analytical sub-sampling, digestion, extraction, and distribution for analysis.

The characterization of the "as received" tank waste materials is conducted to provide key characterization information for processing, as well as to provide limited information for the permitting activities. This Test Plan covers the sub-sampling and processing of analytical samples, and the inorganic, organic and radiochemical analysis of these samples to provide both precise and accurate compositional results that meet, when possible, regulatory requirements.

This Test Plan does not cover physical properties testing on the C-104 material. Physical properties testing is to be conducted under an alternate test plan. Also, this Test Plan does not include analyses to support the dilution of the C-104 material for the CUF activities, nor does it include the inorganic and radiochemical analysis for the resulting diluted material.

Prerequisites

The majority of sub-sampling, analytical processing, and inorganic, organic and radiochemical analysis are being conducted per established and approved Battelle procedures or analytical test plans written specifically to support the work detailed in this Test Plan. The Battelle technical procedures and test plans supporting the characterization activity adhere to SW-846 protocols to the extent possible considering the limited sample volume, radiological condition, and extended target analyte list.

Hazards Assessment and Mitigation

All hazards associated with work conducted to this Test Plan have either been evaluated as part of each laboratory's Hazard Awareness Summary or as hazards unique to a specific analytical preparation or specific analytical procedures or test plans. The Hazard Awareness Summaries are posted for all laboratories in the Radiological Processing Laboratory. Hazards unique to analysis procedures are identified in the applicable procedures or test plans, and where applicable, specific Chemical Processing Permits are obtained.

Quality Control

Quality control is governed by Quality Assurance Planning Subject Area, including Exhibit "Conducting Analytical Work in Support of Regulatory Programs". The Subject Area Exhibit specifies calibration and verification requirements for analytical systems, as well as batch processing quality control samples to monitor preparation and extraction processing (i.e., blanks, duplicates, matrix spikes, matrix spike duplicates, and laboratory control standards). This Test Plan identifies those analyses for which duplicates and matrix spikes are to be performed, and the approximate quantity of sample to be used for each analysis.

Technical procedures used to support the characterization of the HLW material are either from Chemical Measurement Center Core Capabilities Manual or are project-specific procedures/test plans written specifically to support activities identified in this Test Plan. Necessary method modifications and deviations from technical procedures, test plans, or SW-846 protocols shall be documented in the final report.

1.0 Sub-Sampling and Phase Separation

The slurry and supernatant materials for "as received" characterization analysis are contained in three sample containers as described in Test Plan BNFL-29953-031. Table 1 details the container tare values and the sample masses associated with each container.

Table 1. "As Received" Sub-Samples for Characterization

Sample Material	Bottle ID	Bottle Tare (g)	Total Mass (g)	Supernatant or Slurry Mass (g)
Composite Slurry	C-104 Comp A	133.8	302.7	168.9
Composite Slurry	C-104 Comp B	133.5	303.8	170.3
Supernatant	C-104 Sup A	248.8	424.5	175.7

The composite slurry samples are to be centrifuged to provide solids and supernatant phase separation. The supernatant from the slurry samples is decanted from the "wet solids" and combined with the supernatant in C-104 Sup A. The "wet solids" remaining are to be sub-sampled immediately for weight percent solids (in duplicate) and then sub-sampled for all organic analyses, water leaching analyses (i.e., anions, tritium, and ammonia), and mercury analysis as soon as practical. Following the sub-sampling for organic analysis, water leaching analyses, and mercury analysis, the remaining solids are to be dried to allow representative sub-sampling for all other analyses to be performed at a later date (i.e., without the necessity of additional weight percent solids measurements).

2.0 Organic Analysis

Special care is taken handling both the supernatants and "wet solids" to ensure sample integrity is maintained and representative sub-samples are extracted for analysis. Organic analyses (either direct or following extraction processing) are performed on the supernatant and "wet solids" fractions, and Table 2 details the estimated sub-sampling quantities for each analysis. Appendix A identifies the organic analyte list and associates each compound with an analysis method. Organic compounds other than those listed in Appendix A that are identified during analysis will be noted in the final report.

Test plans will be used to establish the extraction protocols for each extraction process used to generate samples for organic analysis (i.e., SVOA, PCB/Pest, and/or Dioxin). In order to conserve sample material, the Matrix Spikes and Matrix Spike Duplicates may be prepared using half the sample size used for the Sample and Duplicate.

3.0 Inorganic and Radiochemistry Sub-Sampling

Where required by the analysis method, sample preparation by digestion, fusion, or leaching are performed to established and approved Battelle procedures. Table 3 details the estimated sub-sampling quantities of the supernatants, "wet solids", and "dried solids". Inorganic analytes and radionuclides of interest are included in Appendix B. Inorganic analytes and radionuclides other than those listed in Appendix A that are identified during analysis will be noted in the final report.

4.0 Analytical Service Request and Special Laboratory Instructions

This Test Plan details the sub-sampling and sample quantity requirements for processing the HLW C-104 "as received" material for inorganic, radiochemistry, and organic analysis. The Analytical Service Request form is to be used to assign unique sample identification numbers to all samples and to identify specific analyses to be performed on each sub-sample. As part of the ASR, special laboratory instructions are to be provided to the laboratory staff to ensure that all sub-sampling and preparation activities are accomplished per this Test Plan. The ASR and the special instruction require review and approval of the Task Leader and become part of the project record once approved and implemented. Changes to the ASR or special instructions also require the approval of the Task Leader.




Figure 1. Analytical Sub-Sampling Flowchart

The starting analysis material consists of two containers of representative composite slurry and one container of decanted supernatant. The supernatant from the two slurry containers and the decanted supernatant represent essentially all of the supernatant available for characterization analysis. If slurry from the two containers have to be combined prior to sub-sampling, the entire contents of the containers shall be thoroughly homogenized, by mechanical mixing, prior to extracting any sub-samples. All material sub-sampling and most analytical processing (e.g., digestions, fusions, and organic extractions) will be performed in the Shielded Analytical Laboratory due to dose levels.

Appendix A: Organic Analytes of Interest List and MRQs

CAS	Compound/Element	MRQ ug/Kg	CAS	Compound/Element	MRQ ug/Kg
PNL-ALO-346(9056)					
144-62-7	Oxalic acid	—	64-19-7	Acetic acid	—
64-18-6	Formic acid	—	79-10-7	2-Propenoic acid	—
PNL-ALO-346(3810/5021)					
121-44-8	Triethylamine	500	71-23-8	n-Propyl alcohol (1-propanol)	—
64-17-5	Ethyl alcohol	—	71-36-3	n-Butyl alcohol	900
67-56-1	Methyl alcohol (Methanol)	—	75-65-0	2-Methyl-2-propanol	—
67-63-0	2-Propyl alcohol (Isopropanol)	—	78-92-2	1-Methylpropyl alcohol (2-butanol)	—
PNL-ALO-346(8082)					
1336-36-3	Polychlorinated biphenyls (PCBs)	3300	58-89-9	gamma-BHC (Lindane)	—
309-00-2	Aldrin	22	60-57-1	Dieldrin	43
319-84-6	alpha-BHC	22	72-20-8	Endrin	43
319-85-7	beta-BHC	22	72-54-8	4,4'-DDD	—
465-73-6	Isodrin	22	76-44-8	Heptachlor	22
50-29-3	4,4'-DDT	—	8001-35-2	Toxaphene	900
PNL-ALO-345(8270C)					
100-00-5	p-Nitrochlorobenzene	—	2234-13-1	Octachloronaphthalene	—
100-25-4	1,4-Dinitrobenzene	800	50-32-8	Benzo(a)pyrene	1100
100-51-6	Benzyl alcohol	—	53-70-3	Dibenz[a,h]anthracene	2700
106-46-7	1,4-Dichlorobenzene	—	541-73-1	1,3-Dichlorobenzene	—
108-95-2	Phenol	2100	62-75-9	N-Nitroso-N,N-dimethylamine	800
110-86-1	Pyridine	5300	67-72-1	Hexachloroethane	—
1319-77-3	Cresol (1)	—	82-68-8	Pentachloronitrobenzene (PCNB)	1600
95-48-7	2-Methylphenol (Cresol isomer)	—	87-68-3	Hexachlorobutadiene	1900
106-44-5	4-Methylphenol (Cresol isomer)	—	87-86-5	Pentachlorophenol	—
117-81-7	Di-sec-octyl phthalate	—	88-85-7	2-sec-Butyl-4,6-dinitrophenol (Dinoseb)	—
117-84-0	n-diocetyl phthalate	—	91-20-3	Naphthalene	—
118-74-1	Hexachlorobenzene	3300	92-52-4	1,1'-Biphenyl	—
120-82-1	1,2,4-Trichlorobenzene	—	95-50-1	1,2-Dichlorobenzene	2000
122-39-4	N,N-Diphenylamine (2)	4300	98-86-2	Acetophenone	3200
126-73-8	Tributyl phosphate	—	98-95-3	Nitrobenzene	4700
128-37-0	2,6-Bis(tert-butyl)-4-methylphenol	—			
TEST Plan per 8290					
1746-01-6	2,3,7,8-Tetrachlorodibenzo-p-dioxin	—	57117-31-4	2,3,4,7,8-Pentachlorodibenzofuran	—
19408-74-3	1,2,3,7,8,9-Hexachlorodibenzo-p-dioxin	—	57117-41-6	1,2,3,7,8-Pentachlorodibenzofuran	—
3268-87-9	1,2,3,4,6,7,8,9-Octachlorodibenzo-p-dioxin	—	57117-44-9	1,2,3,6,7,8-Hexachlorodibenzofuran	—
35822-39-4	1,2,3,4,6,7,8-Heptachlorodibenzo-p-dioxin	—	57653-85-7	1,2,3,6,7,8-Hexachlorodibenzo-p-dioxin	—
39001-02-0	1,2,3,4,6,7,8,9-Octachlorodibenzofuran	—	60851-34-5	2,3,4,6,7,8-Hexachlorodibenzofuran	—
39227-28-6	1,2,3,4,7,8-Hexachlorodibenzo-p-dioxin	—	67562-39-4	1,2,3,4,6,7,8-Heptachlorodibenzofuran	—
40321-76-4	1,2,3,7,8-Pentachlorodibenzo-p-dioxin	—	70648-26-9	1,2,3,4,7,8-Hexachlorodibenzofuran	—
51207-31-9	2,3,7,8-Tetrachlorodibenzofuran	—	72918-21-9	1,2,3,7,8,9-Hexachlorodibenzofuran	—
55673-89-7	1,2,3,4,7,8,9-Heptachlorodibenzofuran	—			

Table 2: Organic Analytical Sub-Sampling Quantities Required ⁽¹⁾

Phase	Analysis or Procedure	Sample	Duplicate	MS/MSD	SW-846 ⁽²⁾
Wet Solids	VOA	0.5 g	0.5 g	0.5 g	5 g
	Water Leach (IC Org.)	1 g	1 g	1 g	n/a
	Extraction (SVOA)	5 g	5 g	5 g	30 g
	Extraction (PCB/Pest)	5 g	5 g	5 g	30 g
	Extraction (Dioxins)	5 g	5 g	5 g	30 g
	Sub Total	16.5 g	16.5 g	16.5 g	
	Total	49.5 g			
Supernatant	VOA	2 ml	2 ml	2 ml	5 ml
	Headspace	2 ml	2 ml	2 ml	10 g
	IC (organic anions)	1 ml	1 ml	1 ml	n/a
	Extraction (SVOA)	35 ml	35 ml	35 ml	3000 ml
	Extraction (PCB/Pest)	35 ml	35 ml	35 ml	3000 ml
	Extraction (Dioxins)	10 ml	10 ml	10 ml	3000 ml
	Sub Total	85 ml	85 ml	85 ml	
	Total	255 ml			

(1) Subsampling quantities are estimates; actual quantities used for the analyses will be dictated by the total quantity of material available for analysis.

(2) Typical SW-846 total volume for sample, duplicate, matrix spike, and matrix spiked duplicate extraction

Table 3: Inorganic/Radiochemistry Analytical Sub-Sampling Quantities Required ⁽¹⁾

Phase	Analysis or Procedure	Sample	Duplicate	MS	SW-846 ⁽²⁾
Dried Solids	Acid Digest (ICP, ICP/MS)	1 g	1 g	1 g	3 g
	KOH Fusion (ICP, ICP/MS, Radiochemistry)	0.3 g	0.3 g	0.3 g	n/a
	Na ₂ O ₂ Fusion (ICP, ICP/MS)	0.3 g	0.3 g	0.3 g	n/a
	Total CN	0.5 g	0.5 g	0.5 g	75 g
	TOC/TIC/TC	0.5 g	0.5 g	0.5 g	n/a
	Carbon-14	0.5 g	0.5 g	0.5 g	n/a
	Selenium-79	1 g	1 g	1 g	n/a
	Wt% Solids	3 g	3 g	n/a	n/a
Wet Solids	Water Leach (IC, Ammonia, H-3)	2 g	2 g	2 g	n/a
	Mercury	0.3 g	0.3 g	0.3 g	0.6 g
	Sub Totals	9.4 g	9.4 g	6.4 g	
	Total	25.2 g			
Supernatant	Acid Digest (ICP, ICP/MS, Radiochemistry)	8 ml	8 ml	8 ml	300 ml
	Dilution (ICP/MS)	1 ml	1 ml	1 ml	n/a
	IC (inorganic anions)	1 ml	1 ml	1 ml	n/a
	Mercury	1 ml	1 ml	1 ml	300 ml
	Total CN	1 ml	1 ml	1 ml	1500 ml
	TOC/TIC/TC	1 ml	1 ml	1 ml	n/a
	Carbon-14	1 ml	1 ml	1 ml	n/a
	Ammonia	2 ml	2 ml	n/a	n/a
	Tritium (H-3)	2 ml	2 ml	2 ml	n/a
	Hydroxide (OH) & pH	5 ml	5 ml	n/a	n/a
	Flashpoint	2 ml	2 ml	n/a	150 ml
	Total Dissolved Solids	5 ml	5 ml	n/a	n/a
	Density	2 ml	2 ml	n/a	n/a
	Sub Totals	32 ml	32 ml	16 ml	
	Total	80 ml			

(1) Subsampling quantities are estimates; actual quantities used for the analyses will be dictated by the total quantity of material available for analysis.

(2) Typical SW-846 total volume for sample, duplicate, and matrix spike.

Appendix B: Inorganic and Radiochemistry Analytes of Interest List

(Note: No MRQs Provided For Inorganic Analytes or Radionuclides of Interest)

ICP Analytes			
Silver	Iron	Antimony	
Aluminum	Potassium	Selenium	
Arsenic	Lanthanum ⁽¹⁾	Silicon	
Boron	Lithium	Tin	
Barium	Magnesium	Strontium ⁽¹⁾	
Beryllium	Manganese	Tellurium ⁽¹⁾	
Bismuth	Molybdenum	Thorium ⁽¹⁾	
Calcium	Sodium	Titanium ⁽¹⁾	
Cadmium	Neodymium ⁽¹⁾	Thallium	
Cerium ⁽¹⁾	Nickel	Uranium	
Cobalt	Phosphorus	Vanadium	
Chromium	Lead	Tungsten	
Copper	Palladium	Yttrium	
Dysprosium	Rhodium	Zinc	
Europium	Ruthenium ⁽¹⁾	Zirconium	
IC Analytes			
Bromide	Nitrite	Nitrate	Phosphate
Chloride	Fluoride	Sulfate	
ICP-MS Analytes			
Iodine-127	Plutonium-240	Uranium-233	
Iodine-129	Praseodymium	Uranium-234	
Neptunium-237	Rubidium	Uranium-235	
Platinum	Tantalum	Uranium-236	
Plutonium-239	Technitium-99	Uranium-238	
Radiochemistry Analytes			
Alpha, Total	Cobalt-60	Plutonium-239/240 ⁽¹⁾	
Americium-241 (AEA)	Curium-242 (AEA)	Plutonium-241	
Americium-241 (GEA) ⁽¹⁾	Curium-243/244 (AEA)	Ruthenium-106/Rhodium-106	
Beta, Total	Europium-154 (GEA)	Selenium-79	
Carbon-14	Europium-155 (GEA)	Strontium-90/Yttrium-90	
Cesium-134 (GEA)	Niobium-94 (GEA)	Tritium	
Cesium-137 (GEA)	Plutonium-238	Uranium-Fluorimetry	
Other Analytes ⁽¹⁾			
Ammonia/Ammonium	Mercury	Wt% Dissolved Solids	
Cyanide	pH (Supernatant)	Wt% Suspended Solids	
Flashpoint (Supernatant)	Total Organic Carbon		
Hydroxide (Supernatant)	Total Inorganic Carbon		
Analytes Not Analyzed per Change Request Proposal			
Total Nitrogen	Total Sulfur	Total Iodine	
Total Oil/Grease	Reactive Sulfur	Reactive Cyanide	
SS Corrosion Testing	TCLP Extractions/Analysis		

(1) Additional Analytes of Interest Measured and Reported

Appendix A: Organic Analytes of Interest List and MRQs

		MRQ			MRQ
CAS	Compound/Element	ug/Kg	CAS	Compound/Element	ug/Kg
PNL-ALO-335(8260B)					
100-41-4	Ethyl benzene	3300	141-78-6	Acetic acid ethyl ester	11000
100-42-5	Styrene	—	142-82-5	n-Heptane	—
10061-01-5	cis-1,3-Dichloropropene	6000	287-92-3	Cyclopentane	—
10061-02-6	trans-1,3-Dichloropropene	6000	4170-30-3	2-Butenaldehyde (2-Butenal)	—
106-35-4	3-Heptanone	—	56-23-5	Carbon tetrachloride	2000
106-42-3	p-Xylene & m-Xylene	3300	563-80-4	3-Methyl-2-butanone	—
106-93-4	Ethylene dibromide	5000	591-78-6	2-Hexanone	—
106-97-8	Butane	—	627-13-4	Nitric acid, propyl ester	—
106-99-0	1,3-Butadiene	—	684-16-2	Hexafluoroacetone (3)	—
107-02-8	Acrolein	—	67-64-1	2-Propanone (Acetone)	53300
107-05-1	3-Chloropropene	10000	67-66-3	Chloroform	2000
107-06-2	1,2-Dichloroethane	2000	71-43-2	Benzene	3300
107-12-0	Propionitrile	120000	71-55-6	1,1,1-Trichloroethane	2000
107-13-1	Acrylonitrile	28000	74-83-9	Bromomethane	5000
107-87-9	2-Pentanone	—	74-87-3	Chloromethane	10000
108-10-1	4-Methyl-2-pentanone	11000	75-00-3	Chloroethane	—
108-38-3	m-Xylene (See 106-42-3)	3300	75-01-4	1-Chloroethene	2000
108-87-2	Methylcyclohexane	—	75-05-8	Acetonitrile	12700
108-88-3	Toluene	3300	75-09-2	Dichloromethane (Methylene Chloride)	10000
108-90-7	Chlorobenzene	2000	75-15-0	Carbon disulfide	—
108-94-1	Cyclohexanone	—	75-34-3	1,1-Dichloroethane	2000
109-66-0	n-Pentane	—	75-35-4	1,1-Dichloroethene	2000
109-99-9	Tetrahydrofuran	—	75-43-4	Dichlorofluoromethane	—
110-12-3	5-Methyl-2-hexanone	—	75-45-6	Chlorodifluoromethane	—
110-43-0	2-Heptanone	—	75-69-4	Trichlorofluoromethane	10000
110-54-3	n-Hexane	—	75-71-8	Dichlorodifluoromethane	2400
110-82-7	Cyclohexane	—	76-13-1	1,2,2-Trichloro-1,1,2-trifluoroethane	10000
110-83-8	Cyclohexene	—	76-14-2	1,2-Dichloro-1,1,2,2-tetrafluoroethane	—
111-65-9	n-Octane	—	78-87-5	1,2-Dichloropropane	—
111-84-2	n-Nonane	—	78-93-3	2-Butanone	12000
123-19-3	4-Heptanone	—	79-00-5	1,1,2-Trichloroethane	2000
123-38-6	n-Propionaldehyde	—	79-01-6	1,1,2-Trichloroethylene	2000
123-86-4	Acetic acid n-butyl ester	—	79-34-5	1,1,2,2-Tetrachloroethane	2000
123-91-1	1,4-Dioxane	—	95-47-6	o-Xylene	3300
126-98-7	2-Methyl-2-propenenitrile	28000	96-22-0	3-Pentanone	—
127-18-4	1,1,2,2-Tetrachloroethene	2000			
PNL-ALO-345(8270C) –Standards Unavailable			PNL-ALO-346(8260B) – Very reactive		
1321-64-8	Pentachloronaphthalene	—	57-14-7	1,1-Dimethylhydrazine	—
1335-87-1	Hexachloronaphthalene	—	60-34-4	Methylhydrazine	—
1335-88-2	Tetrachloronaphthalene	—	624-83-9	Methyl isocyanate	—
Deleted per BFNL					
3825-26-1	Ammonium perfluorooctanoate	—	88-89-1	Picric acid	—
75-21-8	Oxirane	—			

(1) Cresol measured as independent Methylphenols.

(3) Toxic gas, not previously analyzed

(2) Not be distinguished from Diphenylamine

(4) "—" = No MRQ provided by BNFL

PNNL Test Plan

Document No.: BNFL-TP-29953-031

Rev. No.: 1

only working copy

Title: C-104 Sample Compositing

Work Location: 325/SFO

Page 1 of 6

Author: Paul Bredt

Effective Date: Upon Final Signature

Supersedes Date: New

Use Category Identification: Reference

Identified Hazards:

- ☐ Radiological
☐ Hazardous Materials
☐ Physical Hazards
☐ Hazardous Environment
☐ Other:

Required Reviewers:

- ☒ Author
☒ Technical Reviewer
☒ RPL Manager
☒ Project Manager
☒ RPG Quality Engineer
☐ BNFL

Are One-Time Modifications Allowed to this Procedure? ☒ Yes ☐ No

NOTE: If Yes, then modifications are not anticipated to impact safety. For documentation requirements of a modification see SBMS or the controlling Project QA Plan as appropriate.

On-The Job Training Required? ☐ Yes or ☒ No

FOR REVISIONS:

Is retraining to this procedure required? ☐ Yes ☒ NoDoes the OJT package associated with this procedure require revision to reflect procedure changes?
☐ Yes ☐ No ☒ N/A

Approval

Signature

Date

Author

Paul Bredt

5/13/99

Technical Reviewer

DE Kursth

5/18/99

RPL Manager

[Signature]

5/13/99

Project Manager

Eugene V. Moroney

5/13/99

RPG Quality Engineer

[Signature]

5-13-99

BNFL

Michael S. Johnson

5/18/99

Applicability

This Test Plan describes work to be performed under Task 2.01, LAW and HLW Feed Characterization. This work is defined under BNFL letter W375-98-0018 dated September 29, 1998. Approximately 1.7 L of material from Tank 241-C-104 have been transferred from the 222-S laboratory to the 325 HLRF. All of this material is to be used to prepare a C-104 composite.

Approximately 250 ml of the homogenous composite are to be collected for delisting and permitting activities. These samples will be withdrawn from the composite in a manner which will provide representative samples for chemical, radiochemical, and physical testing. To support the delisting and permitting, this test plan will generate samples that will allow measurement of chemical properties of the waste that are both precise and accurate. Integrity of the subsamples will be maintained consistent with prior sampling and storage history. No preservation or temperature control of the subsamples are planned. Sampling protocols in SW-846 are not strictly applicable since these protocols are targeted at sampling in the field.

Following collection of the homogenous delisting and permitting samples, all remaining standing liquid will be removed from the composite. This liquid will be submitted for additional characterization activities. The remaining solids will only contain a limited amount of interstitial liquid.

Objectives

The objectives of this test plan are the following:

- 1) Homogenize the C-104 samples shipped from 222-S to 325
- 2) Subsample the homogenous composite for chemical and radiochemical characterization
- 3) Decant all standing liquid for additional chemical and radiochemical characterization
- 4) Subsample solids for solids washing and leaching studies

Note

1. Sample material is not to contact plastic as this could complicate organic analyses. This precludes the use of plastic transfer pipettes.
2. Use "Qorpak" jars with TFE-lined closures. These bottles/closures do not introduce contamination to the samples.
3. Secondary containment is to be used wherever practical to prevent sample loss.

Quality Control

Quality control has been implemented in the work instructions.

Since this document will be used to record an experimental process, markups as specified in the RPL Operations manual section 16.6 will be allowed. The staff member performing the change initials markups to this Test Plan. The Cognizant Scientist overseeing the work initials and dates changes to the Test Plan. Changes made by the Cognizant Scientist do not require additional reviews or approvals. If changes occur to multiple pages then the Cognizant scientist shall note the effected pages and initialize the note. Superseded text shall be lined out, but not obscured, initialed and dated.

**PNNL Test Plan
Supplemental Signature Page**

Document No.: BNFL-29953-031
Rev. No.: 1

Title: C-104 Sample Compositing

Work Location: 325/SFO

Page: Supplemental

Author: Paul Bredt

Effective Date: Upon Final Signature
Supersedes Date: New

Use Category Identification: Reference

Identified Hazards:

- ☐ Radiological
- ☐ Hazardous Materials
- ☐ Physical Hazards
- ☐ Hazardous Environment
- ☐ Other:

Supplemental Reviewers:

- ☒ SFO Manager
- ☐ Building Manager
- ☐ Radiological Control
- ☐ ES&H
- ☐ Other

Approval

Signature

Date

SFO Manager



5/13/89

Building Manager

Radiological Control

ES&H

Other

Other

Other

R/G = red liquid
Green
settled solids

- 2) Weigh the sample jars listed below to ± 0.01 g. Transfer all material from the jars to the mixing vessel. If necessary, use supernatant from the jars or vessel to rinse the solids into the vessel. Reweigh the empty jars and record the mass to ± 0.01 g in the space provided.

initial + transfer on 6/17/99

Sample Label	Mass (Full)	Mass (Empty)	Mass Transferred	
16273..	273.768	123.722	150.046	R/G
16274.. chunky	290.118	132.480	157.638	R/G
16275.. chunky some solids in jar	301.270	124.835	176.435	liquid and solids on
16276..	284.182	126.970	157.212	R/G
16277.. chunky + thick some solids in jar	302.310	139.660	162.650	no standing liquid
16278.. some solids still in jar	301.512	136.640	164.872	R/G
16279.. some solids still in jar	288.623	138.978	149.645	R/G
16280..	266.863	125.061	141.802	R/G
16281..	270.904	128.296	142.608	R/G
16282.. chunky some solids in jar	299.436	139.091	160.345	no standing liquid
16283.. still some solids in jar	284.721	125.549	159.172	R/G
16284.. chunky	288.493	128.242	160.251	R/G
16285.. chunks	283.223	135.922	147.301	R/G
16286..	281.264	129.612	151.652	R/G

Examined 16281, no visible organic layer

- 3) The goal of this step is to homogenize the sample using as little force as possible. Stir the sample by slowly increasing the motor speed until the solids are mobilized. Given this work is being conducted in a steel vessel, observations need to be made with the lid off the vessel. Stir for a minimum of one hour. Record the hot cell temperature. Started stirrer 8:30am 6/23/99

collected samples starting at 9:50am Date 6/23/99 Temperature 33.7 °C

- 4) Clearing the valve: While the solids are mobilized, collect ~50 ml of sample in a clean jar. This fraction is probably high in solids due to the geometry of the vessel, so return this sample to the vessel and continue to stir the vessel.
- 5) Collect 3 ~100 ml samples in volume-graduated tared bottles listed below by removing material using the 3/4" ball valve located on the bottom of the vessel. Sufficient sample is to be collected in each jar as to minimize headspace in the jars. Weight the full bottles to ± 0.01 g and record the masses below.

collected last sample at 9:57am with cell temp of 33.8 °C.

C-104 COMP A

C-104 COMP B

C-104 GL

Total 302.685 g

Tare 133.7596 g

Slurry 89 g

168.925 PRB 6/23/99

Total 303.839 g

Tare 133.4967 g

Slurry 170.342 g

Total 291.094 g

Tare 134.5266 g

Slurry 156.567 g

- 6) Turn off the stirring motor, record the date and time. Cover the vessel using a blank flange.

Day 6/23/99 Time 10:00am

- 7) Allow C-104 COMP A, C-104 COMP B, and C-104 GL to settle for a minimum of 16 hours.

allowed vessel to settle until 6/24/99. Removed standing liquid and used to rinse the 6 jars that still contained solids
PRB 6/23/99

• very little standing liquid (<5%) on 6/24/99 @ 9:00am / AB

M&TE List:

Balance 1: Calib ID 384-06-01-004 Calib Exp Date 8/99
Location 601 rm

Balance 2: Calib ID 388-06-01-020 Calib Exp Date 8/99
Location C-Cell

Thermocouple: Calib ID 2531³²⁵⁻⁴¹⁶₀₂₉₇₁ Calib Exp Date 5/01
Location 601 Thermocouple type K

Digital Thermometer: Calib ID 2531 Calib Exp Date 5/00
Location 601

Bath Balance 3: ID 362-0601-049 exp 8/99 location B-cell

Work Instructions

- 1) The composite is to be prepared in a 3L stainless steel vessel. Secondary containment will be used to allow recovery from a possible breach of a 3L vessel or failure of the tap valve. The recommended parts for the kettles are listed below. Viton O-rings are to be used for sealing the vessel. No grease is to be used. All components (including the valve) are to be rinsed with methanol and then placed in a 102°C oven for 12 hours. The valve (packed with ultra high molecular weight polyethylene) is lightly greased with silicone. Since the valve will only see limited use, removing this grease with the methanol rinse should not effect its performance. The system is then to be assembled and leak tested using deionized water. Do not use teflon tape to assemble the vessel.

Description	Part	Vendor
UHMWPE packed 3/4" Ball Valve	SS-63ES12	Seattle Valve and Fitting
5"ID x 9.87" pipe nipple with 6.75" Comflat flange	FNF0500	Varian
6.75" blank off flange	F06750000NC4	Varian
6.75" viton gasket	FG0675VU	Varian
Nut and bolt set	FB0600C06	Varian
Clamping ring	Z12,171-1	Sigma-Aldrich
3/4" swagelok to pipe thread	SS-12-TA-1-12	Seattle Valve and Fitting
Stir rod	14-500-18	Fischer

used 0.01M NaOH to Rinse Jars (original jars from 222-S)
 then added to vessel.
 PRB 7/2/99
 BNFL-29953-031 Rev. 1
 Page 6 of 6

14) Drain the vessel into a 250 ml jar labeled C-104 RIN.

C-104 RIN

Total 372.187 g
 Tare 249.512 g
 Slurry 122.674 g

23 Na
 160
 1 H
 40 g/mole

15) Add another 50mL of 0.01M NaOH to the vessel and agitate.

16) Drain the vessel into C-104 RIN.

C-104 RIN

Total 524.96 g
 Tare 249.5128 g
 Slurry 272.447 g

17) Place sample jars C-104 COMP C, C-104 COMP D, C-104 COMP E, and C-104 RIN in a secondary container and retain for CUF studies.

0.01 M NaOH

Solution #1
 $\frac{0.01 \text{ M NaOH}}{1000 \text{ ml}} \cdot 0.1 \text{ l} = \frac{0.001 \text{ moles NaOH}}{100 \text{ ml}}$
~~Shot~~
 Shot PRB 7/13/99
 $0.001 \text{ moles} \cdot \frac{40 \text{ g}}{\text{mole}} = 0.04 \text{ g}$

Using DI in #201, added 0.0664g NaOH Fisher Brand
 Lot # 961969

and placed in plastic volumetric Flask. Brought up to
 100 ml. PRB 7/2/99

Solution #2 0.0727 g NaOH in 100 ml H₂O

PRB 7/2/99 Rinsed vessel again with another another double
 shot of 0.01M NaOH.

C-104 RIN 2

total 390.49 g
 Tare 249.5786 g
 Slurry 140.911 g

and a leaf?
 8 rocks ~1/4" in Bottom of
 vessel after draining. Yellow/Brown
 Transferred Rocks to
 C-104 SUPC
 total 265.908 g
 Tare 250.5623 g
 Rocks 15.3457 g

- 8) Record the date and time, and total volume of the slurries and volume of the settled solids in C-104 COMP A, C-104 COMP B, and C-104 GL.

Day 7/2/99 Time 8:45 am

C-104 COMP A

C-104 COMP B

C-104 GL

Total 117 ml ^{89.1}
Solids 104 ml

Total 120 ml ^{89.2}
Solids 107 ml

Total 109 ml ^{89.9}
Solids 98 ml

- 9) If the volume percent settled solids in the 3 samples are within ~10%, then the samples are representative of the whole composite and proceed to step 10. If the volume percent settled solids vary by much more than 10%, then return the slurry samples in jars C-104 COMP A, C-104 COMP B, and C-104 GL to the kettle, increase the stirring rate and repeat steps 3 through 9. Record new information and attach to this test plan.
- 10) Turn the stirrer on and allow the system to stir for ~10 minutes. While the stirrer is on, collect all the remaining material in 500 ml jars as labeled below. It is possible that up to 3 jars may be required. Record the time and date.

Day 7/2/99 Time 9:25 am

C-104 COMP C

C-104 COMP D

C-104 COMP E

Total 951.16 g
Tare 345.4623 g
Slurry 605.698 g

Total 955.90 g
Tare 347.3564 g
Slurry 608.54 g

Total 472.76 g
Tare 347.5600 g
Slurry 125.20 g

- 11) Allow samples C-104 COMP C, C-104 COMP D, and C-104 COMP E to settle for at least 3 days then transfer all standing liquid on samples C-104 COMP C, C-104 COMP D, C-104 COMP E, and C-104 GL to 250 ml jars as labeled below. This transfer is to be conducted by decanting or using clean glass pipettes. It is possible that up to 3 jars may be required. Record the time and date.

C-104 GL decanted early 8/11/99

Day 8/11/99 Time 11:45 am

C-104 SUP A

C-104 SUP B

C-104 SUP C

Total 424.51 g
Tare 248.8005 g
Slurry _____ g

Total _____ g
Tare 249.9560 g
Slurry _____ g

Total _____ g
Tare 250.5623 g
Slurry _____ g

contains several Rocks - see page 7 PAB 8/13/99

- 12) Transfer sample C-104 COMP A, C-104 COMP B, C-104 GL, C-104 SUP A, C-104 SUP B, and C-104 SUP C to the SAL with a chain of custody.

- 13) Add 50mL of 0.01M NaOH to the vessel and agitate.

C-104 SUP A after addition of sup from C-104 GL = 264.912g PAB 7/29/99
" after addition of sup from C-104 comp C = 336.017g PAB 8/11/99
" after addition of sup from C-104 comp D = 410.44g PAB 8/11/99
" after addition of sup from C-104 comp E = 424.51g REC 8-11-99

After sup removal → Comp D = 880.64g Comp C = 878.52g Comp E = 458.23g

PNNL Test Plan

Document No.: BNFL-29953-080
Rev. No.: 1

Title: Organic Extraction of C-104 Samples and sub-sampling for VOA, Headspace, and Anions

Work Location:
325/SFO, 325/general labs; 329/general labs

Page 1 of 17

Author: Michael W. Urie

Effective Date: Upon final signature
Supersedes Date: New

Use Category Identification: Reference

Identified Hazards:

- ☒ Radiological
- ☒ Hazardous Materials
- ☐ Physical Hazards
- ☐ Hazardous Environment
- ☐ Other:

Required Reviewers:

- ☒ Technical Reviewer
- ☐ Building Manager
- ☐ Radiological Control
- ☐ ES&H
- ☒ Quality Engineer
- ☒ Project Manager
- ☒ RPL Manager
- ☒ SFO Manager
- ☒ AO&AM Manager

Are One-Time Modifications Allowed to this Procedure?

☒ Yes ☐ No

NOTE: If Yes, then modifications are not anticipated to impact safety. For documentation requirements of a modification see SBMS or the controlling Project QA Plan as appropriate.









On-The Job Training Required? ☐ Yes or ☒ No

FOR REVISIONS:

Is retraining to this procedure required? ☐ Yes ☒ No

Does the OJT package associated with this procedure require revision to reflect procedure changes? ☐ Yes ☒ No

Approval

	Signature	Date
Author (VOA, SVOA)/Reviewer		6-5-00
Author (PCB, Headspace)/Reviewer		6-5-00
Author (Dioxins/Furans, Anions)/Reviewer		6-5-00
RPL Manager		6/6/00
SFO Manager		6/6/00
Project Manager/Reviewer		6-5-00
AO&AM Manager		6-5-00
Quality Engineer		6/5/00

The extractions of these C-104 HLW samples will be performed in the Shielded Analytical Laboratory within the 325 facility.

1.0 Total Dissolved Solids and Weight Percent Solids Determination

Because these samples may contain reduced iron or other magnetically separable particles, a magnetic stir-bar and magnetic stir table should not be used. A better approach is to perform the stirring with an impeller-type stirrer, such as a Teflon coated spatula rotated by a variable speed drill. After a few minutes of stirring, and once the solids appear to be suspended, a 1-g to 3-g aliquot is placed in a tared graduated centrifuge tube, weighed, and centrifuged at 1000 RPM for approximately one hour. After centrifuging, note and record the volume of both the liquid and the solids in the tube. Decant the liquid into a tared beaker, weigh and dry at 105°C overnight. Weigh the beaker after at least 12 hours of drying to determine the total dissolved solids for the supernatant. Weight percent solids determination will be performed on the centrifuged solids, remaining in the centrifuge tube, in accordance with PNL-ALO-504.

1.1 Separation of the Wet Solids from the Slurry

Centrifugation of the slurry (i.e., C104 Comp A and C104 Comp B) may be more convenient than filtration for the separation of the wet solids from the slurry. In order to centrifuge the 120-mL jars, they must first be balanced to ± 1 g. Weigh each jar and transfer the appropriate quantity of liquid from the heavier jar to the lighter jar to balance them. Place the jars in clean polyethylene sleeves, and centrifuge at no greater than 1000 RPM for 1 hour. *As a precaution, it is prudent to perform a "dry-run" first, using balanced jars containing approximately 100 mL of deionized water, and centrifuging at 1100 RPM.* After the jars containing the slurries have been centrifuged, carefully remove them from the centrifuge and the plastic sleeves. Carefully decant the supernatant into a clean jar or combine with the jar containing C-104 supernatant (i.e., container C104 SUP. A) if room is available in the container. Weigh the jar containing the wet centrifuged solids, and record this weight on the benchsheet. In the event the total quantities of supernatant and wet solids are less than those listed in test plan BNFL-29953-30, contact Michael W. Urie, 376-9454.

1.2 Sub-sampling for VOA and Headspace analysis

VOA and headspace aliquots shall be made prior to introducing methylene chloride, or other solvents, into the hot-cells.

Headspace samples should be aliquotted into clean 10-mL headspace vials and sealed with a septa-lined cap immediately afterward. A 1-mL supernatant sample, sample duplicate, sample triplicate and blank will be prepared for each sample as described in Test Plan TP-29953-030, Table 2. (Note: The sample triplicate is an additional sub-sample not identified in TP-29953-030.) A 1-mL supernatant matrix spike and matrix spike duplicate will also be aliquotted at this time. The headspace vials should be tared on an analytical balance, and each 1-mL aliquot weighed and recorded, so that the density of the supernatant can be determined during this step. Additionally, 50-microliter aliquots each of the supernatant sample, sample duplicate, sample triplicate, matrix spike, and matrix spike duplicate shall also be prepared to permit quantitation of analytes that may be outside the calibration range for a 1-mL sample size.

VOA samples should be aliquotted into clean 40-mL VOA vials and sealed with a septa-lined cap immediately afterward. A 2-mL supernatant sample, sample duplicate and blank will be prepared for each sample as described in Test Plan TP-29953-030. A 1-mL supernatant matrix spike, and matrix spike duplicate will also be aliquotted at this time. Additionally, 50-microliter aliquots of each the supernatant sample, sample duplicate, matrix spike, matrix spike duplicate shall also be prepared to permit quantitation of analytes that maybe outside the calibration range for a 2-mL sample size. Half gram aliquots of the wet centrifuged solids will be aliquotted into clean 40-mL VOA vials, diluted with organic-free water to a volume of 5 mL and sealed immediately with a septa-lined cap. The aliquots

Applicability

This Organic Extraction Test Plan describes work to be performed under Test Plan TP-29953-030, Inorganic, Organic and Radiochemical Characterization of C-104 Samples. These samples are slurries, which contain solids, and decanted liquid. Together these samples provide the starting material for the organic characterization of the "as received" materials. Per the TP-29953-030, two bottles containing about 340 grams of slurry and one jar containing about 175 grams of supernatant will be sub-sampled for VOA, headspace analysis, organic anions, SVOA, pesticide/PCB, and Dioxin/Furan analysis, as well as inorganic and radiochemistry analysis specified in the test plan. Sub-sampling and dilutions for VOA and headspace analysis will be performed prior to beginning extractions so as not to contaminate these sub-samples with solvent vapors.

Based on the history of the samples, and the limited quantities available, exceptions are being taken to the preservation, temperature control, sample size, and hold time requirements specified by SW-846 protocols. The choice of spiking solutions and extraction solvents is based upon SW-846 methods 8270C, 8081A/8082 and 8290 guidelines, where applicable.

This revision provides final documentation for the actual work performed for phase separation of the C-104 slurry, sub-sampling activities for the VOA and Headspace analyses, and the organic extraction process performed for preparing the SVOA, PCB, and Dioxin/Furan samples.

Hazards Assessment and Mitigation

The radioactive work conducted under this Test Plan is comprised of analytical organic analysis preparative operations that have been conducted routinely in the RPL and 329 Facilities. The organic extractions with small quantities of methylene chloride or methylene chloride/acetone mixtures have been performed in the Shielded Analytical Laboratory (SAL) many times and are included as a standard preparative activity on the RPL Analytical Service Request. The organic solvent extraction operations are included in the SAL work authorization. Since all of the analytical preparative operations fall within current work authorizations, no further assessment of the hazards is detailed in this Test Plan.

Quality Control

Per TP-29953-030, quality control is governed by PNNL's web-based Quality Assurance Planning Subject Area, "Conducting Analytical Work in Support of Regulatory Programs". The organic analyses will be performed in duplicate using a sample size that will closely meet regulatory reporting level for waste material. Sample sizes are specified in Test Plan TP-29953-030. Surrogate spike compounds will be added to the sample, sample duplicate, and matrix spikes in order to provide information on analyte recoveries. Separate laboratory control samples (LCS) will be prepared outside the hot-cell.

Integrity of the sub-samples and processed extracts distributed throughout the laboratory will be maintained by chain-of-custody documentation. The Task Manager shall approve changes to this Test Plan (initialed markups are allowed).

Work Instructions

An extraction scheme for the SVOA extraction activity is provided in Figure 1. Extraction schemes for PCB/pesticide and dioxin extractions are provided in Figures 2 and 3, respectively.

Total dissolved solids of the supernatant and weight percent solids of the centrifuged solids will be determined prior to sub-sampling and extracting.

Table 3 Surrogate Spike Compounds and Levels added to Samples		
Analysis	Spike Compounds	Amounts Added (ug)
Semivolatiles	phenol-d ₅	75
	2-fluorophenol	75
	2-chlorophenol-d ₄	75
	2,4,6-tribromophenol	75
	1,2-dichlorobenzene-d ₄	50
	nitrobenzene-d ₅	50
	2-fluorobiphenyl	50
Dibenzodioxins and Dibenzofurans	p-terphenyl-d ₁₄	50
	¹³ C ₁₂ -2,3,7,8 TCDD	0.05
	¹³ C ₁₂ -2,3,7,8 TCDF	0.05
	¹³ C ₁₂ -1,2,3,7,8 PeCDD	0.05
	¹³ C ₁₂ -1,2,3,7,8 PeCDF	0.05
	¹³ C ₁₂ -2,3,4,7,8 PeCDF	0.05
	¹³ C ₁₂ -1,2,3,4,7,8 HxCDD	0.05
	¹³ C ₁₂ -1,2,3,6,7,8 HxCDD	0.05
	¹³ C ₁₂ -1,2,3,4,7,8 HxCDF	0.05
	¹³ C ₁₂ -1,2,3,6,7,8 HxCDF	0.05
	¹³ C ₁₂ -1,2,3,7,8,9 HxCDF	0.05
	¹³ C ₁₂ -2,3,4,6,7,8 HxCDF	0.05
	¹³ C ₁₂ -1,2,3,4,6,7,8 HpCDD	0.05
	¹³ C ₁₂ -1,2,3,4,6,7,8 HpCDF	0.05
	¹³ C ₁₂ -1,2,3,4,7,8,9 HpCDF	0.05
Pesticides and PCBs	¹³ C ₁₂ -OCDD	0.1
	tetrachloro-m-xylene	0.040
	decachlorobiphenyl	0.040

2.1 Extraction of the supernatant portion of the HLW samples

Extractions for the SVOA supernatant sample and duplicate are performed on 20-mL aliquots, with the extractions for the SVOA matrix spike and matrix spike duplicates being performed on 10-mL aliquots. Extractions for all pesticides and PCB supernatant samples are performed on 10-mL aliquots. And, extractions for dioxins/furans supernatant sample and duplicate are performed on 15-mL aliquots, with the extractions for the dioxins/furans matrix spike and matrix spike duplicate being performed on 7.5-mL aliquots. The quantity of matrix spike used is given in Table 4. Extraction blanks shall be prepared using the same quantity of organic-free water as the quantity of supernatant sample. Stepwise instructions for performing the extractions are given in Sections 6.1, 7.1 and 8.1.

Semivolatiles

As shown in Figure 1, the supernatant portion of the as received sample is diluted with 25 mL of 0.01 N NaOH (prepared from organic-free water) prior to extraction. Following dilution the supernatant sample is extracted three times with equal portions of methylene chloride.

The supernatant sample is then pH adjusted by slow drop-wise addition of phosphoric acid while the sample is cooled in an ice-bath during the acidification. The pH-adjusted supernatant sample is extracted three times with equal portions of methylene chloride.

If during the acidification process any solids are formed at a relative quantity >1% by volume, the solids are separated, desiccated with sodium sulfate, and ultrasonic extracted three times using equal portions of methylene chloride.

All SVOA extracts from the supernatant portion of the as received sample are combined and concentrated to 1 mL outside the hot-cells.

for the VOA MS and MSD shall be 0.25-g rather than the 0.5-g aliquots used for the sample and duplicate. In a like manner, a second set of wet centrifuged solids will be aliquotted using a 50-mg sample size for each the sample, duplicate, MS and MSD.

VOA and headspace samples will be transferred from the hot-cell immediately after preparation. For further guidance or questions regarding VOA sub-sampling contact George S. Klinger, 372-0448. For further guidance or questions regarding headspace sub-sampling contact Eric W. Hoppe, 376-2126.

2.0 Extraction samples for SVOA, PCB/pesticides and Dioxins analysis

General Comments:

The quantities of the sample, sample duplicate, matrix spike, and matrix spike duplicate are given in Table 2 of Test Plan BNFL-29953-030 and restated in Section 2.1.

Teflon separatory funnels, with FEP caps, are used for the liquid-liquid extraction processing and teflon centrifuge tubes are used for the subsequent solids ultrasonic processing.

Phosphoric acid is used to adjust the pH prior to extraction of the liquids, as appropriate.

A small (0.5 ml) portion of the liquid is potentiometricly titrated to determine the quantity of phosphoric acid required to adjust the pH of the sample. The amount of precipitate formed during acidification will be evaluated and the precipitate extracted separately, if required.

Spiking solutions will be added to the sample prior to extraction. If solids formed as a result of pH adjustment warrant a separate extraction step, additional spikes will not be added as these extracts will be recombined with the "like" phase extracts.

The nominal MDLs for liquids and solids are shown in Tables 1 and 2, respectively. The surrogate spikes and quantities added are shown in Table 3. The appropriate spiking materials shall be provided by G. Klinger for SVOA, by E. Hoppe for pesticides/PCB, and J. Campbell for dioxins/furans.

Table 1 Liquid portion HLW organic analysis MDLs

Analysis	MDL (ppb, 1 L water)	MDL (ppb, 25 mL sample)
Semivolatiles	10 to 25	400 to 1000
Pesticides and PCBs	0.1 to 1	4 to 40
Dibenzodioxins and Dibenzofurans	1×10^{-4} to 1×10^{-3}	4×10^{-3} to 4×10^{-2}

Table 2 Solid portion HLW organic analysis MDLs

Analysis	MDL (ppm, 1 g solid)	MDL (ppm, 5 g sample)
Semivolatiles	10 to 25	2 to 5
Pesticides and PCBs	0.1 to 1	0.02 to 0.2
Dibenzodioxins and Dibenzofurans	1×10^{-4} to 1×10^{-3}	2×10^{-3} to 2×10^{-2}

Pesticide/PCBs

As shown in Figure 2, the solids portion of the sample is leached (with ultrasonic agitation) twice with 40 mL of organic-free 0.01 N NaOH solution. Based upon the earlier dissolution test using a 0.5-g aliquot, any solids remaining at a level greater than 1% of the original solids portion are separated and extracted separately. The NaOH leachate (i.e., dissolved solids) is extracted three times with equal portions of methylene chloride.

The NaOH leachate is then pH adjusted by slow drop-wise addition of phosphoric acid while the sample is cooled in an ice-bath during the acidification. If a solid precipitate is formed at a relative quantity of >1% by volume, it is separated and extracted separately. The pH-adjusted NaOH leachate is extracted three times with equal portions of methylene chloride.

The undissolved solids and any solids formed during the acidification process are combined, desiccated with sodium sulfate, and ultrasonic extracted three times using a 1:1 methylene chloride/acetone solution.

All pesticide/PCB extracts from the solids portion of the as received sample are combined and concentrated to 1 mL outside the hot-cells.

Dioxins/Furans

As shown in Figure 3, no liquids will be added to the solid portion of the solids sample, as was done for the SVOA and pesticide/PCB extractions. The dioxin extractions do not require a pH adjustment of the wet centrifuged solids. A desiccant is mixed with the wet solids to retain any water, and the desiccated solids are ultrasonically extracted three times with a 1:1 methylene chloride/acetone solution. The dioxin extracts are combined and concentrated to 1 mL outside the hot-cells.

3.0 Preparation and Extraction of Matrix Spikes and LCS for SVOA, Dioxins/Furans and pesticide/PCB analysis

A separate LCS will be prepared for each analysis outside the hot-cells using the sample reagents used for the extraction of the HLW samples. The LCS matrix will consist of 1 Liter of distilled water. The LCSs will be extracted using liquid-liquid extraction. The LCSs will be spiked with the compounds and levels listed in Table 4. Separate LCSs will be prepared for SVOA, Dioxin/Furans, pesticides, and PCBs. The LCS will be spiked with the same surrogates as listed in Table 3.

Table 4		
CAS Reg. No.	Compound	ug
Semivolatile MS and LSC spike compounds		
100-51-6	Benzyl alcohol	50
106-46-7	1,4-Dichlorobenzene	50
108-95-2	Phenol	50
117-81-7	Di-sec-octyl phthalate	50
117-84-0	n-dioctyl phthalate	50
118-74-1	Hexachlorobenzene	50
120-82-1	1,2,4-Trichlorobenzene	50
50-32-8	Benzo(a)pyrene	50
53-70-3	Dibenz[a,h]anthracene	50
541-73-1	1,3-Dichlorobenzene	50
62-75-9	N-Nitroso-N,N-dimethylamine	50
67-72-1	Hexachloroethane	50
87-68-3	Hexachlorobutadiene	50

Pesticides/PCB

As shown in Figure 2, the supernatant portion of the as received sample is diluted with 25 mL of 0.01 N NaOH (prepared from organic-free water) prior to extraction. Following dilution the supernatant sample is extracted three times with equal portions of methylene chloride.

The supernatant sample is then pH adjusted by slow drop-wise addition of phosphoric acid while the sample is cooled in an ice-bath during the acidification. The pH-adjusted supernatant sample is extracted three times with equal portions of methylene chloride.

If during the acidification process any solids are formed at a relative quantity >1% by volume, the solids are separated, desiccated with sodium sulfate, and ultrasonic extracted three times using equal portions of a 1:1 methylene chloride/acetone mixture.

All extracts from the supernatant portion of the as received sample are combined and concentrated to 1 mL outside the hot-cells.

Dioxins/Furans

Adjustment of the pH is presumed not to be necessary for the dioxin/furan extractions. To dilute the sample, 25 mL of 0.01 N NaOH (prepared from organic-free water) will be added to the sample prior to extraction. As shown in Figures 3, a supernatant sample is extracted (liquid-liquid) three times with equal portions of methylene chloride. The extracts from the supernatant portion of the as received sample are combined and concentrated to 1 mL outside the hot-cells.

2.2 Extraction of the centrifuged solids portion of the HLW samples

The solid sample and duplicate will be extracted using 5 g of the solids portion of the as received sample. A matrix spike and spike duplicate will be extracted using 2.5 g of sample. The quantity of matrix spike used is given in Table 4. Leach blanks shall be prepared using the same quantity of organic-free water as the quantity of 0.01 N NaOH added to the sample. Stepwise instructions for performing the extractions are given in Sections 6.2, 7.2 and 8.2.

SVOAs

As shown in Figure 1, the solids portion of the as received sample is leached (with ultrasonic agitation) once with 50 mL of organic-free 0.01 N NaOH solution. Based upon the earlier dissolution test using a 0.5-g aliquot, any solids remaining at a level greater than 1% of the original solids portion are separated and extracted separately. The NaOH leachate (i.e., dissolved solids) is extracted three times with equal portions of methylene chloride.

The NaOH leachate is then pH adjusted by slow drop-wise addition of phosphoric acid while the sample is cooled in an ice-bath during the acidification. If a solid precipitate is formed at a relative quantity of >1% by volume, it is separated and extracted separately. The pH-adjusted NaOH leachate is extracted three times with equal portions of methylene chloride.

The undissolved solids and any solids formed during the acidification process are combined, desiccated with sodium sulfate, and ultrasonic extracted three times using methylene chloride.

All SVOA extracts from the solids portion of the as received sample are combined and concentrated to 1 mL outside the hot cells.

- 1) Transfer a 0.5-mL aliquot of the supernatant (or soluble solids fraction) into a tared 100-mL beaker and weigh.
- 2) Add 10 mL of 0.01 N sodium hydroxide solution (prepared from organic-free water) and a clean magnetic stir bar to the beaker containing the aliquot. Measure and record the initial pH.
- 3) Titrate the sample to pH 2 using 0.1 N H_3PO_4 solution. Record the acid volume, temperature and pH at $\Delta 0.1 - 0.2$ pH units. Note the acid volume and pH at the point where any precipitation begins to occur, or redissolve. Repeat this titration using 0.1 N HNO_3 solution.
- 4) Using the titration spreadsheet, plot the curves for both the supernatant and soluble solids fraction.
- 5) Closely examine the curves. Find a region of the curve where the pH is near 6.5 and exhibits some buffering behavior. Calculate the quantity of acid needed per gram of sample to adjust the pH to the midpoint of this region. Review the data with the cognizant scientist prior to adjusting the pH of the extraction sample.

5.2 Determination of Insoluble Solids Content

- 1) Transfer a 0.5-g aliquot of the centrifuged solids into a tared centrifuge tube and weigh.
- 2) Add 10 mL of 0.01 N NaOH solution in 1-mL aliquots. After each addition, swirl the centrifuge tube for a few minutes and observe and record any dissolution of the solid that appears to occur after each addition. If all of the solids dissolve before 10 mL of 0.01 N NaOH solution have been added, record this volume for use in Step 1, Sections 6 and 7.
- 3) Centrifuge the tube at the highest safe speed for the centrifuge tube for approximately 15 minutes. Carefully decant the liquid portion and reweigh the centrifuge tube containing the residual centrifuged solids.
- 4) Calculate the percentage of solids remaining.
- 5) If the solids remaining are less than one percent of the original wet solids, 0.01 N NaOH solution water should be added to the solids and then extracted as a liquid sample. If the solids remaining are greater than 1% then the dissolved portion will be extracted as a liquid and the insoluble solids will be extracted using ultrasonication extraction.

6.0 Stepwise Instructions for Preparation of Semi-volatile Organic Samples

Note: Prior to performing SVOA extractions, perform activities defined in Sections 1.0 and 1.1 and Section 5.0. Figure 1 provides a schematic of the following steps.

6.1 Solids

- 1) Transfer 5-g aliquot (2.5-g aliquot for MS and MSD) of the centrifuged solids to a tared 200-mL centrifuge tube and weigh.
- 2) Add the surrogate spiking solution to all samples (including blank) and the target compound spiking solution to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.

Table 4		
CAS Reg. No.	Compound	ug
87-86-5	Pentachlorophenol	50
91-20-3	Naphthalene	50
95-50-1	1,2-Dichlorobenzene	50
98-95-3	Nitrobenzene	50
100-00-5	p-Nitrochlorobenzene	50
100-25-4	1,4-Dinitrobenzene	50
110-86-1	Pyridine	50
122-39-4	N,N-Diphenylamine	50
126-73-8	Tributyl phosphate	50
128-37-0	2,6-Bis(tert-butyl)-4-methylphenol	50
1319-77-3	Cresol	50
2234-13-1	Octachloronaphthalene	50
82-68-8	Pentachloronitrobenzene (PCNB)	50
88-85-7	2-sec-Butyl-4,6-dinitrophenol (Dinoseb)	50
92-52-4	1,1'-Biphenyl	50
98-86-2	Acetophenone	50
PCB MS and LCS spike compounds		
11097-69-1	PCB Arochlor 1254	0.5
Pesticides MS and LCS spike compounds		
58-89-9	Gamma-BHC	0.2
50-29-3	4, 4'-DDT	0.8
72-20-8	Endrin	0.8
76-44-8	Heptachlor	0.2
309-00-2	Aldrin	0.2
60-57-1	Dieldrin	0.8
Dioxins/Furans MS and LCS spike compounds		
1746-01-6	2,3,7,8-Tetrachlorodibenzo-p-dioxin (TCDD)	8.0
40321-76-4	1,2,3,7,8-Pentachlorodibenzo-p-dioxin (PeCDD)	40
57653-85-7	1,2,3,6,7,8-Hexachlorodibenzo-p-dioxin (HxCDD)	40
35822-39-4	1,2,3,4,6,7,8-Heptachlorodibenzo-p-dioxin (HpCDD)	40
3268-87-9	1,2,3,4,6,7,8,9-Octachlorodibenzo-p-dioxin (OCDD)	80
51207-31-9	2,3,7,8-Tetrachlorodibenzofuran (TCDF)	8.0
57117-41-6	1,2,3,7,8-Pentachlorodibenzofuran (PeCDF)	40
57117-44-9	1,2,3,6,7,8-Hexachlorodibenzofuran (HxCDF)	40
67562-39-4	1,2,3,4,6,7,8-Heptachlorodibenzofuran (HpCDF)	40
39001-02-0	1,2,3,4,6,7,8,9-Octachlorodibenzofuran (OCDF)	80

4.0 Preparation of Organic Anion Samples

The organic anion sample preparation uses a sodium-form of a cation exchange column to remove most of the radioactive cesium and strontium to reduce the overall radioactivity in the samples. Organic anion samples (1-mL supernatant samples and 1 g wet solids samples) are prepared in accordance with procedure AOAM-03. For further guidance and questions regarding execution of this procedure contact James A. Campbell, 376-0899.

5.0 Initial Testing

5.1 Determination of Titration Curves for Supernatants and Soluble Fraction of Wet Centrifuged Solids

Note: If solids are formed that do not redissolve, centrifuge and decant the liquid back into the separatory funnel used in Step 1. Cap the centrifuge tube containing the wet solids and set aside for ultra-sonic extraction.

- 5) Transfer supernatant to the separatory funnel used in Step 1 and perform a second set of three sequential separatory funnel shakeout extractions of the pH-adjusted liquid using 25-mL portions of methylene chloride. Collect and combine the three extracts in the 250-mL amber bottle labeled in Step 3.
- 6) To any solids formed in Step 4, add 2-3 times amount of anhydrous sodium sulfate desiccant and stir with a glass or metal rod until a sandy texture is obtained.
- 7) Add 25 ml of methylene chloride and ultrasonicate (pulsed) for 2 minutes. Settle (or centrifuge if necessary) and decant the extract into the 250-mL amber bottle labeled in Step 3.
- 8) Repeat Step 7 two additional times and combine the extracts.

For further guidance and questions regarding execution of these steps, and those described in Appendix A, for extraction of SVOA samples contact George S. Klinger, 372-0448.

7.0 Stepwise Instructions for Preparation of Pesticide/PCB Organic Samples

Note: Prior to performing pesticide/PCB extractions, perform activities defined in Sections 1.0 and 1.1 and Section 5.0. Figure 2 provides a schematic of the following steps.

7.1 Solids

- 1) Transfer 5-g aliquot (2.5-g aliquot for MS and MSD) of the centrifuged solids to a tared 200-mL centrifuge tube and weigh.
- 2) Add the surrogate spiking solution to all samples (including blank) and the target compound spiking solution to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.
- 3) Add 40 mL of organic-free 0.01 N NaOH solution to the centrifuge tube and ultrasonicate (pulsed) for 2 minutes.
- 4) Centrifuge the tube and decant the liquid into a tared bottle, labeled PPCB C-104 SF1.
- 5) Repeats Steps 3 and 4 and weigh bottle PPCB C-104 SF1. Set aside the wet solids for ultrasonic extraction (Step 8).
- 6) Transfer the NaOH leachate sample to a centrifuge tube and while stirring vigorously, very slowly adjust the pH of the soluble solids to near 6.5 and verify final pH. This step should be done using an ice bath to cool the sample.

Note: The quantity of acid required for adjusting the pH to near 6.5 is determined by titrating an aliquot of the NaOH leachate (i.e., soluble solids fraction) per Section 5.1.

- 3) Add 50 mL of organic-free 0.01 N NaOH solution to the centrifuge tube and ultrasonicate (pulsed) for 2 minutes.
- 4) Centrifuge the tube and decant the liquid into a tared bottle, labeled SVOA C-104 SF1, and weigh. Set aside the wet solids for ultrasonic extraction (Step 7).
- 5) Transfer the NaOH leachate sample to a centrifuge tube and while stirring vigorously, very slowly adjust the pH of the soluble solids to near 6.5 and verify final pH. This step should be done using an ice bath to cool the sample.

Note: The quantity of acid required for adjusting the pH to near 6.5 is determined by titrating an aliquot of the NaOH leachate (i.e., soluble solids fraction) per Section 5.1.

Note: If solids are formed that do not redissolve, centrifuge and decant the liquid into a separatory funnel. Cap the centrifuge tube containing the wet solids and set aside for ultrasonic extraction (Step 7).

- 6) Transfer leachate to a separatory funnel and perform a set of three sequential separatory funnel shakeout extractions of the pH-adjusted liquid using 25-mL portions of methylene chloride. Collect and combine the three extracts in the 250-mL amber bottle labeled as designated below.

C104-S-y-z

Where,

y = S for solid (centrifuged solids fraction), L for liquid (supernatant fraction)

z = B for blank, S for sample, D for sample duplicate, MS for matrix spike,
MSD matrix spike duplicate

- 7) Combine the solids reserved in Step 4 and any solids formed in Step 5 and add 2-3 times amount of anhydrous sodium sulfate desiccant and stir with a glass or metal rod until a sandy texture is obtained.
- 8) Add 25 mL of methylene chloride and ultrasonicate (pulsed) for 2 minutes. Settle (or centrifuge if necessary) and decant the extract into the 250-mL amber bottle labeled in Step 6.
- 9) Repeat Step 8 two additional times and combine the extracts.

6.2 Supernatant

- 1) Transfer 20-mL aliquot (10-mL aliquot for MS and MSD) of the C-104 supernatant into a separatory funnel and dilute with 25 mL of 0.01 N NaOH.
- 2) Add the surrogate spiking solution to all samples (including blank) and the target compound spiking solution to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.
- 3) Perform three sequential separatory funnel shakeout extractions of the supernatant using 25-mL portions of methylene chloride. Collect and combine the three extracts in a 250-mL amber bottle labeled as designated in Section 6.1 Step 6.
- 4) Transfer the sample to a centrifuge tube and while stirring vigorously, very slowly adjust the pH of the sample with the quantity of acid calculated in Section 5.1 for supernatant sample and verify final pH. This step should be done using an ice bath to cool the sample.

- 7) Add 25 ml of methylene chloride/acetone mixture (1:1) and ultrasonicate (pulsed) for 2 minutes. Settle (or centrifuge if necessary) and decant the extract into the 250-mL amber bottle labeled in Step 3.
- 8) Repeat Step 7 two additional times and combine the extracts.

For further guidance and questions regarding execution of these steps for pesticide/PCB extractions, contact Eric W. Hoppe, 376-2126.

8.0 Stepwise Instructions for Preparation of Dioxin/Furan Samples

Note: Prior to performing Dioxin/Furan extractions, perform activities defined in Sections 1.0 and 1.1 and Section 5.0. Figure 3 provides a schematic of the following steps.

- 1) Transfer 5-g aliquots (5-g aliquot for MS and MSD) of the centrifuged solids to a tared 200-mL centrifuge tube and weigh. Add the labeled spiking solution (i.e., surrogates) to all samples (including blank) and the unlabeled spiking solution (i.e., spikes) to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.
- 2) Add 2-3 times the amount of anhydrous sodium sulfate desiccant. Stir with glass or metal rod until it forms a sandy texture. Add 25 mL of methylene chloride/acetone mixture (1:1) and ultrasonicate (pulsed) for 2 minutes. Settle (or centrifuge, if necessary) and decant the extract into 250-mL amber bottle labeled as indicated below. Repeat methylene chloride/acetone extraction two more times and combine extracts.

C104-D-y-z

Where,

y = S for solid (centrifuged solids fraction), L for liquid (supernatant fraction)

z = B for blank, S for sample, D for sample duplicate, MS for matrix spike,
MSD for matrix spike duplicate.

- 3) Transfer 15 mL of the C-104 supernatant (7.5 mL for MS and MSD) into a separatory funnel and add 25 mL of 0.01 N NaOH to the separatory funnel. Add the labeled spiking solution (i.e., surrogates) to all samples (including blank) and the unlabeled spiking solution (i.e., spikes) to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.
- 4) Perform three sequential separatory funnel shakeout extractions of the supernatant using three 25-mL portions of methylene chloride. Collect and combine the three extracts in a 250-mL amber bottle labeled in Step 2.

For further guidance and questions regarding execution of these steps contact James A. Campbell, 376-0899.

Note: If solids are formed that do not redissolve, centrifuge and decant the liquid into a separatory funnel. Cap the centrifuge tube containing the wet solids and set aside for ultrasonic extraction (Step 8).

- 7) Transfer leachate to a separatory funnel and perform a set of three sequential separatory funnel shakeout extractions of the pH-adjusted liquid using 25-mL portions of methylene chloride. Collect and combine the three extracts in the 250-mL amber bottle labeled as designated below.

C104-P-y-z

Where,

y = S for solid (centrifuged solids fraction), L for liquid (supernatant fraction)

z = B for blank, S for sample, D for sample duplicate, MS for PCB matrix spike, MSD for PCB matrix spike duplicate, MSP for pesticide spike, MSDP for pesticide matrix spike duplicate

- 8) Combine the solids reserved in Step 5 and any solids formed in Step 6 and add 2-3 times amount of anhydrous sodium sulfate desiccant and stir with a glass or metal rod until a sandy texture is obtained.
- 9) Add 25 ml of methylene chloride/acetone mixture (1:1) and ultrasonicate (pulsed) for 2 minutes. Settle (or centrifuge if necessary) and decant the extract into the 250-mL amber bottle labeled in Step 7.
- 10) Repeat Step 9 two additional times and combine the extracts.

7.2 Supernatant

- 1) Transfer 10-mL aliquot of the C-104 supernatant into a separatory funnel and dilute with 25 mL of 0.01 N NaOH.
- 2) Add the surrogate spiking solution to all samples (including blank) and the target compound spiking solution to the MS and MSD. Use the entire contents of the vial(s) provided for spiking. After transferring the contents of the spiking vial to the sample, add approximately 0.2 mL of methylene chloride to the vial(s) and transfer this rinsate to the sample.
- 3) Perform three sequential separatory funnel shakeout extractions of the supernatant using 25-mL portions of methylene chloride. Collect and combine the three extracts in a 250-mL amber bottle labeled as designated in Section 7.1 Step 7.
- 4) Transfer the sample to a centrifuge tube and while stirring vigorously, very slowly adjust the pH of the sample with the quantity of acid calculated in Section 5.1 for supernatant sample and verify final pH. This step should be done using an ice bath to cool the sample.

Note: If solids are formed that do not redissolve, centrifuge and decant the liquid back into the separatory funnel used in Step 1. Cap the centrifuge tube containing the wet solids and set aside for ultra-sonic extraction.

- 5) Transfer supernatant to the separatory funnel used in Step 1 and perform a second set of three sequential separatory funnel shakeout extractions of the liquid using 25-mL portions of methylene chloride. Collect and combine the three extracts in the 250-mL amber bottle labeled in Step 3.
- 6) To any solids formed in Step 4. Add 2-3 times amount of anhydrous sodium sulfate desiccant and stir with a glass or metal rod until a sandy texture is obtained.

Figure 2: Pesticide/PCB Extraction Process Diagram





Figure 1: SVOA Extraction Process Diagram



Appendix A: Semivolatile Research Sample

Prior work done on AW-101 and AN-107 samples using phosphoric acid to adjust the pH was complicated by large quantities of formed solids. It is assumed that some of the formed solids were the results of aluminum precipitation at pH less than 11 and greater than 3. It is also likely that some of the formed solids were insoluble phosphates, which were formed upon addition of the phosphoric acid.


The use of nitric acid to adjust the pH of the sample to pH 3 may have certain advantages in reducing or eliminating "formed solids" in the supernatant and the soluble portion of the centrifuged solids. Additionally, it is likely that phosphate acts in a similar fashion to sulfate in its ability to catalyze nitrate (which is present in the C-104 material at a concentration of approximately 30,000 ppm) to form the reactive nitronium ion (NO_3^+), which is a powerful nitrating agent for a variety of organics.

Nitric acid alone produces only a small quantity of "auto-catalyzed" nitronium ion. We believe that the use of nitric acid, rather than phosphoric acid, to adjust the pH of the sample may eliminate or reduce formed solids, thus reducing the number of extraction steps, and also reduce or eliminate the quantity of nitration "artifacts".

Reaction of organic amines, such as chelator fragments found in some tank samples, with nitrous acid (HONO) may also be reduced by the addition of nitric acid.

In order to test this idea for application to potential future work, one additional semivolatile sample (supernatant only) will be processed using the procedure described in Sections 5.1 and 6, using 0.1 N nitric acid, rather than phosphoric acid, for the titration of the sample and pH adjustment during the extraction.

The supernatant used for this test is to be decanted/pipetted from container "C104 COMP E".

Figure 3: Dioxin/Furan Extraction Process Diagram

Analytical Service Request (ASR)

(Information on this COVER PAGE is applicable to all samples submitted under this ASR)

RECORD COPY

Requestor --- Complete all fields on this COVER PAGE, unless specified as optional or ASR is a revision

Requestor:

Signature

M. W. Urie

Print Name

M. W. URIE

Phone

376-9454

MSIN

P722

PNNL Project #:

29274 (W49436)

Charge Code:

MISC (W45578)

Date Required:

SEE INSTRUCTIONS
APRIL 7, 2000

Matrix Type Information

- ◆ Liquids: ☐ Aqueous ☐ Organic ☐ Multi-phase
- ◆ Solids: ☐ Soil ☐ Sludge ☐ Sediment
- ☐ Glass ☐ Filter ☐ Metal
- ☐ Smear ☐ Organic ☐ Other
- ◆ Other: ☒ Solid/Liquid Mixture, Slurry
- ☐ Gas ☐ Biological Specimen

If sample matrices vary, specify on Request Page

QA/Special Requirements

- ◆ QA Plan: SBMS ☐
- HASQARD (CAWSRP) ☒
- ◆ Additional QA Requirements? No ☒ or Reference Doc # ☐
- ◆ Field COC? No ☐ Yes ☒
- ◆ Lab COC Required? No ☐ Yes ☒
- ◆ Hold Time: None ☒ or RCRA ☐ CERCLA ☐
- Other, Specify ☐
- & Date Sampled ☐ Time Sampled ☐
- ◆ Special Storage Requirements: None ☒ Refrigerate (4°C) ☐
- or Other, specify ☐
- ◆ Data Quality Review Required? No ☒ Yes ☐

Disposal Information

◆ Disposition of Virgin Samples:

Virgin samples are returned to requestor unless archiving provisions are made with receiving group!

If archiving, provide:

Archiving Reference Doc # ☐

◆ Disposition of Treated Samples:

Dispose ☒ Return ☐

Waste Designation Information

- ◆ Sample Information Check List Attached? Yes ☒ or Reference Doc # ☐
- or Previous ASR # ☐
- or Previous RPL ID # ☐

Does the Waste Designation Documentation Indicate Presence of PCBs? No ☒ Yes ☐

Additional or Special Instructions

See Special instruction (Attached)

Send Report To

M Urie

Phone

376-9454

Phone

Preliminary results requested, as available? No ☒ Yes ☐ (requesting preliminary results may increase cost)

Receiving and Login Information (to be completed by laboratory staff)

Date Delivered:

2-14-00

Delivered By (optional)

HLRF STAFF

Received By:

SAL STAFF

Time Delivered (optional)

Group ID (optional)

ASR Number:

5729

CMC Waste Sample?

No ☒

Yes ☐

RPL Numbers:

(00-1360) - (00-1361)

Cost Estimate, if requested: \$ ☐

RPG/CMC Work Accepted By:

M W Urie

Signature/Date:

MW Urie 2-25-00

Analytical Service Request (ASR)
(REQUEST PAGE ----- Information Specific to Individual Samples)

Page 1 of 1

ASR 5729

00-01360 C-104 Supernatant Composite

Density/Solution	SAL	-- Use W49436
Wt% Solids/TDS	SAL	-- Use W49436
Digestion-128	SAL	-- Use W49436
ICP-211-CMC	LAB	-- Use CMC WP Number
ICP/MS	ADV INORG	-- Use W49439
GEA-381/474-CMC	RAD	-- Use CMC WP Number
Alpha/Gross-4001/408-CMC	RAD	-- Use CMC WP Number
Beta/Gross-4001/408-CMC	RAD	-- Use CMC WP Number
Am,Cm/AEA-417/422-CMC	RAD	-- Use CMC WP Number
Pu/AEA-417/422-CMC	RAD	-- Use CMC WP Number
U/KPA-4014-CMC	RAD	-- Use CMC WP Number
Sr-90-476/408-CMC	RAD	-- Use CMC WP Number
Se79-440/474-CMC	RAD	-- Use CMC WP Number
IC-212-CMC	LAB	-- Use CMC WP Number
ICP/MS	ADV INORG	-- Use W49439
TOC/TIC-381-CMC	LAB	-- Use CMC WP Number
TOC/TIC-380-CMC	LAB	-- Use CMC WP Number
NH3-ISE	LAB	-- Use W49439
Flashpoint	LAB	-- Use W49439
CN/Total	LAB	-- Use W49439
H3-418/474-CMC	RAD	-- Use CMC WP Number
C14-381/474-CMC	RAD	-- Use CMC WP Number
Hg-131/201-CMC	LAB	-- Use CMC WP Number
OH-/Titration-228-CMC	LAB	-- Use CMS WP Number
pH/Solution	LAB	-- Use W49439
Ext-S/SVOA	SAL	-- Use W49436
SVOA/GCMS	ORG	-- Use W49440
Ext-Solvent (for PCB)	SAL	-- Use W49436
PCB/Pesticides	ORG	-- Use W49441
Ext-Solvent (for Dioxins)	SAL	-- Use W49436
Dioxins/Furans	ORG	-- Use W49441 (this test needs added to DB)
IC-Organic	ORG	-- Use W49441 (this test needs added to DB)
Headspace	ORG	-- Use W49441 (this test needs added to DB)
VOA/GCMS	ORG	-- Use W49440

00-01361 C-104 Centrifuged Solids Composite

Wt% Solids/Total (after phase separation)	SAL	-- Use W49436
Digestion-129	SAL	-- Use W49436
ICP-211-CMC	LAB	-- Use CMC WP Number
Fusion-115	SAL	-- Use W49436
ICP-211-CMC	LAB	-- Use CMC WP Number
ICP/MS	ADV INORG	-- Use W49439
GEA-381/474-CMC	RAD	-- Use CMC WP Number
Alpha/Gross-4001/408-CMC	RAD	-- Use CMC WP Number
Beta/Gross-4001/408-CMC	RAD	-- Use CMC WP Number
Am,Cm/AEA-417/422-CMC	RAD	-- Use CMC WP Number
Pu/AEA-417/422-CMC	RAD	-- Use CMC WP Number
U/KPA-4014-CMC	RAD	-- Use CMC WP Number
Sr-90-476/408-CMC	RAD	-- Use CMC WP Number
Sc79-440/474-CMC	RAD	-- Use CMC WP Number
Fusion-116	SAL	-- Use W49436
ICP/MS	ADV INORG	-- Use W49439
Leach/Water-103	SAL	-- Use W49436
IC-212-CMC	LAB	-- Use CMC WP Number
NH3-ISE	LAB	-- Use W49439
H3-418/474-CMC	RAD	-- Use CMC WP Number
TOC/TIC-381-CMC	LAB	-- Use CMC WP Number
TOC/TIC-380-CMC	LAB	-- Use CMC WP Number
CN/Total	LAB	-- Use W49439
C14-381/474-CMC	RAD	-- Use CMC WP Number
Hg-131/201-CMC	LAB	-- Use CMC WP Number
Ext-S/SVOA	SAL	-- Use W49436
SVOA/GCMS	ORG	-- Use W49440
Ext-Solvent (for PCB)	SAL	-- Use W49436
PCB/Pesticides	ORG	-- Use W49441
Ext-Solvent (for Dioxins)	SAL	-- Use W49436
Dioxins/Furans	ORG	-- Use W49441 (this test needs added to DB)
IC-Organic	ORG	-- Use W49441 (this test needs added to DB)
Headspace	ORG	-- Use W49441 (this test needs added to DB)
VOA/GCMS	ORG	-- Use W49440

Special Instructions (Revision 1) for ASR 5729

General Comment: This ASR is to complete the work defined by Test Plan BNFL-29953-30 Rev 0. Should sample quantities or other issues prohibit performing the work as defined, contact M.W. Urie (376-9454.)

The "C-104 Supernatant Composite" and "C-104 Centrifuged Solids Composite" are prepared from the C-104 material supplied under COC BNFL-48 (i.e., C-104 Comp A, C-104 Comp B, and C-104 Sup A).

For both the supernatant and centrifuged solids sample, all organic analyses require Sample, Duplicate, Matrix Spike, and Matrix Spike Duplicate, and all inorganic and radiochemical analyses require Sample, Duplicate, Matrix Spike (except Wt% solids, OH, Flashpoint, density, and TDS which do not require a Matrix Spike). Only the ICP (acid digest only), SVOA, PCB/Pesticides, and Dioxin spiking solutions are to be added to Matrix Spikes during processing in the SAL. Process Blanks and Blank Spikes/LCSs are to be processed per the governing QA Plan.

Movement of sub-samples or processed samples from the SAL to the laboratories shall be done under Lab COC.

All supernatant results are to be reported on a per milliliter of supernatant basis and all centrifuged solids are to be reported on a per gram of wet centrifuged solids basis.

1. Prior to beginning the phase separation of the slurry material (C-104 Comp A and C-104 Comp B), sub-sampling for TDS and Wt% Solids (on centrifuged solids) is to be conducted and the tests performed per Test Instruction (TI) BNFL-29953-80 Rev 0.
2. The phase separation of the slurry material is to be conducted per instructions in TI BNFL-29953-80 Rev 0. All separated supernatant from C-104 Comp A and C-104 Comp B and supernatant from C-104 Sup A should be combined into single container.
3. All centrifuged solids sub-sampling activities that need to use undried solids should be conducted as soon as possible following phase separation. This includes VOA, Water Leach sub-samples, cyanide, mercury, C-14, and TOC/TIC.
4. Following the solids sub-sampling activities, all organic sub-sampling and preparative activities (solids or supernatant) should be completed, per TI BNFL-29953-80 Rev 0, as soon as possible and prior to any additional inorganic or radiochemical sub-sampling or processing.
5. Following the organic sub-sampling and processing/extraction activities, the remaining centrifuged solids should be dried to constant weight and mixed well prior to sub-sampling for further processing (e.g., for digestions, fusions). (If a large quantity of centrifuged solids remain following the organic activities, not all of the solids need to be dried.)

APPENDIX B

Appendix B: Analytical Data

Battelle PNNL/RPL/Inorganic Analysis ... ICPAES Data Report

Project: 29274 / W49436
Client: M. Urie

REVISION 1

RPL Number(s): 00-01360 & 00-01361

Client ID: "C-104 Supernatant Composite" &
"C-104 Centrifuged Solids Composite"

ASR Number: 5729

Total Samples: 2


Procedure: PNL-ALO-211, "Determination of Elements by Inductively Coupled
Argon Plasma Atomic Emission Spectrometry" (ICP-AES).


Analyst: JJ Wagner

Analysis Date (Filename): 04-20-00 (A0597 K/Ni), 04-26-00 (A0599 ALO-128/-129)

See Chemical Measurement Center 98620: ICP-325-405-1 File for Calibration and
Maintenance Records.

M&TE Number: ICPAES instrument -- WB73520
Mettler AT400 Balance -- Ser.No. 360-06-01-029

 6-12-00
Reviewed by

 6-12-00
Concur

6/12/00

Battelle PNNL/RPL/Inorganic Analysis ... ICPAES Data Report

ASR-5729

One radioactive liquid sample, **C-104 Supernatant Composite** (RPL# 00-01360), was prepared in duplicate by the Shielded Analytical Laboratory (SAL) using ALO-128 acid digestion of liquids procedure. Approximately 5.0 ml of sample (weighed) was processed and diluted to a final volume of 25 ml. Sample aliquot volumes were calculated using the weight of sample processed divided by a density of approximately 1.166 g/ml. Estimated density was based upon the average verified delivery volume of a 5ml pipette used to transfer each sample aliquot during sample preparation and sample weight. Final volume of processed sample was calculated by measuring net weight of the final processed volume and dividing by density. Density of each prepared sample was estimated by weighing a one ml aliquot of each processed sample. After processing, sample aliquots were clear and did not require filtering. A process blank, blank-spike and matrix-spiked sample were also prepared. Calculated results of density measurements and volumes are recorded on bench sheets included in final ICPAES report data package. During ICPAES analysis additional simple dilution of 10 and 50-fold were performed in order to quantify high concentrations of certain analytes such as sodium. All measurement results reported have been corrected for analytical and sample dilutions. Results are reported as $\mu\text{g/ml}$.

One radioactive (dry) solid sample, **C-104 Centrifuged Solids Composite** (RPL# 00-01361), was prepared in duplicate by SAL using ALO-129 acid leach of solids procedure and ALO-115 KOH/Ni fusion procedure.

ALO-129 procedure: Approximately 0.5g aliquots were used to prepare samples using ALO-129 acid leach of solids procedure including a matrix-spiked sample. Final volume of processed sample was calculated by measuring net weight of the final processed volume and dividing by density. Density of each prepared sample was estimated by weighing a one ml aliquot of each processed sample. Some sample residue remained after processing. Residue was removed by filtering each sample aliquot. The process blank for the acid leach of solids procedure is the same as that used for ALO-128 acid digestion of liquids above. Calculated results of density measurements and volumes are recorded on bench sheets included in final ICPAES report data package. During ICPAES analysis additional simple dilution of 10 and 50-fold were performed in order to quantify high concentrations of certain analytes such as sodium. All measurement results reported have been corrected for analytical and sample dilutions. Results are reported as $\mu\text{g/g-dry}$.

ALO-115 procedure: Approximately 0.2g and 0.25g size sample aliquots of dried centrifuged solids were prepared. Final volume of processed sample was 100ml, prepared using volumetric flasks. Essentially the entire sample dissolved. No evidence of residue was noted. Preparation required the use of additional HCl to dissolve the samples. All solutions remained soluble after final dilution. During ICPAES analysis additional simple dilution of 2 and 10-fold were performed in order to quantify high concentrations of certain analytes such as sodium, aluminum, iron, thorium, uranium and zirconium. Potassium and nickel measurement results are not

6/12/00

Battelle PNNL/RPL/Inorganic Analysis ... ICPAES Data Report

applicable for this procedure because of reagents and crucible material used during sample preparation. Measurement results reported have been corrected for preparation and analytical dilution. ICPAES measurement results are reported as $\mu\text{g/g-dry}$.

Quality control check-standard results met tolerance requirements for analytes of interest except as noted below. Following is a list of quality control measurement results relative to ICPAES analysis tolerance requirements.

Five fold serial dilution:

(Fusion of solid samples) Results were generally within tolerance limit of $\leq 10\%$ after correcting for dilution except as follows. Sodium in RPL# 00-1361-Ni was high by approximately 12%. All other analytes diluted similarly in this sample was within tolerance. All other sample dilutions performed were within tolerance.

(Acid digest/leach prepared samples)

All results were within tolerance limit of $\leq 10\%$ after correcting for dilution.

Duplicate RPD (Relative Percent Difference):

(Fusion of solid samples) All analytes of interest were recovered within tolerance limit of $\leq 20\%$ relative percent difference (RPD) except silver and phosphorous. RPD for silver was 28% and 55% for phosphorous.

(Acid digest/leach prepared samples)

All analytes of interest were recovered within tolerance limit of $\leq 20\%$ relative percent difference (RPD).

Post-Spiked Samples (Group A):

(Fusion of solid samples) All analytes of interest were recovered within tolerance of 75% to 125%.

(Acid digest/leach prepared samples)

All analytes of interest were recovered within tolerance of 75% to 125%.

Post-Spiked Samples (Group B):

(Fusion of solid samples) All analytes of interest were recovered within tolerance of 75% to 125%.

Battelle PNNL/RPL/Inorganic Analysis ... ICPAES Data Report

(Acid digest/leach prepared samples)

All analytes of interest were recovered within tolerance of 75% to 125%.

Blank Spike:

(Fusion of solid samples) A blank spike is not require for fusion prepared samples.

(Acid digest/leach prepared samples)

All analytes of interest in the blank spike 00-01360-BS were recovered within tolerance limit of 80% to 120% except silver (21%). Chloride from the hydrochloric acid used to prepare the sample using PNL-ALO-128 digestion procedure likely precipitated the silver causing low recovery.

Matrix Spiked Sample:

(Fusion of solid samples) A matrix spike is not require for fusion prepared samples.

(Acid digest/leach prepared samples)

All analytes of interest in the matrix spiked sample (RPL# 00-01360-MS and RPL# 00-01361-MS) were recovered within tolerance limit of 75% to 125% except silver (24%, 27%), barium (56%), and arsenic (50%). Chloride from the hydrochloric acid used to prepare the sample using PNL-ALO-128 digestion likely precipitated silver resulting in low recovery. Low barium recovery results may be caused by the presence of sulfate in the sample. The reason for low recovery results for arsenic is not known.

Quality Control Check Standards:

Concentration of all analytes of interest except palladium in the KOH/Ni fusion prepared analytical runs were within tolerance limit of $\pm 10\%$ accuracy in the standards: QC_MCVA, QC_MCVB, and QC_SSTMV. Calibration Blank (ICP98.0) concentration was less than two times IDL. Palladium in QC_MCVB measured low by 20 to 27%. A single element standard of palladium at 2 $\mu\text{g/ml}$ was measured at the beginning and end of the analytical run recovered ($\pm 3\%$) well within a tolerance limit of $\pm 10\%$ accuracy.

Concentration of all analytes of interest in the acid digest/leach prepared samples was within tolerance limit of $\pm 10\%$ accuracy in the standards: QC_MCVA, QC_MCVB, and QC_SSTMV except as follows. Magnesium was high by 11% in one of four measurements of

Battelle PNNL/RPL/Inorganic Analysis ... ICPAES Data Report

QC_MCVA check standard. Palladium in QC_MCVB measured low by 20%. However, a single element standard of palladium at 2 µg/ml measured 2.1 µg/ml well within a tolerance limit of $\pm 10\%$ accuracy indicating that the overall calibration for palladium was within tolerance. Palladium was not detected in any of the samples measured.

High Calibration Standard Check:

Verification of the high-end calibration concentration for all analytes of interest was within tolerance of $\pm 5\%$ accuracy.

Process Blank:

(Fusion of solid samples) All analytes of interest were within tolerance limit of \leq EQL or $< 5\%$ of sample concentration.

(Acid digest/leach prepared samples)

All analytes of interest were within tolerance limit of \leq EQL or $< 5\%$ of sample concentration except boron and silicon. Boron concentration was about 6% of the concentration measured in C-104 Supernatant Composite sample and about 100% of the boron concentration measured in C-104 Centrifuged Solids Composite sample. Silicon concentration in the process blank was about 10% to 21% of the concentration measured in C-104 Centrifuged Solids Composite.

Laboratory Control Standard (LCS):

(Fusion of solid samples) All analytes of interest at a concentration equal to or greater than EQL were recovered within tolerance limit of 75% to 125% in both fusion prepared LCS standards. SRM-2710 Montana Soil was used for the LCS in PNNL-ALO-115 fusion preparations.

(Acid digest/leach prepared samples)

LCS was not required or prepared for acid digest or acid leached samples.

Analytes other than those requested by the client are for information only. Please note bracketed values listed in the data report are within ten times instrument detection limit and have a potential uncertainty much greater than 15%.

Battelle PNNL/RPL/Inorganic Analysis ... ICPAES Data Report

Comments:

- 1) "Final Results" have been corrected for all laboratory dilution performed on the sample during processing and analysis unless specifically noted.
- 2) Detection limits (DL) shown are for acidified water. Detection limits for other matrices may be determined if requested.
- 3) Routine precision and bias is typically $\pm 15\%$ or better for samples in dilute, acidified water (e.g. 2% v/v HNO₃ or less) at analyte concentrations greater than ten times detection limit up to the upper calibration level. This also presumes that the total dissolved solids concentration in the sample is less than 5000 $\mu\text{g/mL}$ (0.5 per cent by weight).
- 4) Absolute precision, bias and detection limits may be determined on each sample if required by the client.
- 5) The maximum number of significant figures for all ICP measurements is 2.

Battelle PNNL/RPG/Inorganic Analysis ... ICPAES Data Report Page 1 of 2

		Multiplier= RPL/LAB #=	4.97 00-1360-PB	49.3 00-1360 @10	50.7 00-1360-DUP @10		
		Client ID=	Process Blank (ALO-128)	C-104 SUPERNATANT COMPOSITE	C-104 SUPERNATANT COMPOSITE		
Det. Limit (ug/mL)	Run Date= (Analyte)	4/26/00	4/26/00	4/26/00	4/26/00		
		ug/mL	ug/mL	ug/mL	ug/mL		
0.025	Ag	--	[1.4]	[1.6]	--	--	--
0.060	Al	5.31	418	449	--	--	--
0.250	As	--	--	--	--	--	--
0.050	B	12.4	205	237	--	--	--
0.010	Ba	[0.081]	--	[0.52]	--	--	--
0.010	Be	--	--	--	--	--	--
0.100	Bi	--	--	--	--	--	--
0.250	Ca	--	[31]	[28]	--	--	--
0.015	Cd	--	8.96	9.83	--	--	--
0.200	Ce	--	--	--	--	--	--
0.050	Co	--	--	--	--	--	--
0.020	Cr	--	55.4	61.1	--	--	--
0.025	Cu	--	[6.9]	[7.7]	--	--	--
0.050	Dy	--	--	--	--	--	--
0.100	Eu	--	--	--	--	--	--
0.025	Fe	[0.18]	17.7	18.4	--	--	--
2.000	K	--	[620]	[690]	--	--	--
0.050	La	--	--	--	--	--	--
0.030	Li	--	21.0	22.9	--	--	--
0.100	Mg	--	[11]	[12]	--	--	--
0.050	Mn	--	[6.8]	[7.0]	--	--	--
0.050	Mo	--	[7.9]	[8.8]	--	--	--
0.150	Na	19.2	67,700	75,700	--	--	--
0.100	Nd	--	--	--	--	--	--
0.030	Ni	[0.35]	121	135	--	--	--
0.100	P	--	1,070	1,180	--	--	--
0.100	Pb	--	--	--	--	--	--
0.750	Pd	--	--	--	--	--	--
0.300	Rh	--	--	--	--	--	--
1.100	Ru	--	--	--	--	--	--
0.500	Sb	--	--	--	--	--	--
0.250	Se	--	--	--	--	--	--
0.500	Si	26.4	1,880	2,110	--	--	--
1.500	Sn	--	--	--	--	--	--
0.015	Sr	--	--	--	--	--	--
1.500	Te	--	--	--	--	--	--
1.000	Th	--	--	--	--	--	--
0.025	Ti	--	--	--	--	--	--
0.500	Tl	--	--	--	--	--	--
2.000	U	--	--	--	--	--	--
0.050	V	--	--	--	--	--	--
2.000	W	--	--	--	--	--	--
0.050	Y	--	--	--	--	--	--
0.050	Zn	--	--	--	--	--	--
0.050	Zr	--	[20]	[20]	--	--	--

Note: 1) Overall error greater than 10-times detection limit is estimated to be within +/- 15%.
 2) Values in brackets [] are within 10-times detection limit with errors likely to exceed 15%.
 3) "--" indicate measurement is below detection. Sample detection limit may be found by multiplying "det. limit" (far left column) by "multiplier" (top of each column).

Battelle PNNL/RPG/Inorganic Analysis ... ICPAES Data Report Page 1 of 1

Multiplier=		51.9	483.2	497.4		
RPL/LAB #=		00-1360-PB	00-1361 @10	00-1361-DUP @10		
Client ID=		Process	C-104 Centrifuged	C-104 Centrifuged		
Run Date=		Blank (ALO-129 equiv.)	Solids Composite	Solids Composite		
Det. Limit	(ug/mL)	4/26/00	4/26/00	4/26/00		
(Analyte)		ug/g-dry	ug/g-dry	ug/g-dry		
0.025	Ag	-	[91]	[78]	-	-
0.060	Al	55.5	122,000	124,000	-	-
0.250	As	-	-	-	-	-
0.050	B	129	[120]	[120]	-	-
0.010	Ba	[0.85]	143	141	-	-
0.010	Be	-	[32]	[32]	-	-
0.100	Bi	-	-	-	-	-
0.250	Ca	-	3,620	3,620	-	-
0.015	Cd	-	696	710	-	-
0.200	Ce	-	[260]	[230]	-	-
0.050	Co	-	-	-	-	-
0.020	Cr	-	1,200	1,200	-	-
0.025	Cu	-	167	163	-	-
0.050	Dy	-	-	-	-	-
0.100	Eu	-	-	-	-	-
0.025	Fe	[1.9]	32,800	32,000	-	-
2.000	K	-	-	-	-	-
0.050	La	-	[110]	[100]	-	-
0.030	Li	-	422	427	-	-
0.100	Mg	-	[450]	[460]	-	-
0.050	Mn	-	8,170	8,210	-	-
0.050	Mo	-	-	-	-	-
0.150	Na	201	139,000	138,000	-	-
0.100	Nd	-	[230]	[230]	-	-
0.030	Ni	[3.7]	2,240	2,240	-	-
0.100	P	-	[150]	[110]	-	-
0.100	Pb	-	1,200	1,180	-	-
0.750	Pd	-	-	-	-	-
0.300	Rh	-	-	-	-	-
1.100	Ru	-	-	-	-	-
0.500	Sb	-	-	-	-	-
0.250	Se	-	-	-	-	-
0.500	Si	276	[1,300]	2,800	-	-
1.500	Sn	-	[990]	[990]	-	-
0.015	Sr	-	[68]	[68]	-	-
1.500	Te	-	-	-	-	-
1.000	Th	-	51,700	52,300	-	-
0.025	Ti	-	[98]	[97]	-	-
0.500	Tl	-	-	-	-	-
2.000	U	-	40,000	39,900	-	-
0.050	V	-	-	-	-	-
2.000	W	-	-	-	-	-
0.050	Y	-	[28]	[28]	-	-
0.050	Zn	-	[160]	[160]	-	-
0.050	Zr	-	29,100	29,600	-	-

Note: 1) Overall error greater than 10-times detection limit is estimated to be within +/- 15%.
 2) Values in brackets [] are within 10-times detection limit with errors likely to exceed 15%.
 3) "-" indicate measurement is below detection. Sample detection limit may be found by multiplying "det. limit" (far left column) by "multiplier" (top of each column).

Battelle PNNL/RPG/Inorganic Analysis ... ICPAES Data Report

Page 1 of 1

		Multiplier= RPL/LAB #=	881.6 00-1361-PB-Ni @2	1024.6 00-1361-Ni @2	773.7 00-1361-Ni-DUP @2	
		Client ID= Run Date=	Process Blank	C-104 Centrifuged Solids Composite	C-104 Centrifuged Solids Composite	
Det. Limit (ug/mL)	(Analyte)	4/20/00 ug/g-dry	4/20/00 ug/g-dry	4/20/00 ug/g-dry	4/20/00 ug/g-dry	
0.025	Ag	-	355	268	-	
0.060	Al	[86]	108,000	116,000	-	
0.250	As	-	-	-	-	
0.050	B	-	-	-	-	
0.010	Ba	-	134	140	-	
0.010	Be	-	[29]	[30]	-	
0.100	Bi	-	-	-	-	
0.250	Ca	-	3,420	3,420	-	
0.015	Cd	-	657	665	-	
0.200	Ce	-	[450]	[300]	-	
0.050	Co	-	-	-	-	
0.020	Cr	-	1,220	1,240	-	
0.025	Cu	-	[180]	195	-	
0.050	Dy	-	-	-	-	
0.100	Eu	-	-	-	-	
0.025	Fe	389	33,000	33,800	-	
0.050	La	-	[120]	[100]	-	
0.030	Li	-	347	350	-	
0.100	Mg	-	[630]	[550]	-	
0.050	Mn	[120]	7,500	7,600	-	
0.050	Mo	-	-	-	-	
0.150	Na	[1,200]	120,000	123,000	-	
0.100	Nd	-	[310]	[220]	-	
0.100	P	-	2,750	1,570	-	
0.100	Pb	-	1,360	1,240	-	
0.750	Pd	-	-	-	-	
0.300	Rh	-	-	-	-	
1.100	Ru	-	-	-	-	
0.500	Sb	-	-	-	-	
0.250	Se	-	-	-	-	
0.500	Si	-	10,200	9,850	-	
1.500	Sn	-	-	-	-	
0.015	Sr	-	[65]	[69]	-	
1.500	Te	-	-	-	-	
1.000	Th	-	44,100	46,200	-	
0.025	Ti	-	[160]	[160]	-	
0.500	Tl	-	-	-	-	
2.000	U	-	36,000	36,000	-	
0.050	V	-	[52]	-	-	
2.000	W	-	-	-	-	
0.050	Y	-	-	-	-	
0.050	Zn	-	[170]	[160]	-	
0.050	Zr	-	40,000	40,600	-	

Note: 1) Overall error greater than 10-times detection limit is estimated to be within +/- 15%.

2) Values in brackets [] are within 10-times detection limit with errors likely to exceed 15%.

3) "--" indicate measurement is below detection. Sample detection limit may be found by multiplying "det. limit" (far left column) by "multiplier" (top of each column).

Battelle, Pacific Northwest National Laboratory
 Richland, WA
 Radiochemical Processing Group

filename 00-1360U
 7/11/2000
 Rev. 1

Client: M. Urie

Cognizant Scientist: J.R. Greenwood 7-11-00

Concur: A.K. Fickum 7/11/00

Procedure PNL-ALO-4014
 Equipment: Chemcheck KPA11R

Uranium Analysis by Kinetic Phosphorescence

		Uranium Concentration		
Sample		$\pm 1\sigma$	Units	
Process Blank	00-1360PB	<5.E-3	ug/ml	
C-104 Supernatant Comp.	00-1360	2.86E+1 $\pm 3\%$	ug/ml	
C-104 Supernatant Comp.	00-1360 Rep	2.85E+1 $\pm 3\%$	ug/ml	
C-104 Supernatant Comp.	00-1360 Dup	3.00E+1 $\pm 3\%$	ug/ml	
	RPD	5%		
Process Blank	00-1361 PB	9.13E-1 $\pm 2\%$	ug/g	
C-104 Centrifuged Solids Comp.	00-1361	3.35E+4 $\pm 3\%$	ug/g	
C-104 Centrifuged Solids Comp.	00-1361 Dup	3.25E+4 $\pm 3\%$	ug/g	
	RPD	3%		
Liquids blank		<5.E-3		
Liquid matrix spike		101%		
Solids blank		<4.E-1		
Solid matrix spike		99%		

Before
Run

Standard	Observed	Expected	Yield
R-330-f	1.03E-4	1.00E-4	1.030
R-330-e	1.04E-3	1.00E-3	1.040
R-330-d	9.97E-3	1.00E-2	0.997
R-330-c	9.89E-2	1.00E-1	0.989
R-330-b	9.61E-1	1.00E+0	0.961

After
Run

R-330-e	1.05E-3	1.00E-3	1.050
R-330-c	1.02E-1	1.00E-1	1.020

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Chemical Measurements Center

00-1360
5/24/2000
Rev. 2

Client: M. Urie

Cognizant Scientist:

L. J. Greenwood

Date:

5/24/00

Concur:

T. Tang - U

Date:

5/24/00

Measured Activities uCi/g with 1-s error

ALO ID Client ID	Beta Error +/-	Sr-90 Error +/-	Co-60 Error +/-	Nb-94 Error +/-	Ru/Rh-106 Error +/-	Sb-125 Error +/-	Sn/Sb-126 Error +/-	Cs-134 Error +/-	Cs-137 Error +/-	Eu-154 Error +/-	Eu-155 Error +/-	Am-241 Error +/-
00-1360PB* Process Blank	1.42E-3 9%	<2.E-3	<4.E-6	<3.E-6	<3.E-5	<9.E-6	<3.E-6	<4.E-6	1.27E-4 5%	<9.E-6	<2.E-5	<3.E-5
00-1360* C-104 Supernatant Comp.	3.00E+1 4%	1.06E-1 16%	4.22E-2 3%	<2.E-3	<9.E-2	<6.E-2	<2.E-2	<2.E-3	3.66E+1 2%	<3.E-3	<4.E-2	<4.E-2
00-1360 DUP* C-104 Supernatant Comp.	3.08E+1 4%	1.08E-1 16%	4.73E-2 3%	<2.E-3	<9.E-2	<6.E-2	<3.E-2	<2.E-3	4.05E+1 2%	<3.E-3	<4.E-2	<4.E-2
RPD	3%	2%	11%						10%			
00-1361 PB Process Blank	7.11E-1 22%	<2.E-1	<5.E-4	<5.E-4	<5.E-3	<2.E-3	<7.E-4	<6.E-4	7.98E-2 2%	<2.E-3	<2.E-3	<2.E-3
00-1361 C-104 Centrifuged Solids Comp.	1.22E+3 4%	5.03E+2 3%	1.92E-1 3%	<3.E-2	<3.E-1	<2.E-1	<6.E-2	<2.E-2	6.90E+1 2%	1.55E+0 2%	9.00E-1 5%	5.78E+0 3%
00-1361 Dup C-104 Centrifuged Solids Comp.	1.15E+3 4%	5.31E+2 3%	1.90E-1 3%	<3.E-2	<3.E-1	2.67E-1 20%	<6.E-2	<2.E-2	6.94E+1 2%	1.57E+0 2%	9.28E-1 5%	5.76E+0 3%
RPD	6%	5%	1%						1%	1%	3%	0%
Solids blank			<2.E-1									
Matrix spike	100%	97%										
	98%	95%										
Blank spike	99%	92%										
	100%	94%										

Note: * Data for sample 00-1360 are reported as uCi/ml

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Chemical Measurements Center

00-1360
6/1/2000
Rev. 1

Client : M. Urie

Cognizant Scientist:

SP Greenwald

Date: 6/1/00

Concur :

O. K. Atkinson

Date: 6/1/02

Measured Activities uCi/g with 1-σ error

ALO ID Client ID	Pu-239+				Pu-238				Pu-241				Am-241				Cm-243+				Cm-244				Sum Alpha			
	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %	Alpha Error +/-	Error %
00-1360PB * Process Blank	<1.E-4	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<7.E-7	<1.E-4	<4.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<4.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6	<2.E-6
00-1360 * C-104 Supernatant Comp.	4.03E-3 6%	1.82E-3 4%	1.82E-3 4%	1.78E-4 7%	<2.E-6	<2.E-6	5.07E-3 9%	2.01E-3 5%	4.23E-5 15%	5.73E-6 40%	4.06E-3																	
00-1360 DUP* C-104 Supernatant Comp.	4.58E-3 5%	1.82E-3 4%	1.82E-3 4%	1.88E-4 8%	<1.E-5	<1.E-5	5.11E-3 9%	2.02E-3 5%	3.81E-5 16%	1.02E-5 31%	4.08E-3																	
RPD	13%	0%	0%	5%			1%	0%	10%	56%	0%																	
00-1361 PB Process Blank	<2.E-2	1.94E-4 34%	1.94E-4 34%	2.26E-4 40%	<5.E-5	<5.E-5	<9.E-3	4.93E-4 27%	8.81E-5 49%	<4.E-5	1.00E-3																	
00-1361 C-104 Centrifuged Solids Comp.	9.80E+0 3%	5.02E+0 4%	5.02E+0 4%	5.77E-1 6%	<3.E-3	<3.E-3	1.39E+1 8%	5.54E+0 5%	5.83E-2 15%	1.51E-2 28%	1.12E+1																	
00-1361 Dup C-104 Centrifuged Solids Comp.	1.03E+1 3%	4.89E+0 4%	4.89E+0 4%	5.81E-1 5%	<2.E-3	<2.E-3	1.74E+1 8%	5.50E+0 5%	7.75E-2 12%	9.37E-3 33%	1.11E+1																	
RPD	5%	3%	3%	1%			22%	1%	28%	47%	1%																	
MD							0.95																					
Solids Blank	<2.E-2	<7.E-5	<7.E-5	<5.E-5	<4.E-5	<4.E-5	<9.E-3	1.46E-4 43%	<6.E-5	<4.E-5																		
Liquids Blank					<9.E-7	<2.E-6	<4.E-7	6.55E-5 33%	<2.E-6	<5.E-7																		
Matrix Spike	92% 73%	95% 103%	95% 103%																									
Blank Spike	105% 109%	103% 101%	103% 101%																									

Note: * Data for sample 00-1360 are reported as uCi/ml

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Chemical Measurements Center

00-1360 H3
6/6/2000

Client : M. Urie

Cognizant Scientist:

V. G. B. Wobbe

Date : 6/6/00

Concur :

L. J. Green

Date : 6/6/00

Measured Activities with 1- σ error

<u>ALO ID</u> <u>Client ID</u>	<u>Se-79</u> <u>Error %</u>	
00-1360 C-104 Supernatant Comp.	6.41E-5 4%	$\mu\text{Ci/ml}$
00-1360 rep C-104 Supernatant Comp.	6.50E-5 5%	$\mu\text{Ci/ml}$
RPD	1%	
00-1361 PB Process blank	<7.E-4	$\mu\text{Ci/g}$
00-1361 C-104 Centrifuged Solids Comp.	6.43E-3 6%	$\mu\text{Ci/g}$
00-1361 dup C-104 Centrifuged Solids Comp.	6.66E-3 6%	$\mu\text{Ci/g}$
00-1361 dup rep C-104 Centrifuged Solids Comp.	9.94E-3 6%	$\mu\text{Ci/g}$
RSD	26%	
Liquids blank	<2.E-6	$\mu\text{Ci/ml}$
Solids blank	<9.E-4	$\mu\text{Ci/g}$

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Chemical Measurements Center

00-1360 H3
7/12/2000
Rev. 1

Client : M. Urie

Cognizant Scientist:

LR Greenwald

Date :

7/12/00

Concur :

W. J. Greenwald

Date :

7/12/00

Measured Activities with 1- σ error

<u>ALO ID</u> <u>Client ID</u>	<u>Tritium*</u> <u>Error %</u>	
00-1360 C-104 Supernatant Comp.	4.53E-3 4%	$\mu\text{Ci/ml}$
00-1360 C-104 Supernatant Comp.	4.81E-3 4%	$\mu\text{Ci/ml}$
RPD	6%	
00-1361 C-104 Centrifuged Solids Comp.	5.93E-2 5%	$\mu\text{Ci/g}$
00-1361 Dup C-104 Centrifuged Solids Comp.	1.14E-2 5%	$\mu\text{Ci/g}$
RPD	136%	
00-1361 PB Process Blank	1.28E-2 4%	$\mu\text{Ci/g}$
Solids Blank	<4.E-4	$\mu\text{Ci/g}$
Liquid Blank	<1.E-4	$\mu\text{Ci/ml}$
Liquid blank spike	95%	
Solids blank spike	103%	

*For the solids, tritium is reported per gram of wet slurry.

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Chemical Measurements Center

00-1360 H3
7/11/2000

Client : M. Urie

Cognizant Scientist:

L.R. Greenwood

Date :

7/11/00

Concur :

Shandra K. Hobbs

Date :

7/11/00

Measured Activities with 1- σ error

<u>ALO ID</u> <u>Client ID</u>	<u>C-14*</u> <u>Error %</u>	
00-1360 C-104 Supernatant Comp.	7.70E-4 5%	$\mu\text{Ci/ml}$
00-1360 C-104 Supernatant Comp.	7.71E-4 5%	$\mu\text{Ci/ml}$
RPD	0%	
00-1361 C-104 Centrifuged Solids Comp.	1.12E-3 7%	$\mu\text{Ci/g}$
00-1361 Dup C-104 Centrifuged Solids Comp.	1.28E-3 7%	$\mu\text{Ci/g}$
RPD	13%	
Blank (as liquid)	<4.E-7	$\mu\text{Ci/ml}$
Blank spike	96%	
Liquid matrix spike	97%	
Solids matrix spike	88%	

*For the solids, tritium is reported per gram of wet slurry.

Date 21 August 2000

To Mike Urie
 Sandra Fiskum

From Charles J. Barinaga 509-376-6095 *Charles J. Barinaga 8/22/00*

Subject ICP/MS Analysis of C104 Samples (ALO# 001360 and 001361)

This report contains our responses to Sandra Fiskum's questions concerning the data in the previous report on this work submitted by Tom Farmer on 06 June 2000. It also contains data for isotopes inadvertently left out in the previous report and revises (indicated by asterisks) some data mis-reporting due to data handling errors that weren't caught in the report preparation and review.

The data left out of the previous report and included here are for U-236 and Np-237 for the supernatant acid digest and for Cs-135 and 137 for the supernatant, water dilution and acid digest, and for the KOH fused solids. (Our term for the 'supernatant water dilution' data set is "direct.")

Also included, at Sandra's request, are the MDL's for the individual samples. (The MDL's are the dilution factor and density adjusted equivalent concentrations of 5 X SD *8/22/00* of the blank for that element/isotope from three acquisitions.) The nominal values are reported below. Please see the summary sheets for the actual MDL for each sample.

MDL's	Rb	Tc	I-127	I-129	Cs	Pr	Ta	233	234
acid	.0006	3.4E-5	0.002	1E-6	0.004	0.001	0.002	2E-5	6E-6
direct	0.003	1.7E-4	0.12	3E-5	0.01	0.005			
fusion	0.5	0.002	0.6	2.4E-4	0.3	0.4	0.12	6.8E-3	7E-3
	235	236	238	tot. U	Np	239	240		
acid	4E-8	8E-8	2E-7	0.02	2.4E-6	2.5E-5	1.3E-4		
direct	5E-8	4E-7	8E-8	0.2	3.7E-7	4.8E-4	2.7E-3		
fusion	1.7E-5	7.8E-5	3.5E-7	80	3E-4	2.6E-2	3.8E-2		

The data revisions include:

Direct (water dilution):

- Small decrease in the 'direct' Pu-239 and 240 values due to correction of dilution factors.
- Transcription errors in the Np-237 and Pr blank values, see below.

Acid Digest:

- I-129 matrix spike – transcription error.
- Under-estimate of Pu-240 due to offset in 239 calibration. Corrected by using the lowest 239 standard to estimate 240.

KOH Fusion:

- Radionuclides for SRM 2710 originally reported as ug/g, now corrected to uCi/g.
- Ta process blank - a transcription error originally reported as 0.4 ug/g, the correct value is <0.14 ug/g (the reporting limit).

Responses to questions from Sandra:

'Direct' (supernatant water dilution)

- Np-237 value for the diluent blank was listed as 2.8E-4 uCi/mL. It should have been 2.8E-7 uCi/mL. (a ppm vs ppb units error in data entry)
- Pr for the diluent ('direct') blank (0.14 ug/mL) is higher than for the samples. There was a transcription error from the calculation sheet to the summary page. The actual Pr blank value should be 0.03 ug/mL.

Ni/KOH fusion (solids KOH fusion)

Rb for the process blank is nearly as high as that in the samples. That Rb is high due to the process is also reflected in the value for SRM 2710, 447 ug/g, which is higher than the "suggested" (not certified) value of 120 ug/g. A significant level of Rb in the process blank was also noted in the screening ICP/MS acquisition.

High RSD's for 'acid digest' Ta and Pu-240 and for 'direct' Pu-239 and 240.

Although the reported values are above the reporting limits, these were low count responses and had more noise during the acquisition.

High RPD's – especially for several 'direct' elements/isotopes

The analyst, James Bramson, noted these differences and re-prepped/reran the samples with the same result. Unfortunately in our current data acquisition scheme, these efforts and data are not captured. We have no explanation except to note that the more soluble elements, e.g. Rb, Tc, I, Cs, do not show this difference.

Pu 240/239 ratio differences within and between acid digest, direct, and fusion.

Since we do not have a 240 standard, Pu-240 was determined by reference to the 239 calibration. An offset in the 239 calibration curve at low concentrations for the 'acid digest' under-estimates the 240 concentration (reported values 361 and 475 uCi/mL). When determined

from a 239 calibration limited to the low concentration standard, the 240 values are 645 and 655 uCi/mL.

Sum Pu 239+240 vs rad counting

The 239-240 rad counting vs. the sum (239, 240) ICP/MS values for the KOH Fusion agree well, however those for the Acid Digest do not. We have no explanation for this. Also there is a difference between the Acid Digest and the Water Dilution sum values. Again we have no explanation except to note that there are inconsistencies with Water Dilution values, this may be due to solubility problems.

Sum U isotopes between 'direct' sample and duplicate

Again this is related to the general inconsistency between the 'sample' and the 'duplicate' solutions for the Water Dilution batch.

I believe this fills out the data and covers your questions. The reviewed sheets and data package will follow later today. Please call if there are additional questions.

8/2/00
J. B. Smith

8/2/00

Results are reported in μg analyte/ ml of original solution, or μCi analyte/ml of original solution.

reviewed
Barnaga
8/22/00

reviewed
Barnaga
8/22/00

C104 Acid Digestion

June 9, 2000 (MDL's added 8/17/00, *revised 8/17/00)

Results are reported in µg analyte/ ml of original solution, or µCi analyte/ml of original solution.

Sample ID	Client ID	MDL µCi/ml	I-129 µCi/ml ± 1 SD	MDL µg/ml	Cs µg/ml ± 1 SD	MDL µg/ml	Pr µg/ml ± 1 SD
1% HNO3			<2.0E-08		<0.0002		<0.0001
1% HNO3			<2.0E-08		<0.0003		<0.0001
1% HNO3			<8.1E-07		<0.0005		<0.0001
00-01360-PB	PROCESS BLANK	8.1E-07	<8.1E-07	0.003	0.016 ± 0.001	0.001	<0.001
00-01360-BS	BLANK SPIKE	8.1E-07	<8.1E-07	0.003	0.013 ± 0.008	0.001	<0.001
00-01360	C-104 Supernatant Composite	9.0E-07	1.8E-04 ± 2.8E-05	0.004	0.930 ± 0.030	0.001	0.0251 ± 0.0002
00-01360-DUP	C-104 Supernatant Composite	1.4E-06	2.17E-04 ± 1.62E-05	0.004	1.05 ± 0.03	0.001	0.029 ± 0.005
00-01360+ Spike	C-104 Supernatant Composite	4.1E-06	3.6E-04 ± 4.0E-05	0.004	1.15 ± 0.05	0.001	0.0583 ± 0.0029
Spike Recovery			105%		113%		85%
00-01360-MS	C-104 Supernatant Composite	1.2E-06	*2.6E-04 ± 2.2E-05	0.004	1.06 ± 0.03	0.001	0.0260 ± 0.001
Check standard results are reported in µg/ml (ppm)							
0.005ppm Multi					0.00516 ± 0.00016		0.000402 ± 0.000006
0.005ppm Multi					0.00492 ± 0.00031		0.000409 ± 0.000004
0.0004ppm Multi							
0.0004ppm Multi							
0.0001ppm I-129							
0.005ppm I-129							
0.0001ppm I-129			0.000103 ± 0.000019				
0.010ppm I-129			0.0102 ± 0.0003				
0.050ppm U							
0.050ppm U							
0.0006ppm Pu							
0.0006ppm Pu							

revised
Bairney
8/22/00

JAB
8/24/00

C104 Acid Digestion

June 9, 2000 (MDL's added 8/17/00)

JPB
8/24/00

Results are reported in µg analyte/ ml of original solution, or µCi analyte/ml of original solution.

Sample ID	Client ID	MDL µg/ml	Ta µg/ml ± 1 SD	MDL µCi/ml	U-233 µCi/ml ± 1 SD	MDL µCi/ml	U-234 µCi/ml ± 1 SD
1% HNO3			<0.0001				
1% HNO3			<0.0001				
1% HNO3			<0.0001				
00-01360-PB	PROCESS BLANK	0.002	<0.002	1.1E-06	<1.1E-06	5.8E-06	<5.8E-06
00-01360-BS	BLANK SPIKE	0.002	<0.002	5.6E-06	<5.6E-06	1.4E-06	<1.4E-06
00-01360	C-104 Supernatant Composite	0.002	0.0033 ± 0.0014	1.0E-05	3.37E-04 ± 1.12E-06	5.0E-06	1.19E-05 ± 3.62E-07
00-01360-DUP	C-104 Supernatant Composite	0.002	0.0052 ± 0.0039	2.0E-05	3.95E-04 ± 2.46E-05	6.2E-06	1.89E-05 ± 1.16E-06
00-01360+ spike	C-104 Supernatant Composite	0.002	0.0406 ± 0.0030				
Spike Recovery			110%				
00-01360-MS	C-104 Supernatant Composite	0.002	0.0036 ± 0.0007	2.6E-05	4.07E-04 ± 1.12E-06	5.4E-06	1.46E-05 ± 3.62E-07
Check standard results are reported in µg/ml (ppm)							
0.005ppm Multi							
0.005ppm Multi							
0.0004ppm Multi			0.000403 ± 0.000005				
0.0004ppm Multi			0.000407 ± 0.000006				
0.0001ppm I-127							
0.005ppm I-127							
0.0001ppm I-129							
0.010ppm I-129							
0.050ppm U							
0.050ppm U							
0.0006ppm Pu							
0.0006ppm Pu							

revised.
Baranaga
8/22/00

C104 Acid Digestion

June 9, 2000 (MDL's added 8/17/00, *revised 7/20/00)

Results are reported in µg analyte/ ml of original solution, or µCi analyte/ml of original solution.

Sample ID	Client ID	MDL µCi/ml	U-235 µCi/ml	MDL µCi/ml	U-235 µCi/ml	MDL µCi/ml	*U-236 µCi/ml	MDL µCi/ml	U-238 µCi/ml
1% HNO3									
1% HNO3									
1% HNO3									
00-01360-PB	PROCESS BLANK	5.0E-09	<5.0E-09	3.0E-08	<3.0E-08	3.9E-09	<3.9E-09		
00-01360-BS	BLANK SPIKE	1.1E-08	1.5E-08 ±	7.5E-09	<7.5E-09	1.6E-07	2.7E-07 ±		1.6E-08
00-01360	C-104 Supernatant Composite	3.7E-08	4.79E-07 ±	5.6E-08	6.26E-07 ±	9.8E-08	1.05E-05 ±		3.12E-07
00-01360-DUP	C-104 Supernatant Composite	2.0E-08	5.52E-07 ±	8.5E-08	7.46E-07 ±	2.1E-07	1.19E-05 ±		7.42E-07
00-01360+ spike	C-104 Supernatant Composite								
Spike Recovery									
00-01360-MS	C-104 Supernatant Composite	3.5E-08	5.64E-07 ±	7.3E-08	7.32E-07 ±	1.3E-07	1.21E-05 ±		3.12E-07
Check standard results are reported in µg/ml (ppm)									
0.005ppm Multi									
0.005ppm Multi									
0.0004ppm Multi									
0.0004ppm Multi									
0.0001ppm I-127									
0.005ppm I-127									
0.0001ppm I-129									
0.010ppm I-129									
0.050ppm U									
0.050ppm U									
0.0006ppm Pu									
0.0006ppm Pu									

Reviewed
Baranaya
8/22/00

gl Baranaya
8/24/00

C104 Acid Digestion

June 9, 2000 (MDL's added 8/17/00, *revised 7/20/00)

Results are reported in µg analyte/ ml of original solution, or µCi analyte/ml of original solution.

Sample ID	Client ID	MDL µg/ml	Total Uranium µg/ml ± 1 SD	MDL µCi/ml	*Np-237 µCi/ml ± 1 SD	MDL µCi/ml	Pu-239 µCi/ml ± 1 SD
1% HNO3			<0.0001		<6.0E-09		<3.6E-07
1% HNO3			<0.0005		<6.0E-09		<3.6E-07
1% HNO3			<0.0006		<6.0E-09		<3.6E-07
00-01360-PB	PROCESS BLANK	2.0E-03	0.013 ± 0.014	2.4E-06	<2.4E-06	2.8E-05	<2.8E-05
00-01360-BS	BLANK SPIKE	2.0E-03	0.80 ± 0.050	2.4E-06	<2.4E-06	1.8E-05	<1.8E-05
00-01360	C-104 Supernatant Composite	1.0E-02	31.6 ± 1.0	2.4E-06	3.01E-05 ± 7.05E-08	2.5E-05	2.36E-03 ± 1.44E-05
00-01360-DUP	C-104 Supernatant Composite	1.0E-02	35.8 ± 2.2	2.4E-06	3.09E-05 ± 1.90E-06	2.0E-05	2.37E-03 ± 2.16E-05
00-01360+ spike	C-104 Supernatant Composite	1.0E-02	43.3 ± 0.3	2.4E-06	5.42E-05 ± 2.68E-06	1.6E-05	4.03E-03 ± 7.92E-05
Spike Recovery			120%		87%		110%
00-01360-MS	C-104 Supernatant Composite	1.0E-02	36.3 ± 0.9	2.4E-06	3.45E-05 ± 9.87E-07	2.2E-05	2.36E-03 ± 4.32E-05
Check standard results are reported in µg/ml (ppm)							
0.005ppm Multi							
0.005ppm Multi							
0.0004ppm Multi							
0.0004ppm Multi							
0.0001ppm I-127							
0.0005ppm I-127							
0.0001ppm I-129							
0.010ppm I-129							
0.050ppm U			0.0477 ± 0.0013		0.000398 ± 0.000010		
0.050ppm U			0.0479 ± 0.0010		0.000426 ± 0.000012		
0.0006ppm Pu							0.000595 ± 0.000020
0.0006ppm Pu							0.000594 ± 0.000011

revised
Barnes
08/22/01

JLB
8/21/00

C104 Acid Digestion

June 9, 2000 (MDL's added 8/17/00, *revised 8/17/00)

Results are reported in µg analyte/ ml of original solution, or µCi analyte/ml of original solution.

Sample ID	Client ID	MDL µCi/ml	*Pu-240 µCi/ml ± 1 SD
1% HNO3			<1.3E-05
1% HNO3			<1.3E-05
1% HNO3			<1.3E-05
00-01360-PB	PROCESS BLANK	4.0E-05	<4.0E-05
00-01360-BS	BLANK SPIKE	2.6E-05	<2.6E-05
00-01360	C-104 Supernatant Composite	3.6E-05	6.45E-04 ± 1.70E-05
00-01360-DUP	C-104 Supernatant Composite	2.9E-05	6.55E-04 ± 1.00E-04
00-01360+ spike	C-104 Supernatant Composite		
Spike Recovery			
00-01360-MS	C-104 Supernatant Composite	2.7E-05	6.75E-04 ± 5.80E-06
Check standard results are reported in µg/ml (ppm)			
0.005ppm Multi			
0.005ppm Multi			
0.0004ppm Multi			
0.0004ppm Multi			
0.0001ppm I-127			
0.005ppm I-127			
0.0001ppm I-129			
0.010ppm I-129			
0.050ppm U			
0.050ppm U			
0.0006ppm Pu			
0.0006ppm Pu			

JPB
8/21/00

revised
JPB
9/22/00

C104 Direct

June 9, 2000 (MDL's added 8/17/00)

Results are reported in μg analyte/ml (ppm) of original solution or μCi analyte/ml of original solution.

Sample ID	Client ID	MDL $\mu\text{g/ml}$	Rb $\mu\text{g/ml}$ \pm 1SD	MDL $\mu\text{Ci/ml}$	Tc-99 $\mu\text{Ci/ml}$ \pm 1SD	MDL $\mu\text{g/ml}$	I-127 $\mu\text{g/ml}$ \pm 1SD
1% HNO_3			<0.0002		<3.4E-07		0.0001 \pm 0.0001
1% HNO_3			<0.0002		<1.0E-06		0.0001 \pm 0.0001
1% HNO_3			<0.0002		<1.7E-06		0.0001 \pm 0.0001
00-01360-DB	DILUENT BLANK	0.003	0.07 \pm 0.10	1.2E-04	<1.2E-04	0.12	<0.12
00-01360	C-104 Supernatant Composite	0.003	0.564 \pm 0.014	1.5E-04	0.0144 \pm 0.0005	0.12	0.76 \pm 0.24
00-01360-DUP	C-104 Supernatant Composite	0.003	0.590 \pm 0.027	1.5E-04	0.0145 \pm 0.0004	0.12	0.67 \pm 0.23
00-01360+ spike	C-104 Supernatant Composite	0.003	1.58 \pm 0.013	1.7E-04	0.0302 \pm 0.0006	0.12	1.43 \pm 0.34
Spike Recovery			108%		99%		95%
00-01360-MS	C-104 Supernatant Composite	0.003	0.54 \pm 0.015	1.4E-04	0.0148 \pm 0.0003	0.12	0.80 \pm 0.22
Check Standard Results are reported in $\mu\text{g/ml}$ (ppm)							
0.005ppm Multi			0.00422 \pm 0.00005				
0.005ppm Multi			0.00503 \pm 0.00006				
0.002ppm Tc-99					0.00205 \pm 0.00007		0.00038 \pm 0.00010
0.002ppm Tc-99					0.00207 \pm 0.00006		0.00051 \pm 0.00012
0.0004ppm I-127							
0.0005ppm I-127							
0.0001ppm I-129							
0.0005ppm I-129							
0.050ppm U							
0.050ppm U							
0.0005ppm Ta,Np							
0.0005ppm Ta,Np							
0.0012ppm Pu							
0.0012ppm Pu							

revised
Barman
8/22/00

JB
8/21/00

C104 Direct

June 9, 2000 (MDL's added 8/17/00, *revised 8/17/00)

Results are reported in µg analyte/ml (ppm) of original solution or µCi analyte/ml of original solution.

Sample ID	Client ID	MDL µCi/ml	I-129 µCi/ml	MDL µg/ml	Cs µg/ml	MDL µg/ml	Pr µg/ml
1% HNO3			<1.2E-08		<0.0001		<0.00005
1% HNO3			<1.4E-08		<0.0001		<0.00005
1% HNO3			<1.6E-08		<0.0001		<0.00005
00-01360-DB	DILUENT BLANK	3.3E-05	<3.3E-05	0.008	0.035 ± 0.020	0.004	*0.03 ± 0.03
00-01360	C-104 Supernatant Composite	2.7E-05	2.13E-04 ± 2.09E-05	0.01	1.28 ± 0.05	0.005	0.073 ± 0.018
00-01360-DUP	C-104 Supernatant Composite	2.7E-05	1.95E-04 ± 1.05E-05	0.01	1.28 ± 0.02	0.005	0.030 ± 0.007
00-01360+ spike	C-104 Supernatant Composite	3.0E-05	3.89E-04 ± 3.83E-05	0.01	2.29 ± 0.03	0.005	1.02 ± 0.03
Spike Recovery			108%		108%		101%
00-01360-MS	C-104 Supernatant Composite	3.1E-05	2.23E-04 ± 1.74E-06	0.01	1.25 ± 0.02	0.005	0.038 ± 0.008
Check Standard Results are reported in µg/ml (ppm)							
0.005ppm Multi					0.00455 ± 0.00011		0.00517 ± 0.00012
0.005ppm Multi					0.00508 ± 0.00011		0.00536 ± 0.00009
0.002ppm Tc-99							
0.002ppm Tc-99							
0.0004ppm I-127							
0.0005ppm I-127							
0.0001ppm I-129			0.000093 ± 0.000026				
0.0005ppm I-129			0.00050 ± 0.00007				
0.050ppm U							
0.050ppm U							
0.0005ppm Ta,Np							
0.0005ppm Ta,Np							
0.0012ppm Pu							
0.0012ppm Pu							

revised
Barnaga
8/22/00

JLB
8/21/00

C104 Direct

June 9, 2000 (MDL's added 8/17/00)

Results are reported in µg analyte/ml (ppm) of original solution or µCi analyte/ml of original solution.

Sample ID	Client ID	MDL µg/ml	Ta µg/ml ± 1SD	MDL µCi/ml	U-233 µCi/ml ± 1SD	MDL µCi/ml	U-234 µCi/ml ± 1SD
1%-HNO3			<0.0001				
1%-HNO3			<0.0001				
1%-HNO3			<0.0001				
00-01360-DB	DILUENT BLANK	0.003	<0.003	1.4E-05	0.0000	2.5E-06	<2.5E-06
00-01360	C-104 Supernatant Composite	0.003	0.0036 ± 0.0009	1.4E-05	3.15E-04 ±	3.3E-06	1.55E-05 ± 1.25E-07
00-01360-DUP	C-104 Supernatant Composite	0.003	<0.003	2.2E-05	2.18E-04 ±	2.5E-06	1.31E-05 ± 1.31E-07
00-01360+ spike	C-104 Supernatant Composite	0.003	0.253 ± 0.004				
Spike Recovery			106%				
00-01360-MS	C-104 Supernatant Composite	0.003	<0.003 ± 0.0006	3.0E-05	2.45E-04 ±	2.5E-06	2.91E-05 ± 7.48E-07
Check Standard Results are reported in µg/ml (ppm)							
0.005ppm Multi							
0.005ppm Multi							
0.002ppm Tc-99							
0.002ppm Tc-99							
0.0004ppm I-127							
0.0005ppm I-127							
0.0001ppm I-129							
0.0005ppm I-129							
0.050ppm U							
0.050ppm U							
0.0005ppm Ta,Np			0.000483 ± 0.000013				
0.0005ppm Ta,Np			0.000482 ± 0.000003				
0.0012ppm Pu							
0.0012ppm Pu							

reviewed
Barnaby
8/22/00

JB
8/21/00

C104 Direct

June 9, 2000 (MDL's added 8/17/00)

Results are reported in µg analyte/ml (ppm) of original solution or µCi analyte/ml of original solution.

Sample ID	Client ID	MDL µCi/ml	U-235 µCi/ml ± 1SD	MDL µCi/ml	U-236 µCi/ml ± 1SD	MDL µCi/ml	U-238 µCi/ml ± 1SD
1% HNO3							
1% HNO3							
1% HNO3							
00-01360-DB	DILUENT BLANK	2.2E-08	<2.2E-08	4.0E-07	<4.0E-07	3.4E-08	<3.4E-08
00-01360	C-104 Supernatant Composite	2.2E-08	4.80E-07 ±	4.0E-07	6.1E-07 ±	7.8E-08	1.06E-05 ±
00-01360-DUP	C-104 Supernatant Composite	4.7E-08	3.65E-07 ±	4.0E-07	4.3E-07 ±	4.0E-08	7.87E-06 ±
00-01360+ spike	C-104 Supernatant Composite						6.72E-08
Spike Recovery							
00-01360-MS	C-104 Supernatant Composite	1.8E-08	3.11E-07 ±	4.0E-07	4.2E-07 ±	5.3E-08	7.66E-06 ±
Check Standard Results are reported in µg/ml (ppm)							
0.005ppm Multi							
0.005ppm Multi							
0.002ppm Tc-99							
0.002ppm Tc-99							
0.0004ppm I-127							
0.0005ppm I-127							
0.0001ppm I-129							
0.0005ppm I-129							
0.050ppm U							
0.050ppm U							
0.0005ppm Ta,Np							
0.0005ppm Ta,Np							
0.0012ppm Pu							
0.0012ppm Pu							

reviewed
Bannaga
8/22/00

g/Bannaga
8/21/00

C104 Direct

June 9, 2000 (MDL's added 8/17/00, *revised 8/17/00)

Results are reported in µg analyte/ml (ppm) of original solution or µCi analyte/ml of original solution.

Sample ID	Client ID	MDL µg/ml	Total Uranium µg/ml ± 1SD	MDL µCi/ml	Np-237 µCi/ml ± 1SD	MDL µCi/ml	*Pu-239 µCi/ml ± 1SD
1%HNO3			<0.0001		<7.0E-08		<3.8E-07
1%HNO3			<0.0004		<7.0E-08		<3.8E-07
1%HNO3			<0.0005		<7.0E-08		<3.8E-07
00-01360-DB	DILUENT BLANK	0.12	<0.12	2.8E-07	*<2.8E-07	4.8E-04	9.8E-04 1.0E-03
00-01360	C-104 Supernatant Composite	0.2	31.7 ± 0.2	3.2E-07	3.58E-05 ± 4.23E-07	4.8E-04	9.6E-03 ± 2.2E-03
00-01360-DUP	C-104 Supernatant Composite	0.2	23.6 ± 0.2	3.2E-07	3.44E-05 ± 7.75E-07	4.8E-04	4.1E-03 ± 1.4E-04
00-01360+ spike	C-104 Supernatant Composite	0.2	48.1 ± 0.6	3.7E-07	2.15E-04 ± 1.06E-06	4.8E-04	7.10E-02 ± 6.93E-04
Spike Recovery			88%		109%		99%
00-01360-MS	C-104 Supernatant Composite	0.2	22.9 ± 0.1	3.4E-07	3.67E-05 ± 8.46E-07	4.8E-04	3.1E-03 ± 3.6E-04
Check Standard Results are reported in µg/ml (ppm)							
0.005ppm Multi							
0.005ppm Multi							
0.002ppm Tc-99							
0.002ppm Tc-99							
0.0004ppm I-127							
0.0005ppm I-127							
0.0001ppm I-129							
0.0005ppm I-129							
0.050ppm U			0.0482 ± 0.0008				
0.050ppm U			0.0473 ± 0.0002				
0.0005ppm Ta,Np					0.000479 ± 0.000016		
0.0005ppm Ta,Np					0.000493 ± 0.000007		
0.0012ppm Pu							0.00115 ± 0.00025
0.0012ppm Pu							0.00120 ± 0.00008

revised,
Barnard
8/22/00

J. Barnard
8/21/00

C104 Direct

June 9, 2000 (MDL's added 8/17/00, *revised 8/17/00)

Results are reported in µg analyte/ml (ppm) of original solution or µCi analyte/ml of original solution.

Sample ID	Client ID	MDL µCi/ml	*Pu-240 µCi/ml ± 1SD
1% HNO3			<1.1E-05
1% HNO3			<1.1E-05
1% HNO3			<1.1E-05
00-01360-DB	DILUENT BLANK	1.0E-03	<1.0E-03
00-01360	C-104 Supernatant Composite	1.2E-03	2.7E-03 ± 6.8E-04
00-01360-DUP	C-104 Supernatant Composite	1.0E-03	1.3E-03 ± 3.6E-04
00-01360+ spike	C-104 Supernatant Composite		
Spike Recovery			
00-01360-MS	C-104 Supernatant Composite	1.3E-03	<1.3E-03
Check Standard Results are reported in µg/ml (ppm)			
0.005ppm Multi			
0.005ppm Multi			
0.002ppm Tc-99			
0.002ppm Tc-99			
0.0004ppm I-127			
0.0005ppm I-127			
0.0001ppm I-129			
0.0005ppm I-129			
0.050ppm U			
0.050ppm U			
0.0005ppm Ta,Np			
0.0005ppm Ta,Np			
0.0012ppm Pu			
0.0012ppm Pu			

JPB
8/21/00

revised
JPB
8/22/00

C104 Ni/KOH Fusion

June 9, 2000 (MDL'S added 8/17/00, *revised 8/17/00)

Results are reported in μg analyte/g (ppm) of wet centrifuged solids, or μCi analyte/g of wet centrifuged solids.

Sample ID	Client ID	MDL $\mu\text{g/g}$	Fb $\mu\text{g/g}$ $\pm 1 \text{ SD}$	MDL $\mu\text{Ci/g}$	Tc-99 $\mu\text{Ci/g}$ $\pm 1 \text{ SD}$	MDL $\mu\text{g/g}$	I-127 $\mu\text{g/g}$ $\pm 1 \text{ SD}$
1% HNO_3			<0.0001		<0.00003		0.0001 \pm 0.0001
1% HNO_3			<0.0005		<0.00002		0.0001 \pm 0.0001
1% HNO_3			<0.0002		<0.00002		0.0001 \pm 0.0001
00-01361-PB	PROCESS BLANK	0.3	98.7 \pm 2.4	0.0015	<0.0015	0.6	1.1 \pm 1.3
00-01361	C-104 Centrifuged Solids Composite	0.5	170 \pm 6	0.002	0.0265 \pm 0.0006	0.6	17 \pm 2
00-01361	C-104 Centrifuged Solids Composite	0.4	152 \pm 4	0.002	0.0290 \pm 0.0004	0.6	19 \pm 4
00-01361 + spike	C-104 Centrifuged Solids Composite	0.5	202 \pm 2	0.002	0.154 \pm 0.005	0.6	35.3 \pm 2.4
Spike Recovery			105%		125%		124%
SRM 2710	LCS/00-01361/Ni	0.8	447 \pm 25	0.004	*0.0561 \pm 0.0059	1.1	13 \pm 2
Check Standards results are reported in $\mu\text{g/ml}$ (ppm)							
0.01ppm Multi			0.0104 \pm 0.0001				
0.01ppm Multi			0.0108 \pm 0.0010				
0.002ppm Tc-99					0.00202 \pm 0.00001		0.00038 \pm 0.00010
0.002ppm Tc-99					0.00226 \pm 0.00001		0.00051 \pm 0.00012
0.0004ppm I-127							
0.0005ppm I-127							
0.0001ppm I-129							
0.0005ppm I-129							
0.020ppm U							
0.200ppm U							
0.002ppm Ta							
0.002ppm Ta, Np							
0.010ppm Np-237							
0.001ppm Pu							
0.001ppm Pu							

reviewed
Barnes
8/22/00

JBarnes
8/21/00

C104 Ni/KOH Fusion

June 9, 2000 (MDL'S added 8/17/00, *revised 8/17/00)

Results are reported in µg analyte/g (ppm) of wet centrifuged solids, or µCi analyte/g of wet centrifuged solids.

Sample ID	Client ID	MDL µCi/g	I-129 µCi/g	MDL µg/g	Qs µg/g	MDL µg/g	Pr µg/g	MDL µg/g
1% HNO3			<0.00007		<0.0001		<0.0001	
1% HNO3			<0.00008		<0.0004		<0.0001	
1% HNO3			<0.00009		<0.0002		<0.0001	
00-01361-PB	PROCESS BLANK	2.3E-04	<2.3E-04	0.2	0.4 ± 0.2	0.2	0.4 ± 0.1	
00-01361	C-104 Centrifuged Solids Composite	2.2E-04	5.0E-04 ± 8.2E-05	0.3	1.87 ± 0.13	0.4	40.8 ± 1.2	
00-01361	C-104 Centrifuged Solids Composite	2.4E-04	4.1E-04 ± 8.2E-05	0.2	2.13 ± 0.17	0.3	43.8 ± 0.5	
00-01361 + spike	C-104 Centrifuged Solids Composite	2.4E-04	1.02E-03 ± 4.64E-05	0.3	17.8 ± 0.4	0.4	62.6 ± 0.6	
Spike Recovery			97%		105%		112%	
SRM 2710	LCS/00-01361/Ni	4.3E-04	* <4.3E-04	0.4	117 ± 7	0.6	8.0 ± 1.2	
Check Standards results are reported in µg/ml (ppm)								
0.01ppm Multi					0.00990 ± 0.00001		0.0110 ± 0.0010	
0.01ppm Multi					0.0108 ± 0.0010		0.0104 ± 0.0010	
0.002ppm Tc-99								
0.002ppm Tc-99								
0.0004ppm I-127								
0.0005ppm I-127								
0.0001ppm I-129			0.000093 ±	0.000026				
0.0005ppm I-129			0.00050 ±	0.00007				
0.020ppm U								
0.200ppm U								
0.002ppm Ta								
0.002ppm Ta, Np								
0.010ppm Np-237								
0.001ppm Pu								
0.001ppm Pu								

revised
8/22/00

8/21/00

C104 Ni/KOH Fusion

June 9, 2000 (MDL'S added 8/17/00, *revised 8/17/00)

Results are reported in µg analyte/g (ppm) of wet centrifuged solids, or µCi analyte/g of wet centrifuged solids.

Sample ID	Client ID	MDL µg/g	Ta µg/g ± 1 SD	MDL µCi/g	U-233 µCi/g ± 1 SD	MDL µCi/g	U-234 µCi/g ± 1 SD
1% ³ HNO ₃			<0.0001				
1% ² HNO ₃			<0.0001				
1% ¹ HNO ₃			<0.0001				
00-01361-PB	PROCESS BLANK	0.14	* <0.14	6.8E-03	<6.8E-03	4.4E-03	<4.4E-03
00-01361	C-104 Centrifuged Solids Composite	0.09	1.06 ±	6.8E-03	2.56E-01 ±	5.8E-03	1.01E-02 ±
00-01361	C-104 Centrifuged Solids Composite	0.07	1.05 ±	6.8E-03	2.43E-01 ±	2.8E-03	1.50E-02 ±
00-01361 + spike	C-104 Centrifuged Solids Composite	0.12	3.48 ±	0.08	5.70E-03		3.69E-05
Spike Recovery			80%				
SRM 2710	LCS/00-01361/Ni	0.15	1.16 ±	0.05	* <1.2E-02	7.5E-03	* <7.5E-03
Check Standards results are reported in µg/ml (ppm)							
0.01ppm Multi							
0.01ppm Multi							
0.002ppm Tc-99							
0.002ppm Tc-99							
0.0004ppm I-127							
0.0005ppm I-127							
0.0001ppm I-129							
0.0005ppm I-129							
0.020ppm U							
0.200ppm U							
0.002ppm Ta			0.00201 ± 0.00010				
0.002ppm Ta, Np			0.00181 ± 0.00010				
0.010ppm Np-237							
0.001ppm Pu							
0.001ppm Pu							

renewed
Barnes
8/22/00

JLB
8/21/00

C104 Ni/KOH Fusion

June 9, 2000 (MDL'S added 8/17/00, *revised 8/17/00)

Results are reported in µg analyte/g (ppm) of wet centrifuged solids, or µCi analyte/g of wet centrifuged solids.

Sample ID	Client ID	MDL µCi/g	U-235 µCi/g	± 1 SD	MDL µCi/g	U-236 µCi/g	± 1 SD	MDL µCi/g	U-238 µCi/g	± 1 SD
1% HNO3										
1% HNO3										
1% HNO3										
00-01361-PB	PROCESS BLANK	1.6E-05	<1.6E-05		4.6E-05	<4.6E-05		2.7E-05	<2.7E-05	
00-01361	C-104 Centrifuged Solids Composite	1.6E-05	3.35E-04 ±	1.92E-05	4.6E-05	3.86E-04 ±	2.30E-05	7.9E-05	7.13E-03 ±	4.17E-04
00-01361	C-104 Centrifuged Solids Composite	1.6E-05	3.14E-04 ±	1.28E-06	6.1E-05	4.40E-04 ±	3.83E-06	5.6E-05	7.03E-03 ±	1.99E-05
00-01361 + spike	C-104 Centrifuged Solids Composite									
Spike Recovery										
SRM 2710	LCS/00-01361/Ni	1.7E-05	* <1.7E-05		7.8E-05	* <7.8E-05		3.5E-07	* 9.01E-06 ±	5.04E-07
Check Standards results are reported in µg/ml (ppm)										
0.01ppm Multi										
0.01ppm Multi										
0.002ppm Tc-99										
0.002ppm Tc-99										
0.0004ppm I-127										
0.0005ppm I-127										
0.0001ppm I-129										
0.0005ppm I-129										
0.020ppm U										
0.200ppm U										
0.002ppm Ta										
0.002ppm Ta, Np										
0.010ppm Np-237										
0.001ppm Pu										
0.001ppm Pu										

revised
Bannan
8/22/00

J.P. Bannan
8/21/00

C104 Ni/KOH Fusion

June 9, 2000 (MDL'S added 8/17/00, *revised 8/17/00)

Results are reported in µg analyte/g (ppm) of wet centrifuged solids, or µCi analyte/g of wet centrifuged solids.

Sample ID	Client ID	MDL µg/g	Total Uranium µg/g ± 1 SD	MDL µCi/g	Np-237 µCi/g ± 1 SD	MDL µCi/g	Pu-239 µCi/g ± 1 SD
1% HNO3			<0.0005		<0.0001		<0.0001
1% HNO3			<0.0004		<0.0001		<0.0001
1% HNO3			<0.0005		<0.0001		<0.0001
00-01361-PB	PROCESS BLANK	84	<84	1.7E-04	<1.7E-04	2.9E-01	<2.9E-01
00-01361	C-104 Centrifuged Solids Composite 70		21400 ± 1200	1.8E-04	2.55E-03 ± 6.67E-05	2.9E-01	2.10E+00 ± 1.83E-01
00-01361	C-104 Centrifuged Solids Composite 50		21000 ± 60	1.7E-04	2.75E-03 ± 1.54E-04	2.9E-01	2.18E+00 ± 1.47E-01
00-01361 + spike	C-104 Centrifuged Solids Composite 70		23800 ± 1400	2.4E-04	5.04E-03 ± 2.08E-04	5.9E-01	1.17E+01 ± 6.23E-01
Spike Recovery			79%		117%		103%
SRM 2710	LCS/00-01361/Ni	3	27.0 ± 1.5	3.0E-04	* <3.0E-04	2.6E-02	* 2.9E-02 ± 2.9E-03
Check Standards results are reported in µg/ml (ppm)							
0.01ppm Multi							
0.01ppm Multi							
0.002ppm Tc-99							
0.002ppm Tc-99							
0.0004ppm I-127							
0.0005ppm I-127							
0.0001ppm I-129							
0.0005ppm I-129							
0.020ppm U			0.0218 ± 0.0010				
0.200ppm U			0.189 ± 0.0030				
0.002ppm Ta							
0.002ppm Ta, Np					0.00215 ± 0.00010		
0.010ppm Np-237					0.0100 ± 0.0001		
0.001ppm Pu							0.00101 ± 0.00010
0.001ppm Pu							0.00103 ± 0.00010

revised
8/22/00
Barnaga

9/13/00
8/21/00

C104 Ni/KOH Fusion

June 9, 2000 (MDL'S added 8/17/00, *revised 8/17/00)

Results are reported in µg analyte/g (ppm) of wet centrifuged solids, or µCi analyte/g of wet centrifuged solids.

Sample ID	Client ID	MDL µCi/g	Pu-240 µCi/g ± 1 SD
1%HNO3			<0.0001
1%HNO3			<0.0001
1%HNO3			<0.0001
00-01361-PB	PROCESS BLANK	2.7E-02	<2.7E-02
00-01361	C-104 Centrifuged Solids Composite	2.7E-02	6.77E-01 ± 2.90E-02
00-01361	C-104 Centrifuged Solids Composite	2.7E-02	6.53E-01 ± 1.47E-02
00-01361 + spike	C-104 Centrifuged Solids Composite		
Spike Recovery			
SRM 2710	LCS/00-01361/Ni	3.8E-02	*<3.8E-02
Check Standards results are reported in µg/ml (ppm)			
0.01ppm Multi			
0.01ppm Multi			
0.002ppm Tc-99			
0.002ppm Tc-99			
0.0004ppm I-127			
0.0005ppm I-127			
0.0001ppm I-129			
0.0005ppm I-129			
0.020ppm U			
0.200ppm U			
0.002ppm Ta			
0.002ppm Ta, Np			
0.010ppm Np-237			
0.001ppm Pu			
0.001ppm Pu			

gBanna
8/21/00

revised.
gBanna
8/22/00

J. Brown
8/21/00

reviewed
Barinaga
8/22/00

C104 Platinum

June 9, 2000 (MDL's added 8/17/00)

Results are reported in μg analyte/g (ppm) wet centrifuged solids

Sample ID	Client ID	MDL $\mu\text{g/g}$	Pt $\mu\text{g/g}$	
1%HNO ₃			<0.007	
1%HNO ₃			<0.007	
1%HNO ₃			<0.009	
00-01361-PB-Zr	PROCESS BLANK	0.05	0.080 \pm	0.001
00-01361-Zr	C-104 Centrifuged Solids Composite	0.05	0.209 \pm	0.003
00-01361-DUP-Zr	C-104 Centrifuged Solids Composite	0.05	0.314 \pm	0.001
00-01361-Zr + spike	C-104 Centrifuged Solids Composite	0.05	0.528 \pm	0.012
Spike Recovery			102%	
SRM 2710-Zr	LCS/00-01361/Zr	0.07	0.181 \pm	0.011
0.1ppb Pt CCV			0.0934 \pm	0.0050
0.5ppb Pt CCV			0.445 \pm	0.003

C104 Cesium Isotopic Analysis

June 5, 2000

J.P. Brown
8/21/00

Sample ID	Client ID	135/137 Ratio	Standard Deviation	%RSD	135 abundance	137 abundance	138 abundance
Barium Standard True Value		Not detectable			0.0732	0.1255	0.8013
					0.0736	0.1264	0.8000
Reagent Blank		Not detectable					
ACID DIGESTION							
00-01360-PB	PROCESS BLANK	Not detectable					
00-01360-BS	BLANK SPIKE	Not detectable					
00-01360	C-104 Supernatant Composite	0.789	0.01	1.3			
00-01360-DUP	C-104 Supernatant Composite	0.781	0.01	1.7			
00-01360-MS	C-104 Supernatant Composite	0.793	0.01	1.1			

NI/KOH FUSION							
PROCESS BLANK		Not detectable					
SRM 2710	LCS/00-01361/Ni	Not detectable					
00-01361	C-104 Centrifuged Solids Composite	0.762	0.04	5.1			
00-01361-DUP	C-104 Centrifuged Solids Composite	0.744	0.04	4.9			

Sample ID	Client ID	135/137 Ratio	Standard Deviation	%RSD	135 abundance	137 abundance	138 abundance
Barium Standard True Value		Not detectable			0.0714	0.1292	0.7994
					0.0736	0.1264	0.8000
Reagent Blank		Not detectable					
DIRECT							
00-01360-DB	DILUENT BLANK	Not detectable					
00-01360	C-104 Supernatant Composite	0.790	0.05	5.7			
00-01360-DUP	C-104 Supernatant Composite	0.775	0.02	2.2			
00-01360-MS	C-104 Supernatant Composite	0.782	0.04	5.4			

reviewed
Samara
8/22/00

Battelle PNNL/RPG/Inorganic Analysis --- TOC/TIC Report

Client: BNFL Task 5
ACL Numbers: 00-1360 and 00-1361
Analyst: MJ Steele

Charge Code/Project: W45439 / 29274
ASR Number: 5729
Analysis Date: June 28, 2000

Procedure: PNL-ALO-381, "Direct Determination of TC, TOC, and TIC in Radioactive Sludges and Liquids by Hot Persulfate Method"
 PNL-ALO-380, "Determination of Carbon in Solids Using the Coulometric Carbon Dioxide Coulometer"

M&TE: Carbon Analysis System (WA92040); Balance (360-06-01-023).

Final Results:

RPL Number	Sample ID	HOT PERSULFATE METHOD						FURNACE METHOD	
		TIC ($\mu\text{gC/ml}$)	TIC RPD	TOC ($\mu\text{gC/ml}$)	TOC RPD	TC ($\mu\text{gC/ml}$)	TC RPD	TC ($\mu\text{gC/ml}$)	TC RPD
00-01361	C-104 Centrifuged Solids	4,200		10,300		14,500		24,800	
00-01361 Dup	C-104 Centrifuged Solids Dup	3,800	10%	7,700	29%	11,500	23%	22,100	12%
	Solids MDL	120		350		--		500	
00-01361 MS	C-104 Centrifuged Solids MS	87%		79%		82%		105%	
00-01360	C-104 Supernatant	8,330		6,500		14,800		14,900	
00-01360 Dup	C-104 Supernatant Dup	8,270	1%	6,720	3%	15,000	1%	14,100	6%
	Supernatant MDL	70		200		--		180	
00-01360 MS	C-104 Supernatant MS	96%		102%		99%		105%	

RPD = Relative Percent Difference

The analysis of the solids and supernatant samples submitted under ASR 5729 was performed by the hot persulfate wet oxidation method and by the furnace oxidation method. The hot persulfate method uses acid decomposition for TIC and acidic potassium persulfate oxidation at 92-95°C for TOC, all on the same sample, with TC being the sum of the TIC and TOC. The furnace oxidation method determines TC by oxidizing all forms of carbon (i.e., inorganic and organic) in oxygen at 1000 °C. Under normal conditions, the furnace method and hot persulfate method should provide equivalent TC results. The supernatant results demonstrated good agreement between the furnace and hot persulfate methods, with the average hot persulfate TC being 14,900 $\mu\text{g/ml}$ and the furnace TC being 14,300 $\mu\text{g/ml}$. However, the agreement between the furnace and hot persulfate TC for the centrifuged solids strongly suggest that carbon compounds (most likely organic carbon compounds) exist that are not well decomposed by the hot persulfate method. That is, the TC for from the furnace methods is nearly twice the level measured in from the hot persulfate method; i.e., approximately 23,000 versus 13,000 $\mu\text{g/g}$, respectively.

The table above shows the results, rounded to two to three significant figures. The raw data bench sheets and calculation work sheets showing all calculations are attached. All sample results are corrected for average percent recovery of system calibration standards and are also corrected for contribution from the blank.

Battelle PNNL/RPG/Inorganic Analysis --- TOC/TIC Report

Q.C. Comments:

The TIC standard is calcium carbonate and TOC/TC standard is α -Glucose (the certificates of purity are attached). The standard materials were used in solid form for system calibration check standards as well as matrix spikes. The QC for the methods involves calibration blanks, system calibration standards, sample duplicates, and one matrix spike per matrix type.

Calibration Standards: The QC system calibration check standards were all within acceptance criteria of 90% to 110%, except for the hot persulfate TOC which demonstrated an average recovery of 88%. Although this recovery is slightly lower than the acceptance criteria, the recovery results were consistent. Since the final results are corrected for the average organic carbon recovery, the slightly low recovery is not expected to significantly effect the results.

Calibration Blanks: The calibration blanks run at the beginning, middle, and end of the analysis runs were acceptable and the standard deviations for the TIC and TOC blanks at or below the historical pooled standard deviation used to establish the method detection limits.

Duplicates: The relative percent difference (RPD) between duplicates was less the acceptance criteria of 20% for TIC, TOC, and TC, except for the TOC and TC from the hot persulfate method. This is another indication that organic compounds may be present that do not decompose readily in the acidic persulfate environment.

Matrix Spike: The accuracy of the carbon measurements can be estimated by the recovery results from the matrix spike. All spike recoveries were within the acceptance criteria of 75% to 125%. However, the matrix spike for the hot persulfate method demonstrated somewhat low recoveries from 79% to 87% for TIC, TOC, and TC for the solids matrix. Although these recoveries are within the acceptance criteria, the low recoveries again indicate some difficulties either in subsampling the solids sample or in ability of the hot persulfate method to produce consistent results from the specific sample matrix.

Laboratory Control Sample: No LCS is included in the carbon analysis procedure.

General Comments:

- The reported "Final Results" have been corrected for all dilution performed on the sample during processing or analysis.
- Routine precision and bias are typically $\pm 15\%$ or better for non-complex samples that are free of interferences.
- The estimated quantitation limit (EQL) is defined as 5 times the MDL. Results less than 5 times the MDL have higher uncertainties, and RPDs are not calculated for any results less than 5 times the MDL.
- Some results may be reported as less than (" $<$ ") values. These less than values represent the sample MDL (method detection limit), which is the system MDL adjusted for the volume of sample used for the analysis. The system MDL is based on the attached pooled historical blank data. The evaluation and calculation of the system MDL is included in the data package.

Report Prepared by: MW Urie

Date 7-13-00

Review/Approval by: D. R. [Signature]

Date 8-11-00

Archive Information:

Files: ASR 5729 Urie.doc

ASR 5729 Urie Persulfate.xls ASR 5729 Urie Furnace.xls

Battelle PNNL/RPG/Inorganic Analysis --- IC Report

Client: BNFL/Task 5
RPL Numbers: 00-1360, 1361
Analyst: MJ Steele

Charge Code/Project: W49438/29214
ASR Number: 29953-5729
Analysis Date: April 23-24, 2000

Procedure: PNL-ALO-212, "Determination of Inorganic Anions by Ion Chromatography"
M&TE: IC system (WD25214); Balance (360-06-01-031) --- See Chemical Measurement Center 98620 RIDS IC File for Calibration, Standards Preparations, and Maintenance Records.

Final Results:

RPL Number	Leached-Centrifuged Solids Sample ID	F(*) µg/g	Cl µg/g	NO ₂ µg/g	Br µg/g	NO ₃ µg/g	PO ₄ µg/g	SO ₄ µg/g	C ₂ O ₄ µg/g	
Wet Weight Basis (as Analyzed)										Dil Fctr
00-1361 PB	C-104 Solids Prep Blank	< 25	26	< 50	< 25	< 50	< 50	< 50	< 50	96.17
00-1361	C-104 Cent. Solids	49,200	260	11,200	1,090	5,990	10,300	1,520	8,180	97.15
00-1361Dup	C-104 Cent. Solids Dup	50,100	230	10,900	1,060	5,790	2,700	1,460	7,710	95.20
	RPD	2%	12%	3%	3%	3%	117%	4%	6%	
00-1361 MS	C-104 Cent. Solids MS %Rec	OvrRng	108%	100%	105%	108%	104%	107%	102%	
Wet Weight Basis (adjusted to Initial Wt % Solids)										Adj. Factor
00-1361 PB	C-104 Solids Prep Blank	< 24.0	26.1	< 48.1	< 24.0	< 48.1	< 48.1	< 48.1	< 48.1	0.95
00-1361	C-104 Cent. Solids	46,200	250	10,500	1,020	5,630	9,650	1,430	7,690	0.94
00-1361Dup	C-104 Cent. Solids Dup	48,300	220	10,500	1,020	5,590	2,600	1,410	7,440	0.97
	RPD	4%	13%	0%	0%	1%	115%	1%	3%	
Dry Weight Basis										Wt% Solids
00-1361 PB	C-104 Solids Prep Blank	< 40	42	< 80	< 40	< 80	< 80	< 80	< 80	59.10
00-1361	C-104 Cent. Solids	78,700	420	17,900	1,740	9,570	16,400	2,430	13,100	58.76
00-1361Dup	C-104 Cent. Solids Dup	81,300	370	17,600	1,720	9,410	4,400	2,380	12,500	59.43
	RPD	3%	13%	2%	1%	2%	115%	2%	5%	

RPL Number	Supernatant Sample ID	F(*) µg/ml	Cl µg/ml	NO ₂ µg/ml	Br µg/ml	NO ₃ µg/ml	PO ₄ µg/ml	SO ₄ µg/ml	C ₂ O ₄ µg/ml
00-1360	C-104 Supernatant Comp.	9,710	790	34,200	3,270	17,600	3,040	3,870	3,590
00-1360 Dup	C-104 Supernatant Comp. Dup	9,500	720	29,100	2,920	16,100	2,640	3,410	3,260
	RPD	2%	9%	16%	11%	9%	14%	13%	10%
00-1360 MS	C-104 Supernatant Comp. MS %Rec	n/a	106%	81%	100%	112%	109%	108%	107%
	Blank Spike %Recovery	110%	107%	105%	108%	78%	104%	106%	107%

RPD = Relative Percent Difference

MS %Rec = Matrix Spike Standard % Recovery

(*) Use fluoride results with reservation; IC system can not resolve fluoride, acetate, and formate

The C-104 composite samples (00-1360 supernatant and 00-1361 centrifuged solids) were analyzed in duplicate by ion chromatography (IC) for inorganic anions as specified in Test Plan BNFL-29953-030. The final results are presented in the table above. All analytical samples

Battelle PNNL/RPG/Inorganic Analysis --- IC Report

were diluted 10 to 2000 fold at the IC workstation to ensure that all anions reported were measured within the calibration range.

The wet centrifuged solids were originally sub-sampled at the same time as all other analytical sub-samples to ensure that all analyses would use the same weight percent solids (of the centrifuged solids) when reporting concentrations on a dry weight basis. Unfortunately the IC sub-samples has to be re-sampled due to a problem encountered during the leaching operation. At the time of the re-sampling, a weight percent solids was performed. This weight percent solids showed a slight loss in water due to some drying of the wet centrifuged solids. A ratio of the original weight percent solids to the resample weight percent solids has been used to adjust the measured IC results to the original sub-sample concentration. This allows direct comparison of the IC results with other analytical results on the wet centrifuged solids. Once adjusted, the IC results have been reported on a dry weight basis using the original weight percent solids results.

For IC column and parameters used, the IC system can not separate fluoride, acetate, and formate; the IC system quantifies and reports all as fluoride. It is unlikely that the levels of fluoride quantified are present in the tank waste, and since both acetate and formate could be present in the C-104 sample, the fluoride results should be used with reservation.

Q.C. Comments:

Duplicates: Duplicate water leaches of wet centrifuged solids sample 00-1361 were performed in the SAL, along with a water leach processing blank. Duplicates for the supernatant sample 00-1360 were prepared at the IC workstation. All RPDs are within the acceptance criteria of 20%, except for phosphate on the water leach of the wet centrifuged solids. The effectiveness of the water leach to maintain phosphate in solution is considered the primary cause of the large discrepancy in the phosphate results.

Matrix Spike: Matrix spikes was prepared for both the leached solids and supernatant samples and all anion recoveries were within the 75% to 125% recovery acceptance criteria. However, the fluoride matrix spike for the leached solids was over-range and could not be quantified; the spike concentration was about one-tenth the sample concentration making the fluoride MS meaningless.

Blank Spike: The working spike (i.e., the spike solution used to prepare the matrix spike samples) was diluted and measured at the same time as the Matrix Spike samples and demonstrated recoveries within the 90% to 110% acceptance criteria, except for nitrate. Other standards analyses during the analytical run demonstrated good nitrate recovery and the poor nitrate recovery from the blank spike is not considered to affect the reported results.

Battelle PNNL/RPG/Inorganic Analysis --- IC Report

System Blank/Processing Blanks: Five system blanks were processed during the analysis of the liquid sample. No anions were detected in the system blanks above the estimate quantitation level.

Quality Control Calibration Verification Check Standards: Four mid-range verification standards were analyzed throughout the analysis runs. For most of the anions recoveries were within the acceptance criteria from 90% to 110% for the verification standard. However, due to column degradation caused by a sample from another ASR, one verification standard produced low recoveries (i.e., 80% to 90%). Column performance was recovered following continued use (i.e., flushing by the eluent), and the reported results are considered valid.

General Comments:

- The reported "Final Results" have been corrected for all dilution performed on the sample during processing or analysis.
- The low calibration standards are defined as the estimated quantitation limit (EQL) for the reported results and assume non-complex aqueous matrices. Actual detection limits or quantitation limits for specific sample matrices may be determined, if requested.
- Routine precision and bias are typically $\pm 15\%$ or better for non-complex aqueous samples that are free of interference and have similar concentrations as the measured anions.

Analyst:

MJ Steele

Date

5/2/00

Approval:

MW Lewis

Date

5/2/00

Archive Information:

Files: ASR 5729 Urie.doc

ASR 5729 5784-86 5778.xls

Battelle PNNL/RPG/Inorganic Analysis ---Hg Report

page 1 of 3

WO/Project: W49436/29274
Client: M. Urie

RPL Numbers: 00-01360 & 00-01361
ASR Number 5729

Procedure: PNNL-ALO-131, "Mercury Digestion"
PNNL-ALO-201, "Mercury Analysis"

Analyst: J. J. Wagner

Digestion Date: May 10, 2000 Analysis Date: May 11, 2000

M&TE: Hg system (WD14126); Mettler AT400 Balance (360-06-01-029).
See Chemical Measurement Center 98620 RIDS for Hg File for Calibration, Standards
Preparations, and Maintenance Records.

Analyst: Jerry Wagner 5-17-00

Approval: MU Urie Date 5-17-00

Final Results:

The samples were analyzed by cold vapor atomic absorption spectrophotometry for inorganic mercury as specified in ASR 5729. Approximately 0.10g weight of centrifuged solids and approximately 0.5ml (0.57g weight) of supernatant liquid samples were transferred to glass digestion vessels by SAL. Samples were processed and diluted to a final volume of 25.5ml to 27ml per procedure ALO-131. Supernatant samples were processed with 0.5g additional potassium permanganate. Centrifuged solids were processed with 1g additional potassium permanganate. The increased amount of potassium permanganate was used to ensure complete oxidation of potential organic material in the samples. Processed blanks, blank-spike and matrix-spiked samples were all treated similarly. Analytical dilution of 2 to 51-fold was necessary for some samples. The mercury concentration results are presented in the table below.

Battelle PNNL/RPG/Inorganic Analysis ---Hg Report

page 2 of 3

Lab ID	Liquid Sample ID	Sample Weight (g)	Sample Volume (ml)	Digestion Factor	Analytic Dilution Factor	Hg $\mu\text{g/ml}$	RPD (%)
00-01360-PB	Process Blank		#0.5	51	1	0.014	
00-01360	C-104 Supernatant Composite	0.5795	0.5	51	5	0.722	
00-01360DUP	C-104 Supernatant Composite	0.5729	0.5	51	5	0.602	20

Lab ID	Solid Sample ID	Sample Weight (g wet)	Digestion Factor	Analytic Dilution Factor	Hg $\mu\text{g/g}$ (wet wt)	Percent Solids (%)	Hg $\mu\text{g/g}$ (dry wt)	RPD (%)
00-01361-PB	Process Blank	#0.1045	#258.5	1	#<0.05	#59.1	#<0.09	
00-01361	C-104 Centrifuged Solids Composite	0.1026	263.2	51	41.1	59.1	69.5	
00-01361DUP	C-104 Centrifuged Solids Composite	0.1064	253.8	51	40.2	59.1	68.1	2.2

RPD = Relative Percent Difference (between sample and duplicate/replicate)

N/A = RPD is not calculated when results are less than 5 x IDL

"*" Field duplicate samples

"#" Volume or weight and %solids for the process blank are averages of sample volumes or weights and %solids.

Notes:

- 1) "Final Results" have been corrected for all dilution performed on the sample during processing or analysis.
- 2) The low calibration standard is defined as the estimated detection limit (IDL) for the reported results and assumes non-complex aqueous matrices. Actual detection limits or quantitation limits for specific sample matrices may be determined, if requested.
- 3) Routine precision and bias is typically $\pm 15\%$ or better for non-complex aqueous samples that are free of interference.

Q.C. Comments:

Following are results of quality control checks performed during Hg analyses. In general, quality control checks met the requirements of the governing QA Plan.

Process Blank Spike (liquids & solids): Process Blank Spike recovery (104% and 108% respectively) is within the acceptance criteria of 80% to 120%.

Matrix Spiked Sample (liquids): A matrix spike was prepared for the supernatant samples submitted under ASR-5729. Recovery of the matrix spike (96%) is within acceptance criteria of 75% to 125%.

Matrix Spiked Sample (solids): A matrix spike was also prepared for the solids samples submitted under ASR-5729. Recovery of the matrix spike could not be determined because high concentration in the solids sample was approximately 160 times greater than the spike concentration.

Duplicate Relative Percent Difference (liquids): RPD for duplicate supernatant samples is just within acceptance criteria of $\leq 20\%$ RPD for RPL# 00-01360, 00-01360D (20% RPD).

Duplicate Relative Percent Difference (solids): RPD for duplicate solid samples is well within acceptance criteria of $\leq 20\%$ RPD for RPL# 00-01361, 00-01361D (2% RPD).

Laboratory Control Sample (solids): Sample recovery of mercury in SRM-2709 San Joaquin Valley Soil certified by NIST to contain 1.40 ± 0.08 $\mu\text{g/g}$ was recovered within acceptance criteria of 75% to 125%. LCSS recovery is 107% and 113% for the two aliquots.

Laboratory Control Sample (liquids): Sample recovery of mercury in SRM-1641d "Mercury in H_2O " certified by NIST to contain 1.60 $\mu\text{g/ml}$ was recovered (100% and 102%), well within acceptance criteria of 75% to 125%.

Process Blanks: The separately prepared process blank concentrations for the solid and liquid prepared samples were both less than two times detection limit. The concentration in the process blanks was less than about 50-times that measured in either the liquid or solid samples.

Quality Control Calibration Verification Check Standards: Three mid-range verification standards were analyzed throughout the analysis run. All were within the acceptance criteria of 80% to 120% recovery for the verification standard. The measured concentrations varied from a minimum of 96% recovery to a maximum of 105% recovery.

Date June 21, 2000

To BNFL

From M. Urie



 Subject Cyanide Results for C-104
Table 1: Total CN Results

Sample ID	C-104 Supernatant		C-104 Wet Centrifuged Solids	
	RPL Number	CN (ug/mL)	RPL Number	CN (ug/g)
Cell Blank	00-1360 cell blk	< 0.01	00-1361 cell blk	< 0.04
C-104 Sample	00-1360	7.4	00-1361	11.4
C-104 Duplicate	00-1360 d	8.5	00-1361d	13.8
RPD (%)		14		19
MS Recovery (%)		94		111

The CN analyses for C-104 supernatants and wet centrifuged solids were performed on May 11, 2000 and June 12, 2000, respectively. The results are presented in Table 1. Due to dose, the samples were weighed into the distillation tubes in the Shielded Analytical Laboratory and then transferred to the CN Workstation for distillation and analysis. The samples were distilled with the addition of sulfamic acid to ensure there would be no interference from high nitrates present in the sample. The samples were analyzed using a Lachat QuickChem AE Autoanalyzer (WC36517). Based on the average sample sizes taken for analysis and the analytical dilutions applied, the method detection limits (MDL) are estimated at 0.250 µg/ml for the supernatant samples and 0.2 µg/g for the solids samples.

All sample preparation sheets, standard preparation information, and analytical data are included with this report

QC Evaluation:

No quality control or other measurement problems were encountered during either analysis run. However, the results reported represent results obtained from reruns of the C-104 supernatant and solid, since an initial analysis produced very inconsistent results and multiple QC failures.

The independent mid-range calibration check solution run at the beginning, middle, and end of the analysis batch on each day gave recoveries ranging from 97% to 101%; each recovery was within the 85% to 115% acceptance criteria of the governing QA plan.

The C-104 supernatant and solids were each analyzed in duplicate. The Relative Percent Difference (RPD) between the sample and duplicate was 14% for the supernatant and 19% for the wet centrifuged solids. Although the RPDs are within the acceptance criteria of 20%, they are higher than normal. The relatively

BNFL

June 21, 2000

Page 2

small sample sizes used to minimize personnel exposure are most likely a major contributor to the poor precision.

For the C-104 supernatants, a distilled Blank Spike sample was used as the Laboratory Control Sample (LCS). The Blank Spike recovery was 101%, well within the acceptance criteria of 80% to 120%. For the C-104 solids, a solid LCS (ERA PriorityPollutnt™) was analyzed. The solid LCS was analyzed at 165 µg/g and 173 µg/g, well within the certified advisory range of 77 µg/g to 301 µg/g.

The spike recovery for the C-104 supernatant spike was 94% and for the wet centrifuged solids was 111%, well within the acceptance criteria of 75% to 125%. The small sample sizes used for the analyses and the apparent sample heterogeneity (i.e., high RPDs) significantly impact the recovery calculation. Therefore, for both the supernatants and the solids the average cyanide concentration (i.e., average of sample and duplicate) has been used to calculate spike recoveries.

Concur: Jersey Wagner

8-9-00
(date)

Memo File: CN ASR 5729 Urie.doc

Spreadsheet File: ASR 5729 Solids 5847 Glasses.xls
and ASR 5729 Liquids 5788 Kurath. xls

Battelle Pacific Northwest Laboratory
Radiochemical Processing Group-325 Building
Chemical Measurements Center

00-1360 NH3
8/10/00

Client : M. Urie

Cognizant Scientist:

L.R. Guenzel

Date : 8-10-00

Concur :

S.K. Fisk

Date : 8/10/00

Measured Concentration with 1- σ error

ALO ID Client ID	NH ₃ Error %	
00-1360 C-104 Supernatant Comp.	1.74E+1 8%	$\mu\text{g/ml}$
00-1360 Dup C-104 Supernatant Comp.	1.92E+1 8%	$\mu\text{g/ml}$
RPD	10%	
00-1361 C-104 Centrifuged Solids Comp.	3.38E+0 7%	$\mu\text{g/g}$
00-1361 Dup C-104 Centrifuged Solids Comp.	3.09E+0 7%	$\mu\text{g/g}$
RPD	9%	
00-1361 Process Blank	1.05E+0 11%	$\mu\text{g/g}$

Note: Concentrations are reported per gram of wet solids for the centrifuged solids.



ASR #	WP#
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100

File: L:\radchem\hydroxide\asr# 5729
Analysis Date: 5/9/2000
Print Date: 6/9/00

Governing Procedures: PNL-ALO-228: Determination of Hydroxyl (OH-), pH and Alkalinity of Aqueous Solutions, Leachates and Supernates and Operation of Brinkman 636 Auto-Titrator

Analyst: S. Swenda 6/16/00
Reviewer: S. Swenda 6/16/00


RPG #	Client ID	Concentration, moles/liter		
		First Point	Second Point	Third Point
00-01360	C104-composite.	0.81	0.77	
00-01360	C104-composite. Rep	0.82	0.79	
	RPD	0%	3%	
Reag. Blk.		0		
Standard 1		100%		
Standard 2		101%		
00-01360MS	Matrix spike	98%		

Note: Results are presented for the first, second, and third inflection points on the titration curves, as applicable. The first inflection point is generally associated with the hydroxide concentration. The second and third points generally represent the carbonate and bicarbonate concentrations.

0.25ML/DIV V(START)/ML 0.000 PH

2 3 4 5 6 7 8 9 10 11 12

BRINKMANN CAT # 2025015-1



C-104 sample

200 μ L of RPL# 00-1360

rgs
5/9/00

ROUTINE # 101
4 PH(INIT) 11.046 V(TE)/ML 5.000
1 V/ML 0.798 PH(M) 7.636
2 V/ML 1.551 PH(M) 4.756

pH Analysis

(Sample Receiving and Prep Laboratory)

Client: M. Urie ASRI/ARF/LOI/ITI: ASR-5729

Work Package: CMC QA Plan: Impact Level:

ACL #	Client Identification	1st pH Reading	2nd pH Reading	pH Average
00-1360	C104-B	12.13	12.13	12.1
<p>NOTE: pH measurements were done by drop analysis using a solid state probe. Calibration buffers of 7 & 10 were used with a separate check buffer of 7. Because the sample pH was outside the buffer range used a standardized 0.1186 M NaOH solution was checked before and after sample reading were taken. This solution should pH @ 13.07 if unexposed to CO₂ which it hasn't been.</p>				
0.1186 M NaOH	1 L. with organic free HI-H ₂ O standardized against NIST SRM 84j a-KAP prepared 3/1/2000 by RGS Chem Rec - 55 Exp. 3/2001			

M&TE: Sention 2001 # 192707-92

Analyst: Lori P. Darnell Date: 7-21-00

Reviewer: U.K. Ashok Date: 7/31/00

Calibration Buffers Used		BC#	
pH	Lot #	Exp. Date	Lot #
7	7	5-2000	179555
		5-2001	179557
		5-2001	179556

Beginning Check: 7.01 Ending Check: 7.01

NaOH pH = 12.83 ↓ pH = 12.83

Distribution

No. of Copies

OFFSITE

2	DOE/Office of Scientific and Technical Information
1	Harold Sturm Savannah River Technology Center PO Box 616, Road 1 Building 773-A, Room A-233 Aiken, SC 29808
1	Paul Townson BNFL, Inc 3000 George Washington Way Richland, WA 99352
1	Ed Higginbotham BNFL, Inc 3000 George Washington Way Richland, WA 99352

No. of Copies

ONSITE

4	<u>CH2M Hill Hanford Group</u> M. E. Johnson (4) A. N. Thompson	H4-10 H4-02
24	<u>Pacific Northwest National Laboratory</u> C. J. Barinaga J. P. Bramson K. J. Carson J. R. DesChane O. T. Farmer S. K. Fiskum L. R. Greenwood F. V. Hoopes R. T. Ratner D. R. Sanders M. J. Steele R. T. Steele C. Z. Soderquist R. G. Swoboda K. K. Thomas T. L. Trang-Le M. W. Urie J. J. Wagner Project File Technical Report Files (5)	P7-07 P8-08 P7-25 P7-25 P8-08 P7-22 P7-22 P7-22 P7-22 P7-22 P7-22 P7-22 P7-22 P7-22 P7-22 P7-22 P7-22 P7-22 P7-22 P7-28 K1-06

